



PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
1	8888635 DRAG KNOB ASSEMBLY	27	8888661 SILENT CAM
2	8888636 SPOOL RING	28	8888662 PINION GEAR
3	8888637 DRAG "D" WASHER	29	8888663 BEARING SCREW (3x)
4	8888638 DRAG "B" WASHER	30	8888664 STOPPER SCREW
5	8888639 DRAG "A" WASHER	31	8888665 STOPPER
6	8888640 SPOOL ASSEMBLY	32	8888666 MAIN BODY
7	8888641 MAIN SHAFT	33	8888667 HANDLE SCREW CAP
8	8888642 CLICK GEAR WASHER	34	8888668 SCREW CAP WASHER
9	8888643 CLICK GEAR	35	8888669 BALL BEARING
10	8888644 ROTOR NUT	36	8888670 DRIVE GEAR
11	8888645 ROTOR	37	8888671 SHIM
12	8888646 E-CLIP	38	8888672 BALL BEARING
13	8888647 BAIL SCREW	39	8888673 SIDEPLATE
14	8888648 ARM LEVER	40	8888674 SIDEPLATE SCREW (3x)
15	8888649 LINE ROLLER BEARING	41	8888675 HANDLE ASSEMBLY
16	8888650 BAIL ASSEMBLY	42	8888676 A/R SHAFT SPRING
17	8888651 BAIL HOLDER SCREW	43	8888677 A/R SHAFT
18	8888652 ARM LEVER PIN	44	8888678 A/R SHAFT KNOB
19	8888653 BAIL SPRING	45	8888679 A/R SHAFT KNOB SCREW
20	8888654 BAIL SPRING COVER	46	8888680 OSCILLATION GEAR
21	8888655 BAIL SPRING COVER SCREW	47	8888681 OSCILLATION SLIDER
22	8888656 KICK LEVER	48	8888682 OSCILLATION SLIDER SCREW
23	8888657 KICK LEVER SPRING	49	8888683 KICK LEVER COVER
24	8888658 KICK LEVER SCREW	50	8888684 KICK LEVER COVER SCREW
25	8888659 BALL BEARING	51	8888685 SPOOL CLICK
26	8888660 RATCHET	52	8888686 PUSH NUT
		53	8888687 A/R SPRING