



Key No.	Parts No.	Parts Name
1	6W3900520	Body
2	6W3064010	Washer (A)
3	6W3901010	Handle Screw
4	6W3902520	Rear Cover
5	6W3903010	Screw (A)
6	6W3603010	Anti-Reverse Lever
7	6W3604010	Screw (B)
8	6W3056010	Bushing (A)
9	6W3055010	Oscillating Gear
10	6W3052010	Oscillating Slider
11	6W3051010	Screw (C)
12	6W3050010	Plate
13	6W3906010	Screw (D)
14	6W3037010	Bushing (B)
15	6W3907020	Anti-Reverse Cam Spring
16	6W3033010	Drive Gear
17	6W3043010	Washer (B)
18	6W3041010	Bushing (C)
19	6W3908520	Side Cover
21	6W3910010	Screw (F)
22	6W3911520	Handle Assembly
23	6W3912010	Anti-Reverse Pawl Spring (A)
24	6W3913010	Anti-Reverse Pawl (A)
25	6W3914010	Screw (G)
26	6W3915510	Anti-Reverse Cam
27	6W3916010	Anti-Reverse Pawl (B)
28	6W3917510	Pinion Gear
30	6W3015010	Ball Bearing
31	6W3919020	Bearing Retainer
32	6W3095010	Screw (H)
33	6W3920010	Spacing Sleeve
34	6W3921010	Washer (D)
35	6W3922010	Roller Clutch
36	6W3923010	Washer (E)
37	6W3924010	Collar (A)
38	6W3925010	Collar (B)
39	6W3926020	Anti-Reverse Pawl Spring (B)
40	6W3927520	Rotor
41	6W3117010	Bail Trip Lever Spring
42	6W3928010	Collar (C)
43	6W3929020	Bail Trip Lever
44	6W3118010	Washer (F)
45	6W3930010	Screw (I)
46	6W3931010	Bail Spring Holder
47	6W3932020	Bail Spring
48	6W3933020	Bail Spring Shaft
49	6W3934520	Cover (A)
50	6W3674010	Screw (J)
51	6W3676010	Screw (K)
52	6W3675010	Screw (L)
53	6W3935020	Bail Arm
54	6W3062010	Collar (D)
55	6W3680510	Bushing (D)
56	6W3681010	Line Roller
57	6W3061010	Washer (G)
58	6W3936520	Bail Assembly
59	6W3675010	Screw (M)
60	6W3674010	Screw (N)
61	6W3937520	Cover (B)
62	6W3082010	Washer (H)
63	6W3087010	Rotor Nut
64	6W3065010	Rotor Nut Holding Plate
65	6W3689010	Screw (O)
66	6W3938510	Main Shaft
67	6W3939010	Click Gear
68-72	6W3940530	Spool Assembly
69	6W3696010	Drag Washer
70	6W3697010	Key Washer
71	6W3698010	Eared Washer
72	6W3699010	Drag Washer Retainer
73	6W3695010	Drag Knob Assembly

OPUS 6000 SPECIAL PARTS

Key No.	Parts No.	Parts Name
68-72	6W3940540	Spool Assembly