


Please order by parts number, not key number
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)



SPINNING REEL

OPUS PLUS 4000BRi



KEY NO.	PART NAME	PART NO.	KEY NO.	PART NAME	PART NO.
1	Drag Knob Assembly	WD0-6501	57	Screw	W49-1501
2	Spool Assembly	WD0-6602	58	Body	W74-2701
3	Washer	W74-2001	59	Handle Screw	W49-1401
4	Washer	W33-9402	60	Collar	W34-4701
5	Main Shaft	W48-9601	61	Screw	W49-1501
6	Rotor Nut	W33-9601	62	Screw	W74-2601
7	Screw	W74-2101	63	Clutch Lever (A)	W74-2801
8	Rotor Nut Holding Plate	W33-9501	64	Clutch Lever Bridge	W49-1701
9	Spring	W33-9701	65	Ball Bearing	W28-0100
10	Collar	W33-9801	66	Anti-Reverse Pawl Spring (B)	W34-3902
11	Ball Bearing	WD0-7201	67	Drive Gear	W49-1901
12	Spacing Sleeve	W34-0051	68	Washer	W34-3701
13	Spring	W34-0001	69	Ball Bearing	WD0-7301
14	Screw	W34-0401	70	Side Cover	WD0-6901
15	Cover (A)	W48-9701	71	Screw	W34-3201
16	Bail Holder Nut	W48-9801	72	Screw	W34-3101
17	Screw	W33-9001	73	Handle Assembly	WD0-7002
18	Screw	W33-9001	74	Screw	W74-2601
19	Rotor	WD0-6701	75	Clutch Lever (B)	W74-3001
20	Bail Assembly	W58-1401	76	Clutch Cam	W74-3101
21	Washer	W45-6601	77	Clutch Cam Spring	W74-3201
22	Line Roller	W33-8102	78	Click leaf Spring	W49-2601
23	Ball Bearing	WD0-6301	79	Retainer	W38-5001
24	Washer	W33-8202	80	Screw	W74-3301
25	Bail Arm	WD0-6801	81	Oscillating Slider Retainer	W49-2701
26	Screw	W74-2301	82	Oscillating Slider	W49-2801
27	Screw	W34-0401	83	Oscillating Gear	W49-2901
28	Cover (B)	W49-0301	84	Bushing	W45-8701
29	Bail Spring Shaft	W33-8702	85	Oscillating Plate	W49-3001
30	Bail Spring	W33-8802	86	Screw	W49-3101
31	Bail Spring Holder	W33-8901	87	Click leaf Spring	W49-3201
32	Bail Trip Lever Spring	W34-0501	88	Clutch Plate (A)	W74-3401
33	Bail Trip Lever	W34-0602	89	Screw	W74-3501
34	Washer	W46-4501	90	Clutch Plate (B)	W49-3501
35	Screw	W34-0703	91	Clutch Trip Lever	W49-3601
36	Screw	W34-3201	92	Spring	W49-3701
37	Bearing Retainer (A)	W74-2401	93	Washer	W38-6201
38	Ball Bearing	W49-0401	94	Drag Metal	W49-3801
40	Collar	W34-1201	95	Drag Washer	W49-3901
41	Washer	W34-1501	96	Eared Washer	W49-4001
42	Roller Clutch	W34-1401	97	Key Washer	W49-4101
43	Collar	W34-1601	98	Drag Coil Spring	W49-4201
44	Collar	W49-0601	99	Washer	W49-4301
45	Pinion Gear	W34-1802	100	Drag Screw	W49-4401
46	Screw	W74-2501	101	Drag Metal	W49-4501
47	Anti-Reverse Pawl	W49-0701	102	Washer	W49-4601
48	Anti-Reverse Pawl Spring (A)	W34-4401	103	Retainer	W49-4701
49	Anti-Reverse Cam Spring (A)	W34-1901	104	Rear Cover (A)	WD0-7101
50	Washer	W49-0801	105	Rear Cover (B)	W74-3701
51	Anti-Reverse Cam	W49-0901	106	Screw	W74-3801
52	Anti-Reverse Lever	WD0-5801	107	Drag Knob	W74-3901
53	Collar	W34-4101	108	Screw	W49-5201
54	Anti-Reverse Pawl (A)	W49-1101	109	Cap	W49-5301
55	Screw	W74-2601	110	Side Ring	W74-5101
56	Anti-Reverse Spring	W49-1201	111	Screw	W74-5201