



AE 10 SPARE PARTS LIST

KEY	PARTS NAME	PART NO.	KEY	PARTS NAME	PART NO.
100	MAIN BODY ASSY.	1210016604X	611	EARED WASHER	12611004-05907
105	PINION BEARING FIX PLATE	12105013-06001	612	KEY WASHER	12612003-06
105-1	PINION BEARING FIX BUSHING	12105023-01001	612-1	KEY WASHER	12612023-06
108	BODY/SIDE PLATE COVER	12108050-01X	700	DRIVE GEAR	12700075-02002
113	BODY PLATE COVER RETAINER	12113001-06001	702	PINION GEAR	12702106-03002
200	SIDE PLATE ASSY.	12200166-04X	708	OSCILLATING SLIDER	12708060-02001
300	ROTOR	12300174-04X	710	TRANSMISSION PLATE	12710002-05001
301	BAIL ARM	12301046-01X	718	MAIN SHAFT	12718165-06001
302	BAIL ARM SPRING	12302008-06001	719	CLICK GEAR	12719005-06001
304	BAIL ARM COVER	12304085-0AX	722	MAIN SHAFT BUSHING	12722014-01
305	KICK LEVEL	12305077-05001	800	ANTI-REVERSE BOTTON	12800070-02001
307	BAIL HOLDER	12307041-02X	801	ANTI-REVERSE BOTTON SPRING	12801023-06001
313	BAIL ASSY.	1231309906X	903	SPRING WASHER	12903001-06
315	LINE ROLLER	12315023-00	9101	ONE WAY BEARING	010717-572
317	LINE ROLLER WASHER	12317008-03001	9102	BALL BEARING	01071303-615
318	ROTOR NUT	12318017-03001	9103	BALL BEARING	01071103-615
323	BAIL ARM WASHER	12323011-01001	9104	BALL BEARING	01040725-615
325	BAIL ARM/AIL HOLDER SCREW	12325005-06001	9107	BALL BEARING DRAG WASHER RETAI	010717-592
400	NORMAL SPOOL ASSY	1240021304X	9202	DRIVE GEAR WASHER	028.1x12x0.3-6
400-1	SPARE SPOOL ASSY	1240013404X	9202-1	DRIVE GEAR WASHER	028.1x12x0.05-6
405	DARG WASHER RETAINER	12405003-06	9208	SIDE PLATE SCREW WASHER	022x3.6x0.2-8
407	CLUTCH LEVER SPRING	12407006-162	9301	SIDE PLATE SCREW	03112x6-617
500	HANDLE ASSY.	1250008904X	9303	OSCILLATION GEAR SCREW	03212.3436.3617
504	HANDLE SCREW CAP WASHER	12504004-0114	9304	LINE ROLLER SCREW	03412.6x7.5-61
513	HANDLE SCREW CAP	12513024-0AX	9305	PINION GEAR SCREW	03314x2x5-617
600	DRAG KNOB ASSY.	1260010101X	9306	BAIL COVER SCREW	03422x5-61
610	DRAG WASHER	12610007-000	9308	BAIL ARM/AIL HOLDER SCREW	03322.6x4.5-61