



AK-400 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	41000325	BODY ASSY.	711	47110014	GUIDE SLIDE BASE ASSY.
105	41050002	WORM SHAFT BUSHING	712	47120005	WORM SHAFT
117	41170003	RETAINER NUT	713	47130003	LINE GUIDE PAWL CAP
200	42000328	HANDLE SIDE PLATE ASSY	715	17150009	LINE GUIDE PAWL
202	42020007	RATCH	720	17200003	DRIVE GEAR SHAFT BUSHING
206	42060003	STOPPER CAP	800	48000002	CLUTCH SHAFT
216	42160005	ANTI-RE PAWL SPRING	801	48010002	CLUTCH SHAFT SPRING
220	42200007	SIDE PLATE HOLDDED SCREW	802	48020010	CLUTCH BAR
222	42220007	MAIN SIDE PLATE HOLDER	803	48030006	CLUTCH BAR SUPPORT
226	42260001	CONTROL PIN	804	48040018	CLUTCH SLIDER
300	43000564	VICE SIDE PLATE	805	48050002	PINION GEAR YOKE
302	43020009	WASHER	806	48060001	YOKE SPRING
303	43030004	CLICK BUTTON	807	48070002	YOKE BRAKED PLATE
304-1	43040001	CLICK PAWL	808	48080002	YOKE BRAKED PLATE SPRING
305	43050001	CLICK PAWL SPRING	809	48090003	CLUTCH BAR WASHER
306	43060001	CLICK PAWL SPRING PIN	810	48100002	CLUTCH SHAFT BUSHING
308	43080003	CLICK BUTTON RETAINER	812	48120001	BRAKED PLATE HOLDER
309	43090001	CLICK PIN	29000002	29000002	E RETAINER
400	44000124	SPOOL ASSY.	49000001	49000001	E RETAINER
401	44010001	SPOOL CLICK GEAR	29000001	29000001	E RETAINER
500	45000146	HANDLE ASSY.	0910241	0910241	BALL BEARING
516	45160031	HANDLE NUT RETAINER	0910365	0910365	BALL BEARING
600	46000006	CAST CONTROL CAP	0910153	0910153	BALL BEARING
608	46080002	DRAG WASHER RETAINER	0910015	0910015	BALL BEARING
609	16090009	DRAG SPRING WASHER	0910244	0910244	BALL BEARING
610	16100055	DRAG WASHER	0910211	0910211	BALL BEARING
610-1	16100037	DRAG WASHER	0920105	0920105	WASHER
610-2	16100038	DRAG WASHER	0920118	0920118	WASHER
611	16110006	EARED WASHER	0920160	0920160	WASHER
612	16120028	KEY WASHER	0920081	0920081	WASHER
612-1	16120027	KEY WASHER	0920292	0920292	WASHER
614	16140003	DRAG WASHER	0920527	0920527	WASHER
615	46150115	STAR DARG	0920076	0920076	WASHER
618	46180001	SPACER	0920066	0920066	WASHER
619	46190002	WASHER	0930700	0930700	SCREW
700	47000005	DRIVE GEAR	0930684	0930684	SCREW
701	47010005	DRIVE GEAR SHAFT	0930075	0930075	SCREW
702	47020065	PINION GEAR	0930226	0930226	SCREW
703	47030011	WORM SHAFT GUARD	0930429	0930429	SCREW
704	47040011	LINE GUIDE SUPPORT BAR	09301208	09301208	SCREW
705	47050007	TRANSMISSION GEAR	0940020	0940020	O RING
708	47080003	TRANSMISSION GEAR	0940027	0940027	O RING
709	47090006	TRANSMISSION GEAR BUSHING			