



AV-80b PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003658	MAIN BODY	702	27020343	PINION GEAR
105	0910332	PINION BEARING FIXED PLATE	705	27050073	TRANSMISSION GEAR
105-1	0910396	BALL BEARING PLATE	708	27080069	OSCILLATING SLIDER
108	21081311	CAP	716	27160010	OSCILLATION SLIDER PLATE
200	22003582	SIDE PLATE	718	27180613	MAIN SHAFT
201	22010290	MAIN BODY DECORATION	719	27190005	CLICK GEAR
201-1	22010291	SIDE PLATE DECORATION	722	27220005	CLICK GEAR WASHER
201-2	22010325	MAIN BODY DECORATION	722-1	27220036	CLICK GEAR WASHER
201-3	22010326	SIDE PLATE DECORATION	725	27250019	TRANSMISSION GEAR BUSHING
300	23003922	ROTOR	800	28000256	ANTI-REVERSE/ANTI-RE LEVER
301	23011799	BAIL ARM COVER	800-1	28000327	ANTI-REVERSE/ANTI-RE LEVER
304	23042431	BAIL ARM COVER	801	28010039	ANTI-RE LEVER SPRING
305	23050136	KICK LEVER	0910494	0910494	BALL BEARING
306	23060917	BAIL HOLDER COVER	0910184	0910184	BALL BEARING
307	23071411	BAIL HOLDER	0910139	0910139	BALL BEARING
309	23090030	BAIL ARM SUPPORT PIN	0910013	0910013	BALL BEARING
310	23100058	COMPRESSION SPRING	0920539	0920539	WASHER
313	23131406	BAIL WIRE ASSY.	0920209	0920209	WASHER
315	23150022	LINE ROLLER	0920170	0920170	WASHER
317	23170004	LINE ROLLERWASHER	0920377	0920377	WASHER
318	23180008	ROTOR NUT	0930452	0930452	SCREW
400	240011916	SPOOL ASSY.	0930562	0930562	SCREW
405	24050031	DRAG WASHER RETAINER	0930471	0930471	SCREW
407	24070026	EXTENSION SPRING	09301274	09301274	SCREW
412-1	24120018	SPOOL BUSHING	0930643	0930643	SCREW
500	25009840	HANDLE ASSY.	0930972	0930972	SCREW
504	25040003	HANDLE SCREW CAP WASHER	09301085	09301085	SCREW
513	25130745	HANDLE CAP	0930663	0930663	SCREW
600	26002909	DRAG KNOB ASSY.	0930575	0930575	SCREW
610	26100053	DRAG WASHER	0930945	0930945	SCREW
611	26110021	EARED WASHER	0930454	0930454	SCREW
612	26120063	KEY WASHER	0930058	0930058	SCREW
612-2	26120064	KEY WASHER	0930450	0930450	SCREW
700	27000332	DRIVE GEAR	0930544	0930544	SCREW