



**MIKE'S REEL REPAIR**  
 #108 - 31060 Peardonville Road  
 Abbotsford, B.C., Canada V2T 6K5  
 Toll Free 1-888-404-1119

AX-65/80. X-MEANS PAINT OR INJ. COLOR

SIZE	65	80		SIZE	65	80	
KEY NO.	PARTS NO.	PARTS NO.	PARTS NAMES	KEY NO.	PARTS NO.	PARTS NO.	PARTS NAMES
100	121001330C102	121001330C102	MAIN BODY	700	12700013-02003	12700013-02003	DRIVE GEAR ASSEMBLY
103	12103002-01003	12103002-01003	KICK LEVE	702	12702096-03002	12702096-03002	PINION GEAR
106	12106028-0A003	12106028-0A003	DRAG KNOB SEAT	703	12703020-01001	12703020-01001	PINION GEAR BUSHING
108	12108031-01726	12108031-01726	BODY AND SIDE PLATE WATER SEALED	706	12706007-03002	12706007-03002	TRANSMISSION GEAR
200	12200115-0C102	12200115-0C102	SIDE PLATE	708	12708052-02001	12708052-02001	OSCILLATION SLIDER
300	12300143-01726	12300143-01726	ROTOR	712	12712010-03001	12712010-03001	WORM SHAFT
301	12301037-01003	12301037-01003	BAIL ARM	713	12713007-06001	12713007-06001	WORM SHAFT RETAINER
304	12304066-0A003	12304066-0A003	BAIL ARM COVER	715	12715004-06001	12715004-06001	LINE GUIDE PWAL
306	12306036-0A003	12306036-0A003	BAIL HOLDER COVER	716	12716010-06001	12716010-06001	OSCILLATION SLIDER PLATE
307	12307031-02915	12307031-02915	BAIL HOLDER	718	12718144-06001	12718144-06001	MAIN SHAFT
308	12308006-03907	12308006-03907	BAIL ARM BUSHING	719	12719014-06001	12719014-06001	CLICK GEAR
309	12309003-01	12309010-012	BAIL ARM YOKE	721	12721011-01001	12721011-01001	MAIN SHAFT BUSHING
310	12310011-06002	12310011-06002	COMPRESSION SPRING	722	12722017-01001	12722017-01001	CLICK GEAR WASHER
313	1231306806002	1231306806002	BAIL ASSEMBLY	724	11724001-03001	11724001-03001	CLUTCH BLOCK SPRING
315	12315018-00	12315018-00	LINE ROLLER	733	12733001-06001	12733001-06001	WORMGUIDE SUPPORT BAR
317	12317003-03	12317003-03	LINE ROLLER WASHER	734	12734001-01001	12734001-01001	LINE GUIDE PWAL BUSHING
318	12318008-03	12318008-03	ROTOR NUT	800	12800055-01003	12800055-01003	ANTI-REVERSE LEVER
323	12323004-011	12323004-011	BAIL ARM WASHER	801	12801013-06	12801013-06	ANTI-REVERSE LEVER SPRING
324	12324004-011	12324004-011	BAIL HOLDER WASHER	903	12903002-06	12903002-06	SPRING WASHER
325	12325001-061	12325001-061	BAIL ARM WATER SEALED SCREW	9101	01104416	01104416	ONE WAY BALL BEARING
326	12326001-0A003	12326001-0A003	BAIL ARM WATER SEALED	9102	01102006-61	01102006-61	BALL BEARING
327	12327001-01003	12327001-01003	DEFEND WINDING RETAINER	9103	01091705-61	01091705-61	BALL BEARING
327-1	12327002-01003	12327002-01003	DEFEND WINDING RETAINER	9104	01050825-61	01050825-61	BALL BEARING
327-2	12327003-01001	12327003-01001	BRUSH	9108	01030625-61	01030625-61	BALL BEARING.
400	1240000404007	1240000504007	NORMAL SPOOL ASSY	9202	029.1x13x0.5-6	029.1x13x0.5-6	PINION GEAR WASHER
400-1	1240000404002	1240000504002	SPARE SPOOL ASSY	9202-1	029.1x13x0.3-6	029.1x13x0.3-6	DRIVE GEAR WASHER
412	12412012-03001	12412012-03001	SPOOL BUSHING	9209	023x5x0.3-7	023x5x0.3-7	LINE GUIDE PWAL WASHER
413	12413003-07	12413003-07	WATER PROOF SLEEVE	9301	03123X13-61	03123X13-61	SIDE PLATE SCREW
415	12415013-01003	12415013-01003	WATER PROOF RETAINER	9303	3212.3x7-611	3212.3x7-611	OSCILLATION SLIDER SCREW
500	1250008104005	1250008104005	HANDLE ASSEMBLY	9303-1	03315.92.66.561	03315.92.66.561	OSCILLATION SLIDER SCREW
504	12504005-01	12504005-01	HANDLE SCREW CAP WASHER	9304	03413.5x9-61	03413.5x9-61	LINE ROTOR SCREW
513	12513021-04002	12513021-04002	HANDLE SCREW CAP	9305	03327.52.6x6-61	03327.52.6x6-61	BALL BEARING SCREW
600	1260006801726	1260006801726	DRAG KNOB ASSEMBLY	9306	03422.6x8-61	03422.6x8-61	BAIL ARM COVER SCREW
610	12610014-00001	12610014-00001	DRAG WASHER	9308	03329.4x3x9-61	03329.4x3x9-61	BAIL ARM/AIL HOLDER SCREW
611	12611013-06001	12611013-06001	EARED WASHER	9316	03422.6x17-61	03422.6x17-61	ONE WAY BALL-BEARING SCREW
612	12612031-06001	12612031-06001	KEY WASHER	9321	03122x10-61	03122x10-61	KICK LEVER SCREW
612-1	12612015-06	12612015-06	KEY WASHER	9322	03221.6x3.2-61	03221.6x3.2-61	DEFEND WINDING RETAINER SCREW
612-2	12612032-06001	12612032-06001	KEY WASHER				