



CD-80a PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003522	MAIN BODY ASSY.	612-6	26120087	KEY WASHER
105	0910332	PINION BEARING FIXED PLATE	616	26160024	DRAG RUBBER RING
105-1	0910396	BALL BEARING PLATE	619	26190013	KNOB RETAINER
108	21080984	CAP	700	27000402	DRIVE GEAR
200	22003483	SIDE PLATE	702	27020343	PINION GEAR
202	22020022	CLICK PAWL	705	27050139	TRANSMISSION GEAR
300	23003831	ROTOR	708	27080108	OSCILLATING SLIDER
301	23011683	BAIL ARM	709	27090005	"C" RETAINER
304	23042253	BAIL ARM COVER	718	27180518	MAIN SHAFT
305	23050114	KICK LEVER	722	27220005	CLICK GEAR WASHER
307	23071338	BAIL HOLDER	722-1	27220036	CLICK GEAR WASHER
309	23090030	BAIL ARM SUPPORT PIN	725	27250019	TRANSMISSION GEAR BUSHING
310	23100043	COMPRESSION SPRING	726	27260015	CLUTCH CAM
313	23131259	BAIL WIRE ASSY.	727	27270060	CLUTCH BAR
315	23150011	LINE ROLLER	728	27280002	CLUTCH SPRING
317	23170008	LINE ROLLER WASHER	729	27290018	CLUTCH SLIDER
318	23180008	ROTOR NUT	730	27300016	PINION GEAR YOKE
400	240011218	SPOOL ASSY.	731	27310001	CLUTCH BLOCK SPRING
405	24050031	DRAG WASHER RETAINER	732	27320001	CLUTCH BAR BUSHING
405-1	24050012	DRAG WASHER RETAINER	800	28000255	ANTI-REVERSE/ANTI-RE LEVER
405-2	24050033	DRAG WASHER RETAINER	800-1	28000327	ANTI-REVERSE/ANTI-RE LEVER
406	24060017	SPOOL CLICK PAWL	801	28010039	ANTI-REVERSE SPRING
406-1	24060019	SPOOL CLICK PAWL	903	29030002	SPRING WASHER
406-2	24060024	SPOOL CLICK PAWL	0910352	0910352	BALL BEARING
407	24070026	EXTENSION SPRING	0910184	0910184	BALL BEARING
407-1	24070011	EXTENSION SPRING	0910141	0910141	BALL BEARING
407-2	24070014	EXTENSION SPRING	0910015	0910015	BALL BEARING
409	24090006	CLICK PAWL FIX PIN	0920209	0920209	WASHER
412	24120019	SPOOL BUSHING	0920168	0920168	WASHER
412-1	24120018	SPOOL BUSHING	0920210	0920210	WASHER
413	24130003	WATERPROOF RETAINER	0920340	0920340	WASHER
500	25004527	HANDLE ASSY	0930452	0930452	SCREW
504	25040008	HANDLE SCREW CAP WASHER	0930711	0930711	SCREW
513	25130440	HANDLE CAP	0930575	0930575	SCREW
600	26002568	DRAG KNOB ASSY.	0930246	0930246	SCREW
600-1	26001105	DRAG KNOB	0930196	0930196	SCREW
602	26020006	DRAG SPRING	0930562	0930562	SCREW
607	26070037	DRAG KNOB HOLDER	0930954	0930954	SCREW
609	26090016	CLICK GEAR	0930448	0930448	SCREW
610	26100053	DRAG WASHER	0930044	0930044	SCREW
610-1	26100087	DRAG WASHER	09301271	09301271	SCREW
611	26110021	EARED WASHER	0930643	0930643	SCREW
611-1	26110022	EARED WASHER	0930763	0930763	SCREW
612	26120063	KEY WASHER	0930810	0930810	SCREW
612-2	26120064	KEY WASHER	0930663	0930663	SCREW
612-3	26120038	KEY WASHER	0930429	0930429	SCREW