



MIKE'S REEL REPAIR
 #108 - 31000 Peardonville Road
 Abbotsford, B.C., Canada V2T 6K5
 Toll Free 1-888-404-1119

CL- 200L/ 202L SPARE PARTS LIST				X-MEANS PAINT OR INJ. COLOR					
KEY NO.	PARTS NO.	PARTS NAMES	0BB	2BB	KEY NO.	PARTS NO.	PARTS NAMES	0BB	2BB
100	11100027111	MAIN BODY ASSY.	.	.	701	1170100903001	DRIVE GEAR SHAFT ASSY.(MANUAL TRIP)	.	.
105	11105003-01	WORM SHAFT BUSHING	.	.	702	1170201103002	PINION GEAR	.	.
105-1	11105004-01	WORM SHAFT BUSHING	.	.	703	11703009-03	LEVEL WIND GUARD	.	.
117	14117001-03	HANDLE NUT	.	.	704	11704008-03907	STABILIZER BAR	.	.
200	11200035-01001	RIGHT SIDE PLATE	.	.	705	11705006-06	WORM SHAFT GEAR	.	.
201	11201008-06	ANTI-REVERSE PAWL	.	.	706	11706002-06	IDLE GEAR	.	.
207	11207017-03001	HOLD PLATE	.	.	707	11707008-11	MEDIUM TRANSMISSION GEAR	.	.
211	11211003-03001	ANTI-REVERSE PAWL PIN	.	.	709	11709002-03	TRANSMISSION GEAR BUSHING	.	.
215	11215009-03001	HOLD PLATE BUSHING	.	.	710	1171000906	LINE GUIDE ASSY.	.	.
216	11216001-06	ANTI-REVERSE PAWL SPRING	.	.	712	11712019-03	WORM SHAFT	.	.
216-1	11216002-06	CLUTCH CAM SLIDER SPRING	.	.	713	11713001-03907	PAWL CAP	.	.
221	11221001-07	O RING	.	.	715	11715003-06	LINE GUIDE PAWL	.	.
300	11300030-01001	LEFT SIDE PLATE	.	.	800	11800002-02002	CLUTCH CAM	.	.
302	11302002-06001	SPACER	.	.	801	11801001-06	CLUTCH CAM SPRING	.	.
302-1	11302005-03	SPOOL SHAFT BUSHING	.	.	802	11802003-01	CLUTCH BAR	.	.
302-3	11302006-03	SPACER	.	.	804	11804004-06	CLUTCH CAM SLIDER (MANUAL TRIP)	.	.
303	11303007-03907	CLICK BUTTON	.	.	804	11804005-06	CLUTCH CAM SLIDER (AUTO TRIP)	.	.
304	11304003-06	CLICK PAWL	.	.	805	11805002-01	PINION GEAR YOKE	.	.
305	11305001-01001	CLICK PAWL SPRING	.	.	806	11806001-06	YOKE SPRING	.	.
311	11311007-06001	SIDE PLATE COVERS	.	.	9102	01081805-61	BALL BEARING	.	.
400	11400029-01001C	GRAPHITE SPOOL ASSY.	.	.	9106	01041104-61	BALL BEARING	.	.
401	11401001-05002	CLICK GEAR	.	.	9201	028.1x12x0.5-6	DRIVE GEAR SHAFT WASHER	.	.
500	1150000504907	DOUBLE HANDLE ASSY.	.	.	9201-1	025.1x8x0.2-6	DRIVE GEAR SHAFT WASHER	.	.
500	1150001304907	BALANCE WEIGHT HANDLE ASSY.	.	.	9202	025.1x10.5x2-6	LEVEL WIND GUARD WASHER	.	.
516	11516001-01	HANDLE NUT HOLDER	.	.	9205	028.2x22x1-1	DRIVE GEAR WASHER	.	.
600	11600014-03001	CAST CONTROL CAP	.	.	9206	024.05x10x0.2-6	CLICK BUTTON WASHER	.	.
609	11609003-05907	DRAG SPRING WASHER	.	.	9301	03422.6x13-61	RIGHT SIDE PLATE SCREW	.	.
610	11610004-006	DRAG WASHER	.	.	9302	03327.52.6x6-61	CLICK PAWL SCREW	.	.
610-1	11610003-006	DRAG WASHER	.	.	9307	03412.6x4-61	HANDLE NUT HOLDER SCREW	.	.
611	11611005-06	EARED WASHER	.	.	9311	03222.6x12-61	LEFT SIDE PLATE SCREW	.	.
612	11612007-06001	KEY WASHER	.	.	9311	03122.6x8-61	LEFT SIDE PLATE SCREW	.	.
612-1	11612007-06003	KEY WASHER	.	.	9312	03325.2x2x4.561	TRANSMISSION GEAR SCREW	.	.
614	11614001-06	TENSION WASHER	.	.	9314	03222x4.5-61	CLICK GEAR SCREW(GRAPHITE SPOOL USED)	.	.
615	11615003-01	STAR DRAG	.	.	9316	03414x5-617	CLUTCH BAR SCREW	.	.
617	11617005-03	DRIVE GEAR SHAFT BUSHING	.	.	9319	03312x5-61	CLUTCH CAM SCREW	.	.
617	11617006-01	DRIVE GEAR SHAFT BUSHING	.	.	9401	11900001-06	DRIVE GEAR SHAFT "E" RETAINER	.	.
700	11700008-03002	DRIVE GEAR	.	.	9404	12900001-06	WORM SHAFT "E" RETAINER	.	.
701	1170100903001A	DRIVE GEAR SHAFT ASSY.(AUTO TRIP)