



MIKE'S REEL REPAIR
 #108 - 31060 Peardonville Road
 Abbotsford, B.C., Canada V2T 6K5
 Toll Free 1-888-404-1119

CN-15C 2+1BB

KEY NO.	PARTS NO.	PARTS NAMES	KEY NO.	PARTS NO.	PARTS NAMES
100	1110004701006	MAIN BODY ASSY.	615	14615002-04002C	ALUM STAR DRAG
105	11105008-03001	WORM SHAFT BUSHING	617	11617005-03	DRIVE GEAR SHAFT BUSHING
107	11107017-03001	LINE GUARD	700	11700008-03002	DRIVE GEAR
117	14117001-03	HANDLE NUT	701	1170102803001	DRIVE GEAR SHAFT ASSY.(MANUAL TRIP)
200	11200054-01006	RIGHT SIDE PLATE	701	1170102803001A	DRIVE GEAR SHAFT ASSY.(AUTO TRIP)
201	11201008-06	ANTI-REVERSE PAWL	702	1170201103002	PINION GEAR ASSY.
207	11207017-03001	HOLD PLATE	720	11720002-06001	ONE WAY CLUTCH INNER RING
211	11211003-03001	ANTI-REVERSE PAWL PIN	800	11800002-02002	CLUTCH CAM
216	11216001-06	ANTI-REVERSE PAWL SPRING	801	11801001-06	CLUTCH CAM SPRING
216-1	11216002-06	CLUTCH CAM SLIDER SPRING	802	11802003-0183	CLUTCH BAR
221	11221001-07	ANTI-REVERSE PAWL PIN	804	11804004-06	CLUTCH CAM SLIDER (MANUAL TRIP)
224	11224001-02905	ONE WAY CLUTCH BEARING CAP	804	11804005-06	CLUTCH CAM SLIDER (AUTO TRIP)
300	11300030-01006	LEFT SIDE PLATE	805	11805002-01	PINION GEAR YOKE
302	11302002-06001	SPACER WASHER	806	11806001-06	YOKE SPRING
302-3	11302006-03	SPACER WASHER	9101	01030625-61	BALL BEARING
303	11303007-03907	CLICK BUTTON	9103	01101612-6	ONE WAY BEARING
304	11304003-06	CLICK PAWL	9106	01041104-6	BALL BEARING
305	11305001-01001	CLICK PAWL SPRING	9201	025.1x8x0.2-6	DRIVE GEAR SHAFT WASHER
311	11311007-06001	SIDE PLATE COVERS	9202	025.1x10x0.2-6	DRIVE GEAR SHAFT WASHER
400	11400042-04005	ALUMINUM SPOOL ASSY.	9204	025.9x10x0.2-6	HANDLE NUT WASHER
401	11401001-05002	CLICK GEAR	9205	028.2x22x1-1	DRIVE GEAR WASHER
500	11500013061	DOUBLE HANDLE ASSY.	9206	024.05x10x0.2-8	CLICK BUTTON WASHER
500	1150000504907	BALANCE WEIGHT HANDLE ASSY	9301	03422.6x13-61	RIGHT SIDE PLATE SCREW
516	11516001-01	HANDLE NUT HOLDER	9302	03322.6x6-61	HOLD PLATE SCREW
600	11600014-03001	CAST CONTROL CAP	9302-1	03327.52.67.561	HOLD PLATE SCREW
608	11608004-06	BALL BEARING RETAINER	9307	03412.6x4-61	HANDLE NUT HOLDER SCREW
609	14609001-05907	DRAG SPRING WASHER	9311	03222.6x12-61	LEFT SIDE PLATE SCREW
610	11610003-006	DRAG WASHER	9314	03212x5-61	CLICK GEAR SCREW
610-1	11610004-006A	DRAG WASHER	9316	03414x5-617	CLUTCH CAM SCREW
611	11611005-06	EARED WASHER	9319	03312x5-61	CLUTCH CAM SCREW
612	11612007-06001	KEY WASHER	9322	03412.6x14-61	LINE GUARD SCREW
612-1	11612007-06003	KEY WASHER	9323	03222.6x4.5-61	ONE WAY CLUTCH BEARING CAP SCREW
614	11614001-06	TENSION WASHER	9401	11900001-06	DRIVE GEAR SHAFT "E" RETAINER