



**MIKE'S REEL REPAIR**

#108 - 31060 Peardonville Road  
Abbotsford, B.C., Canada V2T 6K5  
Tel! Free 1-888-404-1119

**CN-30D 2+1BB SPARE PARTS LIST**

KEY NO.	PARTS NO.	PARTS NAMES	KEY NO.	PARTS NO.	PARTS NAMES
100	1110001501831	MAIN BODY ASSY.	706	11708003-06	IDLE GEAR
105	11105003-01	WORM SHAFT BUSHING	707	11707003-01	MEDIUM TRANSMISSION GEAR
117	14117001-03	HANDLE NUT	708	11708003-11	TRANSMISSION GEAR
200	11200053-01006	RIGHT SIDE PLATE	709	11709002-03	TRANSMISSION GEAR BUSHING
201	11201001-06	ANTI-REVERSE PAWL	710	1171001306917	LINE GUIDE ASSY.
207	11207011-03001	HOLD PLATE	712	11712014-03	WORM SHAFT
211	11211002-03001	ANTI-REVERSE PAWL PIN	713	11713001-03907	PAWL CAP
212	112120010183	COUNTER COVER ASSY	715	11715003-06	LINE GUIDE PAWL
215	11215009-03001	BALL BEARING HOLD PLATE	720	11720002-06001	ONE WAY CLUTCH INNER RING
216	11216001-06	ANTI-REVERSE PAWL SPRING	800	11800002-02002	CLUTCH CAM
221	11221001-07	ANTI-REVERSE PAWL PIN	801	11801001-06	CLUTCH CAM SPRING
224	11224001-02905	ONE WAY CLUTCH BEARING CAP	802	11802005-01X	CLUTCH BAR
300	11300025-0183	LEFT SIDE PLATE	804	11804001-06	CLUTCH CAM SLIDER
302	11302002-06001	SPACER	805	11805001-06	PINION GEAR YOKE
303	11303004-03907	CLICK BUTTON	806	11806001-06	CAST CONTROL CAP SPRING
304	11304003-06	CLICK PAWL	910	11910001-01	DEPTH COUNTER
305	11305001-01001	CLICK PAWL SPRING	9101	01030625-5	BALL BEARING
311	11311004-06001	SIDE PLATE COVERS	9103	01101612-6	ONE WAY CLUTCH BEARING
400	11400033-04005	ALUMINUM SPOOL ASSY.	9106	01041104-61	BALL BEARING
401	11401001-05002	CLICK GEAR	9201	025.1x8x0.2-6	DRIVE GEAR SHAFT WASHER
500	1150000606002	BALANCE WEIGHT HANDLE ASSY.	9202	025.1x10.5x.2-6	LINE GUIDE/DRIVE GEAR SHAFT WASHER
516	11516001-01	HANDLE NUT HOLDER	9204	025.9x10x0.2-6	HANDLE NUT WASHER
600	11600014-03001	CAST CONTROL CAP	9205	028.2x22x1-1	DRIVE GEAR WASHER
608	11608004-06	BALL BEARING RETAINER	9206	024.05x10x0.2-8	CLICK BUTTON WASHER
609	14609001-05907	DRAG WASHER	9210	025.1x10.5x.5-6	LEVEL WIND GUARD WASHER
610	11610004-008A	DRAG SPRING WASHER	9301	03423.0x13-61	RIGHT SIDE PLATE SCREW
610-1	11610003-006	DRAG WASHER	9302	03327.52.6x6-61	HOLD PLATE SCREW
611	11611005-06	EARED WASHER	9307	03412.6x4-61	HANDLE NUT HOLDER SCREW
612	11612007-06001	KEY WASHER	9311	03223x12-61	LEFT SIDE PLATE SCREW
612-1	11612007-06003	KEY WASHER	9312	03327.52.67.561	TRANSMISSION GEAR SCREW
614	11614001-06	TENSION WASHER	9314	03212x5-61	CLICK GEAR SCREW
615	11615007-04002C	STAR DRAG	9316	03414x5-617	CLUTCH BAR SCREW
617	11617007-03	DRIVE GEAR SHAFT BUSHING	9319	03312x5-61	CLUTCH CAM SCREW
700	11700006-032	DRIVE GEAR	9320	03122x26-61	COUNTER COVER SCREW
701	1170102103A	DRIVE GEAR SHAFT ASSY. (AUTO TRIP)	9320-1	03122x8-62	COUNTER COVER SCREW
701	1170102103	DRIVE GEAR SHAFT ASSY. (MANUAL TRIP)	9323	03222.6x4.5-61	ONE WAY CLUTCH BEARING SCREW
702	11702005-061	PINION GEAR	9401	11900001-06	DRIVE GEAR SHAFT "E" RETAINER
703	11703007-03907	LEVEL WIND GUARD	9404	12900001-06	WORM SHAFT "E" RETAINER
704	11704005-03907	STABILIZER BAR	9404-1	11900002-06	TRANSMISSION GEAR "E" RETAINER
705	11705008-06	WORM SHAFT GEAR	9504	11901001-06	IDLE GEAR"C" RETAINER