



**MIKE'S REEL REPAIR**  
 #108 - 31060 Peardonville Road  
 Abbotsford, B.C., Canada V2T 6K5  
 Toll Free 1-888-404-1119

X-MEANS PAINT OR INJ. COLOR

CN-30L			CN-30		
SIZE	30	PARTS NAMES	SIZE	30	PARTS NAMES
KEY NO.	PARTS NO.	PARTS NAMES	KEY NO.	PARTS NO.	PARTS NAMES
100	1110006001x	MAIN BODY ASSY.	707	11707003-01	TRANSMISSION GEAR
105	11105003-01	WORM SHAFT BUSHING	709	11709002-03	TRANSMISSION GEAR BUSHER
105-1	11105004-01	WORM SHAFT BUSHING	710	1171001306X	WORM GAUDE
117	11117005-06001	HANDLE NUT	712	11712010-03907	WORM SHAFT
200	11200067-01X	RIGHT SIDE PLATE	713	11713001-03907	PAWL CAP
201	11201013-06001	ANTI-REVERSE PAWL	715	11715003-06	LINE GUIDE PAWL
204	11204008-06001	COMPRESSION SPRING	720	11720002-06001	DRIVE GEAR BUSHING
207	11207023-06001	HOLD PLATE	800	11800004-02002	CLUTCH CAM
208	11208013-06001	SIDE PLATE COVERS	801	11801005-06001	CLUTCH CAM SPRING
211	11211005-03001	ANTI-REVERSE PAWL PIN	802	11802003-01X	CLUTCH BAR
215	11215009-03002	HOLD PLATE BUSHING	804	11804008-06001	CLUTCH CAM SLIDER
216	11216001-06001	ANTI-REVERSE PAWL SPRING	805	11805003-03001	PINION GEAR YOKE
221	11221001-07	O RING	806	11806001-06	ANTI-RE PAWL BUSHING
224	11224001-02905	ONE WAY CLUTCH BEARING CAP	807	11807001-06001	PINION GEAR YOKE PLATE
300	11300025-01X	LEFT SIDE PLATE	912	11912006-04001	COVER BOARD
302	11302002-06001	SPACER	9101	01030625-61	BALL BEARING
303	11303004-03907	CLICK BUTTON	9103	01101612-6	ONE WAY CLUTCH BEARING
304	11304003-06	CLICK PAWL	9106	01041104-61	BALL BEARING
305	11305001-01002	CLICK PAWL SPRING	9201	025.1x13x0.5-6	DRIVE GEAR SHAFT WASHER
311	11311004-06001	SIDE PLATE COVERS	9201-1	028x10x0.5-6	DRIVE GEAR SHAFT WASHER
400	11400033-04X	ALUMINUM SPOOL ASSY.	9202	025.1x10.5x.2-6	LINE GUIDE WASHER
401	11401001-05002	CLICK GEAR	9204	025.9x10x0.2-6	HANDLE WASHER
500	1150000606X	BALANCE WEIGHT HANDLE ASSY.	9205	028x36x1-1	DRIVE GEAR WASHER
516	11516001-01	HANDLE NUT HOLDER	9206	024.05x10x0.2-8	CLICK BUTTON WASHER
600	11600016-03X	CAST CONTROL CAP	9210	025.1x10.5x.5-6	LEVEL WIND GEAR WASHER
608	11608004-06	BALL BEARING RETAINER	9301	03213x11.8-61	RIGHT SIDE PLATE SCREW
609	14609003-05907	DRAG SPRING WASHER	9301-1	03122.6x9-61	RIGHT SIDE PLATE SCREW
610	11610006-01002	DRAG WASHER	9302	3327.52.67.561	HOLD PLATE SCREW
610-1	11610005-01001	DRAG WASHER	9302-1	03222.6x9.5-61	HOLD PLATE SCREW
611	11611012-06001	EARED WASHER	9307	03412.6x4-61	HANDLE NUT HOLDER SCREW
612	11612012-06001	KEY WASHER	9311	03223x12-61	LEFT SIDE PLATE SCREW
612-1	11612015-06001	KEY WASHER	9313	3322.6x6-61	CLICK PAWL SPRING SCREW
614	11614001-06	TENSION WASHER	9314	03212.0x5.0-61	CLICK GEAR SCREW
615	11615007-04X	STAR DRAG	9316	03414x5-61	CLUTCH BAR SCREW
700	11700027-06003	DRIVE GEAR	9317	03312x3.5-61	CLUTCH CAM SCREW
701	1170103106001	DRIVE GEAR SHAFT ASSY.(AUTO TRIP)	9319	03312x5-61	CLUTCH CAM SCREW
702	11702033-06002	PINION GEAR ASSY.	9323	03222.6x4.5-61	ONE WAY CLUTCH BEARING SCREW
703	11703007-03907	LEVEL WORM GUARD	9401	11900001-06	WORM SHAFT "E" RETAINER
704	11704005-03907	WORMGUIDE SUPPORT BAR	9404	12900001-06	WORMGUIDE SUPPORT BAR E RETAINER
705	11705008-06	SPOOL TRANSMISSION GEAR	9504	11901001-06	LEVEL WIND GEAR C RETAINER
706	11706003-06	LEVEL WIND GEAR			