



CN-45L 2+1BB. SPARE PARTS LIST

X-MEANS PAINT OR INJ.COLOR

KEY NO.	PARTS NO.	PARTS NAMES	KEY NO.	PARTS NO.	PARTS NAMES
100	1110001601831	MAIN BODY ASSY.	704	11704004-03907	STABILIZER BAR
105	11105003-01	WORM SHAFT BUSHING	705	11705008-06	WORM SHAFT GEAR
117	14117001-03	HANDLE NUT	706	11706003-06	IDLE GEAR
200	11200052-01006	RIGHT SIDE PLATE	707	11707003-01	MEDIUM TRANSMISSION GEAR
201	11201001-06	ANTI-REVERSE PAWL	709	11709002-03	TRANSMISSION GEAR BUSHING
207	11207003-06001	HOLD PLATE	710	1171001406917	LINE GUIDE ASSY.
211	11211002-03001	ANTI-REVERSE PAWL PIN	712	11712011-03907	WORM SHAFT
215	11215009-03001	HOLD PLATE BUSHING	713	11713001-03907	PAWL CAP
216	11216001-06	ANTI-REVERSE PAWL SPRING	715	11715003-06	LINE GUIDE PAWL
221	11221001-07	ANTI-REVERSE PAWL PIN	720	11720002-06001	ONE WAY CLUTCH INNER RING
224	11224001-02905	ONE WAY CLUTCH BEARING CAP	800	11800002-02002	CLUTCH CAM
300	11300026-0183	LEFT SIDE PLATE	801	11801001-06	CLUTCH CAM SPRING
302	11302002-06001	SPACER	802	11802004-0183	CLUTCH BAR
303	11303004-03907	CLICK BUTTON	804	11804001-06	CLUTCH CAM SLIDER
304	11304003-06	CLICK PAWL	805	11805001-06	PINION GEAR YOKE
305	11305001-01001	CLICK PAWL SPRING	806	11806001-06	YOKE SPRING
311	11311005-06001	SIDE PLATE COVERS	9101	01030625-5	BALL BEARING
400	11400034-04X1	ALUMINUM SPOOL ASSY.	9103	01101612-6	ONE WAY CLUTCH BEARING
401	11401001-05002	CLICK GEAR	9106	01041104-61	BALL BEARING
516	11516001-01	HANDLE NUT HOLDER	9201	025.1x8x0.2-€	DRIVE GEAR SHAFT WASHER
500	1150000606002	BALANCE WEIGHT HANDLE ASSY.	9202	025.1x10.5x.2-€	LEVEL WIND GUARD WASHER
600	11600014-03001	CAST CONTROL CAP	9204	025.9x10x0.2-6	HANDLE NUT WASHER
608	11608004-06	BALL BEARING RETAINER	9205	028.2x22x1-1	DRIVE GEAR WASHER
609	14609001-05907	DRAG SPRING WASHER	9206	024.05x10x0.2-€	CLICK BUTTON WASHER
610	11610004-006A	DRAG WASHER	9210	025.1x10.5x.5-€	LINE GUIDE WASHER
610-1	11610003-006	DRAG WASHER	9301	03423.0x13-61	RIGHT SIDE PLATE SCREW
611	11611005-06	EARED WASHER	9302	03327.52.6x6-61	HOLD PLATE SCREW
612	11612007-06001	KEY WASHER	9307	03412.6x4-61	HANDLE NUT HOLDER SCREW
612-1	11612007-06003	KEY WASHER	9311	03223x12-61	LEFT SIDE PLATE SCREW
614	11614001-06	TENSION WASHER	9312	03327.52.67.561	TRANSMISSION GEAR SCREW
615	11615007-04002C	STAR DRAG	9314	03212.0x5.0-61	CLICK GEAR SCREW
617	11617005-03	DRAG GEAR SHAFT RETAINER	9316	03414x5-61	CLUTCH BAR SCREW
700	11700006-032	DRIVE GEAR	9319	03312x5-61	CLUTCH CAM SCREW
701	1170102103A	DRIVE GEAR SHAFT ASSY.(AUTO TRIP)	9323	03222.6x4.5-61	ONE WAY CLUTCH BEARING SCREW
701	1170102103	DRIVE GEAR SHAFT ASSY.(MANUAL TRIP)	9401	11900001-06	DRIVE GEAR SHAFT "E" RETAINER
702	11702005-061	PINION GEAR	9404	12900001-06	WORM SHAFT "E" RETAINER
703	11703006-03907	LEVEL WIND GUARD	9504	11901001-06	IDLE GEAR"C" RETAINER