



MIKE'S REEL REPAIR
 #108 - 31060 Peardonville Road
 Abbotsford, B.C., Canada V2T 6K5
 Toll Free 1-888-404-1119

CN-55/55W.2+1BB				X-MEANS PAINT OR INJ. COLOR			
SIZE	55	55W		SIZE	55	55W	
KEY NO.	PARTS NO.	PARTS NO.	PARTS NAMES	KEY NO.	PARTS NO.	PARTS NO.	PARTS NAMES
100	1110005001006	1110005101006	MAIN BODY ASSY.	701	1170103106001	1170103106001	DRIVE GEAR SHAFT ASSY.(AUTO TRIP)
107	11107018-06001	11107018-06001	LINE GUARD	702	1170203006002	1170203006002	PINION GEAR ASSY.
108	11108008-06001	11108008-06001	HANGER	720	11720002-06001	11720002-06001	DRIVE GEAR BUSHING
108-1	11108009-06001	11108009-06001	HANGER	800	11800004-02002	11800004-02002	CLUTCH CAM
117	11117005-06001	11117005-06001	HANDLE NUT	801	11801001-06	11801001-06	CLUTCH CAM SPRING
200	11200056-01006	11200056-01006	RIGHT SIDE PLATE	802	11802004-0183	11802004-0183	CLUTCH BAR
201	1201010-06001	1201010-06001	ANTI-REVERSE PAWL	804	11804007-06001	11804007-06001	CLUTCH CAM SLIDER
207	11207022-06001	11207022-06001	HOLD PLATE	805	11805003-03001	11805003-03001	PINION GEAR YOKE
208	11208012-06001	11208012-06001	SIDE PLATE COVERS	806	11806001-06	11806001-06	ANTI-RE PAWL BUSHING
211	11211002-03001	11211002-03001	ANTI-REVERSE PAWL PIN	9101	01040725-61	01040725-61	BALL BEARING
215	11215009-03002	11215009-03002	HOLD PLATE BUSHING	9103	01101612-6	01101612-6	ONE WAY CLUTCH BEARING
216	11216001-06	11216001-06	ANTI-REVERSE PAWL SPRING	9106	01030625-61	01030625-61	BALL BEARING
221	11221001-07	11221001-07	O RING	9201	025.1x11.5x.5-6	025.1x11.5x.5-6	DRIVE GEAR SHAFT WASHER
224	11224001-02905	11224001-02905	ONE WAY CLUTCH BEARING CAP	9202	025.1x10.5x.2-6	025.1x10.5x.2-6	LINE GUIDE WASHER
300	11300039-01006	11300039-01006	LEFT SIDE PLATE	9204	025.9x10x0.2-6	025.9x10x0.2-6	HANDLE WASHER
302	11302002-06001	11302002-06001	SPACER	9205	028x36x1-1	028x36x1-1	DRIVE GEAR WASHER
303	11303004-03907	11303004-03907	CLICK BUTTON	9206	024.05x10x0.2-8	024.05x10x0.2-8	CLICK BUTTON WASHER
304	11304003-06	11304003-06	CLICK PAWL	9301	03223x12-61	03223x12-61	RIGHT SIDE PLATE SCREW
305	11305001-01001	11305001-01001	CLICK PAWL SPRING	9301-1	03223x20-61	03223x20-61	RIGHT SIDE PLATE SCREW
311	11311008-06001	11311008-06001	SIDE PLATE COVERS	9301-2	03122.6x12-61	03122.6x12-61	RIGHT SIDE PLATE SCREW
312	11312001-06001	11312001-06001	BALL BEARING HOLD PLATE	9302	3327.52.67.561	3327.52.67.561	HOLD PLATE SCREW
400	11400043-04005	11400044-04005	ALUMINUM SPOOL ASSY.	9302-1	03222.6x9.5-61	03222.6x9.5-61	HOLD PLATE SCREW
401	11401001-05002	11401001-05002	CLICK GEAR	9307	03412.6x4-61	03412.6x4-61	HANDLE NUT HOLDER SCREW
500	1150000606001	1150000606001	BALANCE WEIGHT HANDLE ASSY.	9309	03222.6x15-61	03222.6x15-61	HANGER SCREW
516	11516001-01	11516001-01	HANDLE NUT HOLDER	9309-1	03213x12-61	03213x12-61	HANGER SCREW
600	11600016-03001	11600016-03001	CAST CONTROL CAP	9309-2	03222.6x9.5-61	03222.6x15-61	HANGER SCREW
608	11608004-06	11608004-06	BALL BEARING RETAINER	9311	03223x10-61	03223x10-61	LEFT SIDE PLATE SCREW
609	14609003-05907	14609003-05907	DRAG SPRING WASHER	9311-1	03223x16-61	03223x16-61	LEFT SIDE PLATE SCREW
609-1	14609004-05907	14609004-05907	DRAG SPRING WASHER	9313	3322.6x6-61	3322.6x6-61	CLICK PAWL SPRING SCREW
610	11610010-01001	11610010-01001	DRAG WASHER	9314	03212.0x5.0-61	03212.0x5.0-61	CLICK GEAR SCREW(ALUMINUM SPOOL USED)
611	11611018-06001	11611018-06001	EARED WASHER	9316	03414x5-617	03414x5-617	CLUTCH BAR SCREW
612	11612019-06001	11612019-06001	KEY WASHER	9317	03312x3.5-61	03312x3.5-61	CLUTCH CAM SCREW
612-1	11612022-06001	11612022-06001	KEY WASHER	9319	03312x5-61	03312x5-61	CLUTCH CAM SCREW
614	11614001-06	11614001-06	TENSION WASHER	9323	03222.6x4.5-61	03222.6x4.5-61	ONE WAY CLUTCH BEARING SCREW
615	11615007-04002C	11615007-04002C	STAR DRAG	9401	11900001-06	11900001-06	WORM SHAFT "E" RETAINER
700	11700028-06002	11700028-06002	DRIVE GEAR				