



CSD-10S PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001690	MAIN BODY	702	17020397	PINION GEAR
102	11020053	BODY FOOT	720	17200003	DRIVE GEAR SHAFT BUSHING
114	11140037	CLAMP	800	18000023	CLUTCH SHAFT
115	11150013	WUNG SCREW	801	18010016	CLUTCH SPRING
116	11160012	WING NUT	802	18020120	CLUTCH BAR ASSY.
117-1	11170002	RETAINER NUT	804	18040008	CLUTCH SLIDER
117	11170011	RETAINER NUT	805	18050004	PINION GEAR YOKE
120	21200002	MAIN BODY PIN	806	18060006	YOKE SPRING
200	12001890	HANDLE SIDE PLATE ASSY	815	18150005	CLUTCH BAR SCREW
201	12010037	ANTI-RE PAWL	29000006	29000006	C RETAINER
202	12020019	RATCH	29000002	29000002	E RETAINER
207	12070094	HOLDED PLATE	0910469	0910469	BALL BEARING
211	12110016	ANTI-RE PAWL PIN	0910153	0910153	BALL BEARING
215	12150013	HOLD PLATE BUSHING	0910229	0910229	BALL BEARING
216	12160009	ANTI-RE PAWL SPRING	0910432	0910432	BALL BEARING
300	13001024	VICE SIDE PLATE	0910468	0910468	BALL BEARING
302	43020018	BUSHING	0920435	0920435	WASHER
302-3	13020030	WASHER	0920114	0920114	WASHER
303	13030074	CLICK BUTTON	0920162	0920162	WASHER
304	13040023	CLICK PAWL	0920448	0920448	WASHER
305	13050009	CLICK PAWL SPRING	0920370	0920370	WASHER
400	14000876	SPOOL ASSY.	0920485	0920485	WASHER
401-2	14010030	CLICK GEAR	0920304	0920304	WASHER
500	15000343	HANDLE ARM ASSY.	0920133	0920133	WASHER
515	15150002	SCREW	0920488	0920488	WASHER
600	16000142	CAST CONTROL CAP	0920458	0920458	WASHER
609	16090009	DRAG SPRING WASHER	09301182	09301182	SCREW
610	16100068	DRAG WASHER	0930525	0930525	SCREW
612	16120073	KEY WASHER	09301183	09301183	SCREW
612-1	16120035	KEY WASHER	0930988	0930988	SCREW
612-2	26120056	KEY WASHER	0930194	0930194	SCREW
614	16140003	DRAG WASHER	0930196	0930196	SCREW
615	16150191	STAR DARG ASSY	0930202	0930202	SCREW
618	46180002	WASHER	0930501	0930501	SCREW
700	17000349	DRIVE GEAR	0940032	0940032	O RING
701	17010151	DRIVE GEAR SHAFT ASSY.			