



CSD-15S PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001831	MAIN BODY ASSY	800	18000023	CLUTCH SHAFT
102	11020046	BODY FOOT	801	18010016	CLUTCH SPRING
114	11140005	CLAMP	802	18020120	CLUTCH BAR ASSY.
115	11150003	WUNG SCREW	804	18040015	CLUTCH SLIDER
116	11160012	WING NUT	805	18050004	PINION GEAR YOKE
117-1	11170002	RETAINER NUT	806	18060001	YOKE SPRING
117	11170011	RETAINER NUT	806-1	18060007	YOKE SPRING
120	21200002	MAIN BODY PIN	815	18150005	CLUTCH BAR SCREW
200	12001890	HANDLE SIDE PLATE ASSY	29000001	29000001	E RETAINER
201	12010037	ANTI-RE PAWL	0910468	0910468	BALL BEARING
202	12020019	RATCH	0910321	0910321	BALL BEARING
207	12070094	HOLDED PLATE	0910145	0910145	BALL BEARING
211	12110016	ANTI-RE PAWL PIN	0910153	0910153	BALL BEARING
215	12150013	HOLD PLATE BUSHING	0910229	0910229	BALL BEARING
216	12160009	ANTI-RE PAWL SPRING	0910432	0910432	BALL BEARING
300	13001024	VICE SIDE PLATE	0920370	0920370	WASHER
302	13020015	WASHER	0920435	0920435	WASHER
302-3	13020030	WASHER	0920114	0920114	WASHER
303	13030074	CLICK BUTTON	0920326	0920326	WASHER
304	13040023	CLICK PAWL	0920448	0920448	WASHER
305	13050009	CLICK PAWL SPRING	0920485	0920485	WASHER
400	14000950	SPOOL ASSY.	0920067	0920067	WASHER
401-2	14010030	CLICK GEAR	0920133	0920133	WASHER
500	15000343	HANDLE ARM ASSY.	0920488	0920488	WASHER
515	15150002	HANDLE SCREW	0920495	0920495	WASHER
600	16000151	CAST CONTROL CAP	0920282	0920282	WASHER
609	16090009	DRAG SPRING WASHER	09301182	09301182	SCREW
610	16100068	DRAG WASHER	09301183	09301183	SCREW
612	16120073	KEY WASHER	0930194	0930194	SCREW
612-1	16120035	KEY WASHER	0930196	0930196	SCREW
614	16140003	DRAG WASHER	0930988	0930988	SCREW
615	16150191	STAR DARG ASSY	0930202	0930202	SCREW
700	17000349	DRIVE GEAR	0930501	0930501	SCREW
701	17010151	DRIVE GEAR SHAFT ASSY.	0930663	0930663	SCREW
702	17020397	PINION GEAR	0930164	0930164	SCREW
720	17200006	DRIVE GEAR SHAFT BUSHING	0930525	0930525	SCREW
720-1	17200005	DRIVE GEAR SHAFT BUSHING	0940032	0940032	O RING