



CATALINA CT - 15D SPARE PARTS LIST

KEY NO.	PARTS NAMES	PARTS NO.	KEY NO.	PARTS NAMES	PARTS NO.
100	MAIN BODY ASSY.	11100048-04003A	703	LEVEL WIND GUARD	11703011-03001
102	BODY FOOT	11102005-06005	704	STABILIZER BAR	11704015-03001
105	WORM SHAFT BUSHING	11105003-01	705	WORM SHAFT GEAR	11705006-06
105-1	WORM SHAFT BUSHING	11105004-01	706	IDLE GEAR	11706002-06
117	HANDLE NUT	11117005-03001	707	MEDIUM TRANSMISSION GEAR	11707008-11
200	RIGHT SIDE PLATE	11200055-A001C	708	TRANSMISSION GEAR	11708003-11
201	ANTI-REVERSE PAWL	11201008-06	709	TRANSMISSION GEAR BUSHING	11709002-03
207	HOLD PLATE	11207017-03001	710	LINE GUIDE ASSY.	1171001206917
211	ANTI-REVERSE PAWL PIN	11211003-03001	712	WORM SHAFT	11712021-03001
212	COUNTER COVER ASSY	1121200101	713	PAWL CAP	11713001-03907
215	HOLD PLATE	11215011-03001	715	LINE GUIDE PAWL	11715003-06
216	ANTI-REVERSE PAWL SPRING	11216001-06	720	DRIVE GEAR BUSHING	11720002-06001
216-1	CLUTCH CAM SLIDER SPRING	11216002-06	800	CLUTCH CAM	11800002-02002
219	RIGHT SIDE PLATE BUSHING	11219011-03	801	CLUTCH CAM SPRING	11801001-06
219-1	CLUTCH BEARING BUSHING	11219017-03001	802	CLUTCH BAR	11802005-01
221	O RING	11221001-07	804	CLUTCH CAM SLIDER (AUTO TIP)	11804005-06
224	ONE WAY CLUTCH BEARING CAP	11224001-02905	805	PINION GEAR YOKE	11805002-01
300	LEFT SIDE PLATE	11300030-A001	806	YOKE SPRING	11806001-06
302	SPACER	11302002-06001	910	DEPTH COUNTER ASSY.	1191000101003
302-2	LEFT SIDE PLATE BUSHING	11302008-03	9101	BALL BEARING	01030625-61
302-3	SPACER	11302006-03	9103	ONE WAY BEARING	01101612-6
303	CLICK BUTTON	11303010-03907	9106	BALL BEARING	01041104-61
304	CLICK PAWL	11304003-06	9107	BALL BEARING	01061335-61
305	CLICK PAWL SPRING	11305001-01001	9202	LEVEL WIND GUARD WASHER	025.1x10.5x.2-6
311	SIDE PLATE COVERS	11311001-06001	9204	HANDLE NUT SCREW	025.9x10x0.2-6
400	ALUMINUM SPOOL ASSY.	11400042-04005	9205	DRIVE GEAR WASHER	028.2x22x1-9
401	CLICK GEAR	11401001-05002	9206	CLICK BUTTON WASHER	024.05x10x0.2-8
418	SPOOL BALL BEARING RETAINER	11418001-01001	9301	RIGHT SIDE PLATE SCREW	03422.6x13-61
500	BALANCE WEIGHT HANDLE ASSY.	11500013061A	9302	CLICK PAWL SCREW	03327.52.6x6-61
500-1	HANDLE ASSY.	1150000504907	9302-1	HOLD PLATE SCREW	03327.52.67.561
516	HANDLE NUT HOLDER	11516001-01	9307	HANDLE NUT HOLDER SCREW	03412.6x4-61
600	CAST CONTROL CAP	11600014-03001	9311	LEFT SIDE PLATE SCREW	03212.6x11-61
608	BALL BEARING RETAINER DRAG	11608004-06	9310	BODY FOOT SCREW	03213x6-61002
609	DRAG SPRING WASHER	14609001-05907	9312	TRANSMISSION GEAR SCREW	03325.2x2x4.561
610	DRAG WASHER	11610004-006A	9314	CLICK GEAR SCREW(ALUMINUM SPOOL USED)	03212.0x5.0-61
610-1	DRAG WASHER	11610013-006	9316	CLUTCH BAR SCREW	03414x5-61
611	EARED WASHER	11611005-06	9319	CLUTCH CAM SCREW	03312x5-61
612	KEY WASHER	11612007-06	9320	COUNTER COVER SCREW	03122.0x26-61
612-1	KEY WASHER	11612007-06003	9320-1	COUNTER COVER SCREW	03122x8-62
614	TENSION WASHER	11614001-06	9323	ONE WAY CLUTCH BEARING CAP SCREW	03222.6x4.5-61
615	STAR DRAG	14615002-04002C	9326	SPOOL CLUTCH BEARING CAP SCREW	03312.6x6-61
617	DRAG GEAR SHAFT RETAINER	11617007-03	9401	DRIVE GEAR SHAFT "E" RETAINER	11900001-06
700	DRIVE GEAR	11700008-03006	9404-1	WORM SHAFT "E" RETAINER	11900002-06
701	DRIVE GEAR SHAFT ASSY.(AUTO TIP)	1170102803001A	9406	SPOOL CLUTCH BEARING "C" RETAINER	12900006-06001
702	PINION GEAR ASSY.	1170201103002			