



**EB 65 SPARE PARTS LIST**

KEY NO.	PARTS NAMES	PARTS NO.	KEY NO.	PARTS NAMES	PARTS NO.
100	MAIN BODY	1210010101614A	708	OSCILLATION SLIDER	12708044-02
111	BODY AND SIDE PLATE WATER SEALED	12111001-07	709	"C" RETAINER	12709003-06
200	SIDE PLATE	1220008001614	718	MAIN SHAFT	12718116-06001
300	ROTOR	12300093-01613	719	CLICK GEAR	12719004-06
301	BAIL ARM	12301025-01614	722	CLICK GEAR WASHER	12722013-01
304	BAIL ARM COVER	12304042-01614	725	TRANSMISSION GEAR BUSHING	12725017-03
305	KICK LEVEL	12305050-05	726	CLUTCH LEVER SHAFT	12726001-02002
307	BAIL HOLDER	12307022-126141	727	CLUTCH LEVER	12727001-0170
309	BAIL ARM YOKE	12309010-012	728	CLUTCH LEVER SHAFT SPRING	12728001-16
309-1	BAIL ARM SUPPORT PIN	12309013-06	729	CLUTCH KICK LEVER	12729001-06
310	COMPRESSION SPRING	12310012-06	730	CLUTCH PLATE	12730001-06001
313	BAIL ASSEMBLY	1231308006002F	731	CLUTCH PLATE SPRING	12731001-06
315	LINE ROLLER	12315021-03917	732	CLUTCH LEVER BUSHING	12732001-03907
318	ROTOR NUT	12318012-03	800	ANTI-REVERSE LEVER	12800029-0170
400	NORMAL SPOOL ASSY	1240006104017	800-1	ANTI-REVERSE LEVER	12800043-01
400-1	SPARE SPOOL ASSY	1240015204001B	801	ANTI-REVERSE LEVER SPRING	12801021-06
407	CLUTCH KICK LEVER SPRING	12407010-06	903	SPRING WASHER	12903002-06
413	WATER PROOF SLEEVE	12413003-07	9101	ONE WAY BALL BEARING	01104416
416	SPOOL HOLD PLATE	12416003-06001	9102	BALL BEARING	01102006-61
500	HANDLE ASSEMBLY	12500051049071	9103	BALL BEARING	01091705-61
504	HANDLE SCREW CAP WASHER	12504005-01	9104	BALL BEARING	01050825-61
513	HANDLE SCREW CAP	12513018-0A913	9202	DRIVE GEAR WASHER	029.1x13x0.3-6
600	DRAG KNOB	1260005601613	9203	LINE ROLLER WASHER	023.5x12.1x.5-6
600-1	DRAG KNOB	12600050-01	9205	DRAG WASHER	028x15x1-11
602	DRAG KNOB SPRING	126020007-05907	9206	CLICK GEAR WASHER	0210x14.5x1-11
607	DRAG KNOB HOLDER	12607029-03907	9301	SIDE PLATE SCREW	03123x13-61
609	CLICK GEAR	12609008-02907	9302	TRANSMISSION BUSHING SCREW	03222.6x9.5-61
610	DRAG WASHER	12610010-000	9304	BAIL ARM SCREW	03413.5x9-61
611	EARED WASHER	12611008-06001	9305	ONE WAY BALL BEARING SCREW	03327.52.6x6-61
611-1	EARED WASHER	12611009-05907	9306	ROTOR COVER SCREW	03422.6x8-61
612	KEY WASHER	12612029-06001	9308	BAIL ARM AND HOLDER SCREW	03424x10-61
612-1	KEY WASHER	12612029-06002	9309	ROTOR NUT SCREW	03426.92.66.561
616	DRAG KNOB RUBBER RING	12616006-0770	9310	SPOOL RIM SCREW	03212x5-61
619	MICRO DRAG KNOB RETAINER	12619003-05907	9313	ANTI-REVERSE/ANTI-RE LEVER SCR	03222x4.5-61
700	DRIVE GEAR ASSEMBLY	12700028-121	9316	ONE WAY BALL BEARING SCREW	03422.6x17-61
702	PINION GEAR	12702007-132	9317	CLUTCH LEVER SCREW	03413x10-61
705	TRANSMISSION GEAR	12705027-12	9319	CLUTCH KICK LEVER SCREW	03312x5-61