



MIKE'S REEL REPAIR
 #108 - 31060 Peardorville Road
 Abbotsford, B.C., Canada V2T 6K5
 Toll Free 1-888-404-1119

EF-65/80

SIZE	65	80		SIZE	65	80	
KEY NO.	PARTS NO.	PARTS NO.	PARTS NAMES	KEY NO.	PARTS NO.	PARTS NO.	PARTS NAMES
100	1210013201614	1210013201614	MAIN BODY	702	12702007-132	12702007-132	PINION GEAR
106	12106029-0A914	12106029-0A914	DRAG KNOB SEAT	705	12705027-12	12705027-12	TRANSMISSION GEAR
108	12108030-0A915	12108030-0A915	BODY AND SIDE PLATE WATER SEALED	708	12708033-02	12708033-02	OSCILLATION SLIDER
111	12111004-07	12111004-07	BODY AND SIDE PLATE WATER AEAL	718	12718078-06002	12718078-06002	MAIN SHAFT
200	12200114-01614	12200114-01614	SIDE PLATE	719	12719004-06	12719004-06	CLICK GEAR
300	12300093-01613	12300094-01613	ROTOR	722	12722013-01	12722013-01	CLICK GEAR WASHER
301	12301025-01614	12301025-01614	BAIL ARM	725	12725017-03	12725017-03	OSCILLATING GEAR BUSHING
304	12304042-01614	12304043-01614	BAIL ARM COVER	800	12800056-01002	12800056-01002	ANTI-REVERSE LEVER
305	12305050-05	12305051-05	KICK LEVEL	801	12801006-060	12801006-060	ANTI-REVERSE LEVER SPRING
307	12307022-12614	12307022-12614	BAIL HOLDER	903	12903002-06	12903002-06	SPRING WASHER
309	12309010-012	12309010-012	BAIL ARM YOKE	9101	01104416	01104416	ONE WAY BALL BEARING
309-1	12309013-06	12309013-06	BAIL ARM SUPPORT PIN	9102	01102006-61	01102006-61	BALL BEARING
310	12310012-06	12310012-06	COMPRESSION SPRING	9103	01091705-61	01091705-61	BALL BEARING
313	1231308006002F	1231308106002F	BAIL ASSEMBLY	9104	01050825-61	01050825-61	BALL BEARING
315	12315021-03917	12315017-00	LINE ROLLER	9202	029.1x13x0.5-6	029.1x13x0.5-6	PINION GEAR WASHER
318	12318012-03	12318012-03	ROTOR NUT	9202-1	029.1x13x0.3-6	029.1x13x0.3-6	DRIVE GEAR WASHER
400	1240006104017	1240006304016	NORMAL SPOOL ASSY	9203	023.5x12.1x.5-6	023.5x12.1x.5-6	LINE ROLLER WASHER
400	1240015204001B	1240016204001B	SPARE SPOOL ASSY	9301	03123X13-61	03123X13-61	SIDE PLATE SCREW
413	12413001-07	12413001-07	WATER PROOF SLEEVE	9301-1	03123x21-61	03123x21-61	SIDE PLATE SCREW
416	12416003-06001	12416003-06001	SPOOL HOLD PLATE	9302	03222.6x6-61	03222.6x6-61	TRANSMISSION GEAR
500	1250002824614A	1250002824614A	HANDLE ASSEMBLY	9303	03212.6x6-61	03212.6x6-61	OSCILLATION SLIDER SCREW
504	12504005-01	12504005-01	HANDLE SCREW CAP WASHER	9304	03413.5x9-61	03413.5x9-61	LINE ROTOR SCREW
513	12513021-04914	12513021-04914	HANDLE SCREW CAP	9305	03327.52.6x6-61	03327.52.6x6-61	BALL BEARING SCREW
600	1260005601613	1260005601613	DRAG KNOB ASSEMBLY	9306	03422.6x8-61	03422.6x8-61	BAIL ARM COVER SCREW
610	12610010-000	12610010-000	DRAG WASHER	9308	03424x10-61	03424x10-61	BAIL ARM/AIL HOLDER SCREW
611	12611008-06001	12611008-06001	EARED WASHER	9309	03426.92.66.561	03426.92.66.561	ROTOR NUT SCREW
612	12612029-06001	12612029-06001	KEY WASHER	9310	03212x5-61	03212x5-61	SPOOL RIM SCREW
612-1	12612029-06002	12612029-06002	KEY WASHER	9316	03422.6x17-61	03422.6x17-61	ONE WAY BALL BEARING SCREW
700	12700024-121	12700024-121	DRIVE GEAR ASSEMBLY				