



HALOGEN HG - 250 SPARE PARTS LIST

KEY NO.	PARTS NO.	PARTS NAMES	KEY NO.	PARTS NO.	PARTS NAMES
100	1410000204901	MAIN BODY ASSY	705	14705001-06	WORM SHAFT GEAR
105	14105001-0114	WORM SHAFT BUSHING	706	14706001-0114	IDLE GEAR
117	14117001-03	HANDLE NUT	707	14707001-0114	MEDIUM TRANSMISSION GEAR
200	1420000104953	RIGHT SIDE PLATE ASSY	709	14709001-03	TRANSMISSION GEAR BUSHING
202	14202001-06	ANTI-REVERSE RATCHET	711	147110010170	LINE GUIDE ASSEMBLY
206	14206001-01001	BRAKE COLLARS(6 PIECES)	712	14712002-03001	WORM SHAFT
210	14210001-03	MAIN SHIFT BUSHING	713	14713001-0170	PAWL CAP
220	14220001-03914	RIGHT DIDE PLATE BOLTS	715	11715003-06	LINE GUIDE PAWL
221	14221001-07	RIGHT SIDE PLATE BOLTS ORING	720	11720002-06001	ONE WAY CLUTCH INNER RING
222	14222001-01001	RIGHT SIDE SET PLATE	800	14800001-06	CLUTCH BAR SHAFT
300	14300001-04953	LEFT SIDE PLATE ASSY	801	14801001-06	CLUTCH PAWL SPRING
302	14302001-03	MAIN SHAFT LEFT DIDE SPACER	802	14802002-0170	CLUTCH BAR
400	14400002-04953	SPOOL	803	14803002-06	CLUTCH BAR SUPPORT
500	1450000204005	DOUBLE HANDE ASSY	804	14804001-06	CLUTCH PAWL
513	14513001-06	HANDLE COVER	805	14805001-0114	PINNON GEAR YOKE
516	145160010A913	HANDE NUT HOLDER	806	14806001-06	YOKE SPRING
600	14600001-04907	CAST CONTROL CAP	807	14807001-0114	CLUTCH CAM
601	14601001-16	COMPRESSION SPRING	808	14808001-06001	CLUTCH CAM SPRING
603	14603001-01	RIGHT DIDE BUSHING O RING	809	14809001-0170	CLUTCH BAR SPACER
604	14604001-0170	CONTROL CLICK	810	14810001-01001	CLUTCH BAR GUIDE
608	14608001-06	BEARING RETAINER	812	14812001-06	CLUTCH CAM PLATE
609	14609003-06001	DRAG SPRING WASHER	9101	01051003-61	BALL BEARING
609-1	14609004-05907	DRAG SPRING WASHER	9103	01101612-5	ONE WAY CLUTCH BEARING
610	11610004-006A	DRAG WASHER	9106	01031004-61	BALL BEARING(A)
610-1	11610003-006	DRAG WASHER	9201	025.1x10.5x.2-6	WASHER
611	11611005-061	EARED WASHER	9203	023x5x0.2-1	RIGHT SIDE PLATE BOLTS SPACER
612	11612007-061	KER WASHER	9204	025.9x12x0.2-6	WASHER
612-1	11612007-06003	KER WASHER	9205	0210x20x1-8	DRIVE GEAR WASHER
614	11614001-06	FRICTION WASHER	9206	023.5x6x0.5-3	CLUTCH BAR SHAFT SPACER
615	14615003-04002C	STAR DRAG	9207	025x6.5x0.2-3	WASHER
618	14618001-07	RUBBER SPACER	9302	03412.3x10.5-61	RIGHT SIDE SET PLATE SCREW
619	14619001-03	MAIN SHAFT RIGHT SIDE SPACER	9303	03212.6x6-61	LEFT SIDE PLATE SCREW
700	14700002-032	DRIVE GEAR	9306	03122x5-61	CLUTCH BAR GUIDE SCREW
701	14701002-03	DRIVE GEAR SHAFT	9402	12900002-06	DRIVE GEAR SHAFT "E"RETAINER
702	14702001-03002	PINION GEAR ASSY.	9403	14900001-06	MEDIUM TRANSMISSION GEAR"E" RETAINER
703	14703002-06001	LEVEL WIND GUARD	9404	12900001-06	WORM SHAFT AND CLUTCH "E" RETAINER
704	14704002-06	LEVEL WIND GUARD			