



Hx-25 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003990	MAIN BODY	612-3	26120032	KEY WASHER
105	21050012	PINION BEARING FIXED BUSHING	700	27002022	DRIVE GEAR
105-1	21050038	PINION BEARING FIXED PLATE	702	27020341	PINION GEAR
108	21081450	CAP	705	27050158	TRANSMISSION GEAR
200	22004321	SIDE PLATE	708	27080134	OSCILLATING SLIDER
201	22010417	MIAN BODY DECORATION	716	27160008	OSCILLATION SLIDER PLATE
201-1	22010418	SIDE PLATE DECORATION	718	27180746	MAIN SHAFT
201-2	22010443	MAIN BODY DECORATION	719	27190025	CLICK GEAR
201-3	22010444	SIDE PLATE DECORATION	722	27220009	CLICK GEAR WASHER
300	23004855	ROTOR	725	27250023	TRANSMISSION GEAR
301	23011924	BAIL ARM	800-1	28000324	ANTI-REVERSE/ANTI-RE LEVER
304	23042611	BAIL ARM COVER	800	28000332	ANTI-REVERSE/ANTI-RE LEVER
305	23050141	KICK LEVER	801	28010024	ANTI-RE LEVER SPRING
307	23071529	BAIL HOLDER	0910221	0910221	BALL BEARING
309	23090002	BAIL ARM SLIDER	0910256	0910256	BALL BEARING
310	23100002	COMPRESSION SPRING	0910278	0910278	BALL BEARING
313	23131571	BAIL WIRE ASSY.	0910379	0910379	BALL BEARING
315	23150029	LINE ROLLER	0910496	0910496	BALL BEARING
317	23170013	LINE ROLLERWASHER	0920154	0920154	WASHER
317-1	23170014	LINE ROLLERWASHER	0920319	0920319	WASHER
318	23180005	ROTOR NUT	0920376	0920376	WASHER
400	240013790	SPOOL ASSY.	0930059	0930059	SCREW
405	24050042	DRAG WASHER RETAINER	09301215	09301215	SCREW
407	24070006	EXTENSION SPRING	09301278	09301278	SCREW
412-1	24120021	SPOOL BUSHING	0930209	0930209	SCREW
413	24130009	WATERPROOF RETAINER	0930307	0930307	SCREW
500	25005654	HANDLE ASSY.	0930438	0930438	SCREW
504	25040004	HANDLE SCREW CAP WASHER	0930471	0930471	SCREW
513	25130826	HANDLE CAP ASSY.	0930541	0930541	SCREW
600	26003005	DRAG KNOB ASSY.	0930597	0930597	SCREW
610	26100109	DRAG WASHER	0930663	0930663	SCREW
611	26110005	EARED WASHER	0930839	0930839	SCREW
612	26120007	KEY WASHER			