



INDURON ID - 400 SPARE PARTS LIST

KEY NO.	PARTS NO.	PARTS NAMES	KEY NO.	PARTS NO.	PARTS NAMES
100	1410000304949	MAIN BODY	703	14703003-06001	WORM SHAFT GUARD
105	14105001-0114	WORM SHAFT BUSHING	704	14704003-16	LINE GUIDE SUPPORT BAR
117	14117001-03	CLICK BUTTON RETAINER NUT	705	14705002-06	TRANSMISSION GEAR
200	1420000104950	MAIN SIDE PLATE	708	14708001-0114	TRANSMISSION GEAR
202	14202001-06	RATCHET	709	14709002-03	TRANSMISSION GEAR BUSHING
203	14203001-01	CONTROL PIN	711	147110010170	GUIDE SLIDE BASE
206	14206003-01001	LEVER DRAG STOPPER CAP	712	14712003-03001	WORM SHAFT
216	14216001-062	ANTI-RE PAWL SPRING	713	14713001-0170	LINE GUIDE PAWL CAP
220	14220001-03907	MIAN SIDE PLATE HOLD SCREW	715	11715003-06001	LINE GUIDE PAWL
221	14221001-07	"O"RING	715	11715003-06001C	LINE GUIDE PAWL
222	14222001-01001	MAIN SIDE PLATE HOLDER	720	14720001-06001	DRIVE GEAR BUSHING
300	14300001-04950	VICE SIDE PLATE	800	14800001-06	CLUTCH SHAFT
302	14302001-03	BUSHING	801	14801001-06	CLUTCH SPRING
303	14303001-0170	CLICK BUTTON	802	14802003-0170	CLUTCH BAR
304	11304009-06001	CLICK PAWL	803	14803003-06	CLUTCH BAR SUPPORT
304-1	14304001-06	CLICK PAWL	804	14804001-06	CLUTCH SLIDER
305	14305001-06	CLICK PAWL SPRING	805	14805001-0114	PINION GEAR YOKE
306	14306001-03	CLICK PAWL SPRING PIN	806	14806001-06	YOKE SPRING
308	14308001-06	CLICK BUTTON RETAINER	807	14807001-0114	YOKE BRAKED PLATE
309	14309001-03907	CLICK PIN	808	14808001-06001	YOKE BRAKED PLATE SPRING
400	1440000304907	SPOOL ASSY.	809	14809001-0170	CLUTCH BAR WASHER
401	C4401001-0114	CLICK GEAR	810	14810001-01	CLUTCH SHAFT BUSHING
500	1450000204005	HANDLE ASSY.	812	14812001-06	BRAKED PLATE HOLDER
516	14516001-0A913	HANDLE NUT RETAINER	9101	01051003-61	BALL BEARING
600	14600001-04907	CAST CONTROL CAP	9103	01101612-62	ONE WAY BEARING
601	14601001-16	COMPRESSION SPRING	9104	01050825-61	BALL BEARING
603	14603001-01	O RING	9106	01031004-611	BALL BEARING
604	14604003-01001	DRAG CLICK	9107	01051104-611	SPOOL BALL BEARING
604-1	11604002-01001	DRAG CLICK	9202	025x6.5x0.2-3	LINE GUIDE PAWL WASHER
608	14608001-06	DRAG WASHER RETAINER	9203	023x5x0.2-1	PRESSURE LOAD BLOCK WASHER
609	14609003-05907	DRAG SPRING WASHER	9204	025.9x12x0.2-6	HANDEL NUT WASHER
609-1	14609004-05907	DRAG SPRING WASHER	9205	0210x20x1-8	RATCHET WASHER
610	11610004-006A	DRAG WASHER	9206	023.5x6x0.5-3	CLICK BUTTON WASHER
610-1	11610003-006	DRAG WASHER	9207	022x4.9x0.2-3	WASHER
611	11611005-061	EARED WASHER	9302	03412.3x10.5-617	HOLD PLATE SCREW
612	11612007-06002	KEY WASHER	9303	03212.6x6-61	ANTI-RE PAWL SCREW
612-1	14612001-06001	KEY WASHER	9305	03412.6x4-61	LEVER DRAG STOPPER CAP SCREW
615	11615010-04002C	STAR DARG KNOB	9306	03122x5-61	DECORATION PLATE SCREW
618	14618001-07	SPACER	9312	03412.6x9-617	TRANSMISSION GEAR SCREW
619	14619001-03	WASHER	9402	12900002-06	E RETAINER FOR MAIN SHAFT
700	14700002-032	DRIVE GEAR	9403	14900001-06	E RETAINER FORTRANSMISSION PIN
701	14701002-03002	DRIVE GEAR SHAFT	9404	12900001-06	E RETAINER FOR WORM SHAFT
702	1470200103002	PINION GEAR	9504	11901001-06	C RETAINER FOR GEAR