



**IDX - 400 SPARE PARTS LIST**

KEY	PARTS NO	PARTS NAME	LOT	KEY	PARTS NO	PARTS NAME	LOT
100	1410000704004A	MAIN BODY		702	1470200103002	PINION GEAR	
105	14105001-0114	WORM SHAFT BUSHING		703	14703003-03001	WORM SHAFT GUARD	
117	11117005-03001	RETAINER NUT		704	14704003-16	LINE GUIDE SUPPORT BAR	
200	1420000104912	MAIN SIDE PLATE		705	14705002-06	TRANSMISSION GEAR	
202	14202001-06	RATCH		708	14708001-0114	TRANSMISSION GEAR	
206	14206002-01002	STOPPER CAP		709	14709002-03	TRANSMISSION GEAR BUSHING	
216	14216001-062	ANTI-RE PAWL SPRING		711	1471100111003	GUIDE SLIDE BASE	
220	14220001-03907	MIAN SIDE PLATE HOLD SCREW		712	14712003-03001	WORM SHAFT	
221	14221001-07	"O"RING		713	14713001-0170	LINE GUIDE PAWL CAP	
222	14222001-01001	MAIN SIDE PLATE HOLDER		715	11715003-06001C	LINE GUIDE PAWL	
300	14300001-04912	VICE SIDE PLATE		720	14720001-06001	DRIVE GEAR SHAFT BUSHING	
302	14302001-03	BUSHING		800	14800001-06	CLUTCH SHAFT	
303	14303001-0170	CLICK BUTTON		801	14801001-06001	CLUTCH SPRING	
304	14304001-06	CLICK PAWL		803	14803003-06	CLUTCH BAR SUPPORT	
304-1	14304006-03001	CLICK PAWL		804	14804001-06	CLUTCH SLIDER	
305	14305001-06	CLICK PAWL SPRING		805	14805001-0114	PINION GEAR YOKE	
306	14306001-03	CLICK PAWL SPRING PIN		806	14806001-06	YOKE SPRING	
308	14308001-06	CLICK BUTTON RETAINER		807	14807001-0114	YOKE BRAKED PLATE	
309	14309001-03907	CLICK PIN		808	14808001-06001	YOKE BRAKED PLATE SPRING	
400	1440000304907D	SPOOL ASSY.		809	14809001-0170	CLUTCH BAR WASHER	
401	14401001-0114	SPOOL CLICK GEAR		810	14810001-01001	CLUTCH SHAFT BUSHING	
500	1450000404003	HANDLE ASSY.		812	14812001-06	BRAKED PLATE HOLDER	
516	14516002-0A001	HANDLE NUT RETAINER		813	14813004-07004	CLUTCH BAR CAP	
600	14600001-04907	CAST CONTROL CAP		9101	01051003-61	BALL BEARING	
601	14601002-06001	COMPRESSION SPRING		9103	01101612-62	ONE WAY BEARING	
603	14603001-01	O RING		9104	01050825-61	BALL BEARING	
604	14604004-06001	DRAG CLICK		9106	01031004-601	BALL BEARING	
608	14608001-06001	DRAG WASHER RETAINER		9201	025.1x10.5x.2-6	WASHER	
609	11609003-06001	DRAG SPRING WASHER		9202	025x6.2x0.2-6	HOLD PLATE WASHER	
610	11610004-006A	DRAG WASHER		9203	023x5x0.2-1	PRESSURE LOAD BLOCK WASHER	
610-1	11610003-006	DRAG WASHER		9204	028x10.5x0.5-6	HANDEL NUT WASHER	
611	11611005-061	EARED WASHER		9205	0210x20x1-8	RATCHET WASHER	
612	11612007-06002	KEY WASHER		9206	023.5x6x0.5-3	CLICK BUTTON WASHER	
612-1	14612001-06001	KEY WASHER		9207	022x4.9x0.2-3	LINE GUIDE PAWL WASHER	
615	1461500701	STAR DARG WRENCH		9302	03412.3x10.5-617	HOLD PLATE SCREW	
616	1461600601	STAR DARG BUSHING		9303	03212.6x6-61	ANTI-RE PAWL SCREW	
617	14617001-03001	DRIVE GEAR SHAFT BUSHING		9305	03412.6x4-61	STOPPER CAP SCREW	
618	14618001-07	SPACER		9306	03122x5-61	DECORATION PLATE SCREW	
619	14619001-1	WASHER		9312	03412.6x9-617	TRANSMISSION GEAR SCREW	
623	14623001-04001	STAR DRAG UNDER CAP		9402	12900002-06	E RETAINER FOR MAIN SHAFT	
700	14700002-032	DRIVE GEAR		9403	14900001-06	E RETAINER	
701	1470100902	DRIVE GEAR SHAFT		9404	12900001-06	E RETAINER	