



IS-15 SPARE PARTS LIST

KEYNO	PARTNAME	PARTSNO	KEYNO	PARTNAME	PARTSNO
100	MAIN BODY	121001200A102	612	KEY WASHER	12612004-06
105	PINION BEARING FIX PLATE	12105013-06	612	KEY WASHER	12612004-06
105	PINION BEARING FIX PLATE	12105013-06	702	PINION GEAR	12702084-03002
105-1	PINION BEARING FIX BUSHING	12105012-03	702	PINION GEAR	12702084-03002
105-1	PINION BEARING FIX BUSHING	12105012-03	705	OSCILLATING GEAR	12705004-120
106	DRAG KNOB SEAT	12106024-0A915	705	OSCILLATING GEAR	12705004-120
106	DRAG KNOB SEAT	12106024-0A915	708	OSCILLATING SLIDER	12708007-021
108	BODY/SIDE PLATE COVER	12108025-01726	708	OSCILLATING SLIDER	12708007-021
108	BODY/SIDE PLATE COVER	12108025-01726	718	MAIN SHAFT	12718137-06
200	SIDE PLATE	12200108-0A102	718	MAIN SHAFT	12718137-06
200	SIDE PLATE	12200108-0A102	719	CLICK GEAR	12719005-06
300	ROTOR	12300134-01726	719	CLICK GEAR	12719005-06
300	ROTOR	12300134-01726	722	CLICK GEAR WASHER	12722014-011
301	BAIL ARM	12301033-01726	722	CLICK GEAR WASHER	12722014-011
301	BAIL ARM	12301033-01726	800	ANTI-REVERSE/ANTI-REVERSE LEVE	12800049-0170
304	BAIL ARM COVER	12304059-0A915	800	ANTI-REVERSE/ANTI-REVERSE LEVE	12800049-0170
304	BAIL ARM COVER	12304059-0A915	801	ANTI-REVERSE LEVER SPRING	12801013-06
305	KICK LEVEL	12305059-05	801	ANTI-REVERSE LEVER SPRING	12801013-06
305	KICK LEVEL	12305059-05	9101	ONE WAY BEARING	010717-572
307	BAIL HOLDER	12307028-02915	9101	ONE WAY BEARING	010717-572
307	BAIL HOLDER	12307028-02915	9102	PINION GEAR BALL BEARING	01071103-61
308	BAIL ARM BUSHING	12308007-03907	9102	PINION GEAR BALL BEARING	01071103-61
308	BAIL ARM BUSHING	12308007-03907	9103	SIDE PLATE /MAIN BODY BALL BEA	01081404-61
309	BAIL ARM YOKE	12309001-01	9103	SIDE PLATE /MAIN BODY BALL BEA	01081404-61
309	BAIL ARM YOKE	12309001-01	9103-1	MAIN BODY BALL BEARING	01071303-61
310	COMPRESSION SPRING	12310001-162	9103-1	MAIN BODY BALL BEARING	01071303-61
310	COMPRESSION SPRING	12310001-162	9104	LINE ROTOR BALL BEARING	01050825-61
313	BAIL	1231307006002	9104	LINE ROTOR BALL BEARING	01050825-61
315	LINE ROLLER	12315018-00	9107	BALL BEARING DRAG WASHER RETAI	010717-592
315	LINE ROLLER	12315018-00	9107	BALL BEARING DRAG WASHER RETAI	010717-592
318	ROTOR NUT	12318003-03	9202	DRIVE GEAR WASHER	028.1x12x0.2-6
318	ROTOR NUT	12318003-03	9202	DRIVE GEAR WASHER	028.1x12x0.2-6
320	BALANCE WEIGHT	12320087-09	9203	LINE ROLLER WASHER	023.5x12.1x.5-6
320	BALANCE WEIGHT	12320087-09	9203	LINE ROLLER WASHER	023.5x12.1x.5-6
323	BAIL ARM WASHER	12323005-01	9301	SIDE PLATE SCREW	03122.6x10-61
323	BAIL ARM WASHER	12323005-01	9301	SIDE PLATE SCREW	03122.6x10-61
324	BAIL HOLDER WASHER	12324005-01	9301-1	SIDE PLATE SCREW	03122.6x14-61
324	BAIL HOLDER WASHER	12324005-01	9301-1	SIDE PLATE SCREW	03122.6x14-61
325	BAIL ARM/BAIL HOLDER SCREW	12325001-061	9303	OSCILLATING SLIDER SCREW	03212.3x7-611
325	BAIL ARM/BAIL HOLDER SCREW	12325001-061	9303	OSCILLATING SLIDER SCREW	03212.3x7-611
400	ALUMINUM SPOOL ASSY.	1240005304007	9304	LINE ROTOR SCREW	03412.6x7.5-61
407	CLUTCH LEVER SPRING	12407006-162	9304	LINE ROTOR SCREW	03412.6x7.5-61
407	CLUTCH LEVER SPRING	12407006-162	9305	PINION GEAR BEARING SCREW	03422x5.5-61
500	HANDLE	1250007804005	9305	PINION GEAR BEARING SCREW	03422x5.5-61
513	HANDLE SCREW CAP	12513016-04927	9306	BAIL ARM COVER SCREW	03422.6x8-61
513	HANDLE SCREW CAP	12513016-04927	9306	BAIL ARM COVER SCREW	03422.6x8-61
600	DRAG KNOB	1260006201726	9309	ROTOR NUT SCREW	033272.6x4.5-61
610	DRAG WASHER	12610003-000	9309	ROTOR NUT SCREW	033272.6x4.5-61
610	DRAG WASHER	12610003-000	9312	HEXAGON SHAFT SCREW	03418.1x3x12-61
700	DRIVE GEAR	12700019-1214	9312	HEXAGON SHAFT SCREW	03418.1x3x12-61