



MIKE'S REEL REPAIR
 #108 - 31060 Peardonville Road
 Abbotsford, B.C., Canada V2T 6K5
 Toll Free 1-888-404-1119

X-MEANS PAINT OR INJ. COLOR

MA-30D/30DX SPARE PARTS LIST

KEY NO.	PARTS NAMES	PARTS NO.	0BB	2BB	KEY NO.	PARTS NAMES	PARTS NO.	0BB	2BB
100	MAIN BODY ASSY.	11100015011	*	*	705	WORM SHAFT GEAR	11705008-06	*	*
105	WORM SHAFT BUSHING	11105003-01	*	*	706	IDLE GEAR	11706003-06	*	*
117	HANDLE NUT	14117001-03	*	*	707	MEDIUM TRANSMISSION GEAR	11707003-01	*	*
200	RIGHT SIDE PLATE	11200016-01001	*	*	708	TRANSMISSION GEAR	11708003-11	*	*
201	ANTI-REVERSE PAWL	11201001-06	*	*	709	TRANSMISSION GEAR BUSHING	11709002-03	*	*
207	HOLD PLATE	11207011-03001	*	*	710	LINE GUIDE ASSY.	1171000506	*	*
211	ANTI-REVERSE PAWL PIN	11211002-03001	*	*	712	WORM SHAFT	11712014-03	*	*
212	COUNTER COVER ASSY	1121200101X	*	*	713	PAWL CAP	11713001-03907	*	*
215	BALL BEARING HOLD PLATE	11215009-03001	*	*	715	LINE GUIDE PAWL	11715003-06	*	*
216	ANTI-REVERSE PAWL SPRING	11216001-06	*	*	800	CLUTCH CAM	11800002-02002	*	*
221	O RING	11221001-07	*	*	801	CLUTCH CAM SPRING	11801001-06	*	*
300	LEFT SIDE PLATE	11300025-01	*	*	802	CLUTCH BAR	11802006-01	*	*
302	SPACER	11302002-06001	*	*	804	CLUTCH CAM SLIDER	11804001-06	*	*
302-1	SPOOL SHAFT BUSHING	11302005-03	*	*	805	PINION GEAR YOKE	11805001-06	*	*
303	CLICK BUTTON	11303004-03907	*	*	806	YOKE SPRING	11806001-06	*	*
304	CLICK PAWL	11304003-06	*	*	910	DEPTH COUNTER	11910001-01	*	*
305	CLICK PAWL SPRING	11305001-01001	*	*	9102	BALL BEARING	01081605-61	*	*
311	SIDE PLATE COVERS	11311004-06001	*	*	9106	BALL BEARING	01041104-61	*	*
400	GRAPHITE SPOOL	11400010-0112	*	*	9201	DRIVE GEAR SHAFT WASHER	025.1x8x0.2-6	*	*
401	CLICK GEAR	11401001-05002	*	*	9202	LINE GUIDE WASHER	025.1x10.5x.2-6	*	*
500	DOUBLE HANDLE ASSY.	1150000504907	*	*	9204	HANDLE KNOB WASHER	025.9x10x0.2-6	*	*
500	BALANCE WEIGHT HANDLE ASSY.	1150000604907	*	*	9205	DRIVE GEAR WASHER	028.2x22x1-1	*	*
516	HANDLE NUT HOLDER	11516001-01	*	*	9206	CLICK BUTTON WASHER	024.05x10x0.2-8	*	*
600	CAST CONTROL CAP	11600014-03001	*	*	9210	LEVEL WIND GEAR WASHER	025.1x10.5x.5-6	*	*
609	DRAG SPRING WASHER	11609003-05907	*	*	9301	RIGHT SIDE PLATE SCREW	03423.0x13-61	*	*
610	DRAG WASHER	11610004-006A	*	*	9302	HOLD PLATE SCREW	03327.52.6x6-61	*	*
610-1	DRAG WASHER	11610003-006	*	*	9307	HANDLE NUT HOLDER SCREW	03412.6x4-61	*	*
611	EARED WASHER	11611005-06	*	*	9311	LEFT SIDE PLATE SCREW	03223x12-61	*	*
612	KEY WASHER	11612007-06001	*	*	9312	TRANSMISSION GEAR SCREW	03327.52.67.561	*	*
612-1	KEY WASHER	11612007-06003	*	*	9314	CLICK GEAR SCREW (GRAPHITE SOOL USED)	03222x4.5-61	*	*
614	TENSION WASHER	11614001-06	*	*	9316	CLUTCH BAR SCREW	03414x5-61	*	*
615	STAR DRAG	11615005-01001	*	*	9319	CLUTCH CAM SCREW	03312x5-61	*	*
617	DRIVE GEAR SHAFT BUSHING	11617005-03	*	*	9320	COUNTER COVER SCREW	03122.0x26-61	*	*
617	DRIVE GEAR SHAFT BUSHING	11617006-01	*	*	9320-1	COUNTER COVER SCREW	03122x8-62	*	*
700	DRIVE GEAR	11700006-032	*	*	9401	DRIVE GEAR SHAFT "E" RETAINER	11900001-06	*	*
701	DRIVE GEAR SHAFT ASSY. (AUTO TRIP)	1170101603001A	*	*	9404	WORM SHAFT "E" RETAINER	12900001-06	*	*
702	PINION GEAR	11702005-061	*	*	9404-1	TRANSMISSION GEAR "E" RETAINER	11900002-06	*	*
703	LEVEL WIND GUARD	11703007-03907	*	*	9504	ADLE GEAR "C" RETAINER	11901001-06	*	*
704	STABILIZER BAR	11704005-03907	*	*					