



**MIKE'S REEL REPAIR**  
 #108 - 31060 Peardonville Road  
 Abbotsford, B.C., Canada V2T 6K5  
 Toll Free 1-888-404-1119

**MA45D/45DX SPARE PARTS LIST**

X-MEANS PAINT OR INJ. COLOR

KEY NO.	PARTS NAMES	PARTS NO.	0BB	2BB	KEY NO.	PARTS NAMES	PARTS NO.	0BB	2BB
100	MAIN BODY ASSY.	11100016011X	.	.	705	WORM SHAFT GEAR	11705008-06	.	.
105	WORM SHAFT BUSHING	11105003-01	.	.	706	IDLE GEAR	11706003-06	.	.
117	HANDLE NUT	14117001-03	.	.	707	MEDIUM TRANSMISSION GEAR	11707003-01	.	.
200	RIGHT SIDE PLATE	11200040-01X	.	.	708	TRANSMISSION GEAR	11708003-11	.	.
201	ANTI-REVERSE PAWL	11201001-06	.	.	709	TRANSMISSION GEAR BUSHING	11709002-03	.	.
207	HOLD PLATE	11207003-06001	.	.	710	LINE GUIDE ASSY.	1171000606	.	.
211	ANTI-REVERSE PAWL PIN	11211002-03001	.	.	712	WORM SHAFT	11712022-03907	.	.
212	COUNTER COVER ASSY	1121200101X	.	.	713	PAWL CAP	11713001-03907	.	.
215	BALL BEARING HOLD PLATE	11215009-03001	.	.	715	LINE GUIDE PAWL	11715003-06	.	.
216	ANTI-REVERSE PAWL SPRING	11216001-06	.	.	800	CLUTCH CAM	11800002-02002	.	.
221	O RING	11221001-07	.	.	801	CLUTCH CAM SPRING	11801001-06	.	.
300	LEFT SIDE PLATE	11300026-01X	.	.	802	CLUTCH BAR	11802006-01X	.	.
302	SPACER	11302002-06001	.	.	804	CLUTCH CAM SLIDER	11804001-06	.	.
302-1	SPOOL SHAFT BUSHING	11302005-03	.	.	805	PINION GEAR YOKE	11805001-06	.	.
303	CLICK BUTTON	11303004-03907	.	.	806	YOKE SPRING	11806001-06	.	.
304	CLICK PAWL	11304003-06	.	.	910	DEPTH COUNTER	11910002-01	.	.
305	CLICK PAWL SPRING	11305001-01001	.	.	9102	BALL BEARING	01081605-61	.	.
311	SIDE PLATE COVERS	11311005-06001	.	.	9106	BALL BEARING	01041104-61	.	.
400	GRAPHITE SPOOL ASSY.	11400013-0112	.	.	9201	DRIVE GEAR SHAFT WASHER	025.1x8x0.2-6	.	.
401	CLICK GEAR	11401001-05002	.	.	9202	LINE GUIDE WASHER	025.9x10x0.2-6	.	.
500	DOUBLE HANDLE ASSY.	1150000504X	.	.	9204	HANDLE KNOB WASHER	025.9x10x0.2-6	.	.
500	BALANCE WEIGHT HANDLE ASSY.	1150000604X	.	.	9205	DRIVE GEAR WASHER	028.2x22x1-1	.	.
516	HANDLE NUT HOLDER	11516001-01	.	.	9206	CLICK BUTTON WASHER	024.05x10x0.2-8	.	.
600	CAST CONTROL CAP	11600014-03001	.	.	9210	LEVEL WIND GEAR WASHER	025.1x10.5x.5-6	.	.
609	DRAG SPRING WASHER	11609003-05907	.	.	9301	RIGHT SIDE PLATE SCREW	03423.0x13-61	.	.
610	DRAG WASHER	11610004-006A	.	.	9302	HOLD PLATE SCREW	03327.52.6x6-61	.	.
610-1	DRAG WASHER	11610003-006	.	.	9307	HANDLE NUT HOLDER SCREW	03412.6x4-61	.	.
611	EARED WASHER	11611005-06	.	.	9311	LEFT SIDE PLATE SCREW	03223x12-61	.	.
612	KEY WASHER	11612007-06001	.	.	9312	TRANSMISSION GEAR SCREW	03327.52.67.561	.	.
612-1	KEY WASHER	11612007-06003	.	.	9314	CLICK GEAR SCREW (GRAPHITE SOOL USED)	03222x4.5-61	.	.
614	TENSION WASHER	11614001-06	.	.	9316	CLUTCH BAR SCREW	03414x5-61	.	.
615	STAR DRAG	11615005-01001	.	.	9319	CLUTCH CAM SCREW	03312x5-61	.	.
617	DRIVE GEAR SHAFT BUSHING	11617005-03	.	.	9320	COUNTER COVER SCREW	03122.0x26-61	.	.
617	DRIVE GEAR SHAFT BUSHING	11617006-01	.	.	9320-1	COUNTER COVER SCREW	03122x8-62	.	.
700	DRIVE GEAR	11700006-032	.	.	9401	DRIVE GEAR SHAFT "E" RETAINER	11900001-06	.	.
701	DRIVE GEAR SHAFT ASSY. (AUTO TRIP)	1170101603001A	.	.	9404	WORM SHAFT "E" RETAINER	12900001-06	.	.
702	PINION GEAR	11702005-061	.	.	9404-1	TRANSMISSION GEAR "E" RETAINER	11900002-06	.	.
703	LEVEL WIND GUARD	11703006-03907	.	.	9504	IDLE GEAR "C" RETAINER	11901001-06	.	.
704	STABILIZER BAR	11704004-03907	.	.					