



NS - 200 SPARE PARTS LIST

KEY NO.	PARTS NEMAS	PARTS NO.	KEY NO.	PARTS NEMAS	PARTS NO.
100	MAIN BODY	14100018-04002	703	WORM SHAFT GUARD	14703005-01001
105	WORM SHAFT BUSHING	14105002-01002	705	TRANSMISSION GEAR	14705003-01002
117	CLICK BUTTON RETAINER NUT	14117001-03	705-1	TRANSMISSION GEAR	14705004-01002
119	BODY COVERS	14119001-01P19	711	GUIDE SLIDE BASE	1471100201003A
200	MAIN SIDE PLATE ASSY	1420000704003	712	WORM SHAFT	14712004-03001
202	RATCHET	14202002-06001	713	LINE GUIDE PAWL CAP	14713002-03001
206	LEVER DRAG STOPPER CAP	14206002-01002	715	LINE GUIDE PAWL	14715002-06001
207	HOLD PLATE	14207001-01001	720	DRIVE GEAR BUSHING	14720002-06001
220	MIAN SIDE PLATE HOLD SCREW	14220002-06001	725	TRANSMISSION GEAR PIN	14725001-06001
226	CONTROL FIXED PIN	14226001-03001	800	CLUTCH SHAFT	14800002-06001
300	VICE SIDE PLATE	14300003-01726	801	CLUTCH SPRING	14801003-06001
302	BUSHING	14302001-1	804	CLUTCH SLIDER	14804003-06001
306	CLICK PAWL SPRING PIN	14306002-03001	804-1	CLUTCH SLIDER	14804005-02001
313	LEFT SIDE PLATE TIMER	14313001-06001	805	PINION GEAR YOKE	14805003-01002
314	LEFT SIDE PLATE PIN	14314001-06001	806	YOKE SPRING	14806002-06001
315	LEFT SIDE HOLD PLATE	14315001-01003	807	YOKE BRAKED PLATE	14807003-01001
316	HOLD PLATE COVERS	14316002-01003	808	YOKE BRAKED PLATE SPRING	14808003-06001
317	LEFT SIDE PLATE PIN SPRING	14317001-06001	809	CLUTCH BAR WASHER	14809002-01003
318	LEFT SIDECONTROL PIN SPRING	14318001-03001	812	BRAKED PLATE HOLDER	14812003-06001
400	SPOOL	1440000904003	813	CLUTCH BAR CAP	14813001-07003
401	CLICK GEAR	1440100201001	9101	BALL BEARING	01030804-61
500	HANDLE ASSY.	1450000204006A	9102	BALL BEARING	01050903-61
516	HANDLE NUT RETAINER	14516002-0A003	9103	ONE WAY BEARING	01101612-62
600	CAST CONTROL CAP	14600003-04005	9106	BALL BEARING	01031004-601
603	O RING	14603002-07	9108	BALL BEARING	01040725-61
608	DRAG WASHER RETAINER	14608002-06001	9201	HOLD PLATE WASHER	025.1x10.5x.2-6
608-1	DRAG WASHER RETAINER	14608001-06001	9201-1	DRIVE GEAR SHAFT WASHER	028x10x0.5-6
609	DRAG SPRING WASHER	14609003-06001	9207	PRESSURE LOAD BLOCK WASHER	022x4.9x0.2-3
609-1	DRAG SPRING WASHER	14609004-06001	9204	HANDEL NUT WASHER	028x10.5x0.5-6
610	DRAG WASHER	11610004-006A	9205	RATCHET WASHER	028.2x20x1-9
610-1	DRAG WASHER	11610003-006	9301	MAIN SIDE PLATE SCREW	03112x8-61
611	EARED WASHER	11611005-061	9301-1	MAIN SIDE PLATE SCREW	03112.6x10-617
612	KEY WASHER	11612007-06001	9309	HANGER SCREW	03412x4-61
612-1	KEY WASHER	11612007-06004	9314	CLICK GEAR SCREW	03212x8-617
615	STAR DARG KNOB	C4615005-01003	9314-1	SCREW	03212x3.2-61
618	SPACER	14618002-07	9316	CLUTCH PLATE SCREW	03422.6x6.5-61
619	WASHER	14619002-01001	9319	CLICK BUTTON SCREW	03412.6x4-61
700	DRIVE GEAR	14700006-03002	9401	E RETAINER FOR MAIN SHAFT	12900001-06
701	DRIVE GEAR SHAFT	14701005-03001	9407	E RETAINER	11900002-06
702	PINION GEAR	14702008-03002	9407-1	E RETAINER	14900001-06