



RTX-30s PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003990	MIAN BODY	612-3	26120032	KEY WASHER
105	21050012	PINION BEARING FIXED BUSHING	700	27002038	DRIVE GEAR
105-1	21050038	PINION BEARING FIXED PLATE	702	27020469	PINION GEAR
108	21081458	CAP	705	27050158	TRANSMISSION GEAR
200	22004321	SIDE PLATE	708	27080134	OSCILLATING SLIDER
201	22010481	MIAN BODY DECORATION	716	27160008	OSCILLATION SLIDER PLATE
201-1	22010482	SIDE PLATE DECORATION	718	27180746	MAIN SHAFT
201-2	22010483	MIAN BODY DECORATION	719	27190025	CLICK GEAR
201-3	22010484	SIDE PLATE DECORATION	722	27220009	CLICK GEAR WASHER
300	23004855	ROTOR	725	27250023	TRANSMISSION GEAR
301	23011942	BAIL ARM	800-1	28000324	ANTI-REVERSE/ANTI-RE LEVER
304	23042612	BAIL ARM COVER	800	28000332	ANTI-REVERSE/ANTI-RE LEVER
305	23050141	KICK LEVER	801	28010024	ANTI-RE LEVER SPRING
307	23071544	BAIL HOLDER	910041	910041	BALL BEARING
309	23090002	BAIL ARM SLIDER	910093	910093	BALL BEARING
310	23100002	COMPRESSION SPRING	910335	910335	BALL BEARING
313	23131571	BAIL WIRE ASSY.	910373	910373	BALL BEARING
315	23150029	LINE ROLLER	910496	910496	BALL BEARING
317	23170013	LINE ROLLER WASHER	920154	920154	WASHER
317-1	23170014	LINE ROLLER WASHER	920319	920319	WASHER
318	23180005	ROTOR NUT	920376	920376	WASHER
400	240014427	SPOOL ASSY.	930059	930059	SCREW
405	24050042	DRAG WASHER RETAINER	9301215	9301215	SCREW
407	24070006	EXTENSION SPRING	9301278	9301278	SCREW
412-1	24120021	SPOOL BUSHING	930209	930209	SCREW
413	24130009	WATERPROOF RETAINER	930307	930307	SCREW
500	25005485	HANDLE ASSY.	930438	930438	SCREW
504	25040004	HANDLE SCREW CAP WASHER	930471	930471	SCREW
513	25130830	HANDLE CAP	930541	930541	SCREW
600	26003199	DRAG KNOB ASSY.	930597	930597	SCREW
610	26100011	DRAG WASHER	930663	930663	SCREW
611	26110005	EARED WASHER	930839	930839	SCREW
612	26120007	KEY WASHER			