


Ri-400P PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	41004379	MAIN BODY ASSY.	705	47050007	TRANSMISSION GEAR
105	41050002	WORM SHAFT BUSHING	708	47080003	TRANSMISSION GEAR
117	11170020	RETAINER NUT	709	47090006	TRANSMISSION GEAR BUSHING
200	42000314	HANDLE SIDE PLATE ASSY	711	47110012	GUIDE SLIDE BASE ASSY.
202	42020007	RATCH	712	47120005	WORM SHAFT
206	42060003	STOPPER CAP	713	47130003	LINE GUIDE PAWL CAP
216	42160005	ANTI-RE PAWL SPRING	715	17150009	LINE GUIDE PAWL
220	42200007	SIDE PLATE HOLDED SCREW	720	17200005	DRIVE GEAR SHAFT BUSHING
222	42220007	MAIN SIDE PLATE HOLDER	720-1	17200002	DRIVE GEAR SHAFT BUSHING
226	42260001	CONTROL PIN	800	48000002	CLUTCH SHAFT
300	43000236	VICE SIDE PLATE	801	48010002	CLUTCH SHAFT SPRING
302	43020009	WASHER	803	48030006	CLUTCH BAR SUPPORT
303	43030004	CLICK BUTTON	804	48040018	CLUTCH SLIDER ASSY
304	43040004	CLICK PAWL	805	48050002	PINION GEAR YOKE
304-1	43040001	CLICK PAWL	806	48060001	YOKE SPRING
305	43050001	CLICK PAWL SPRING	807	48070002	YOKE BRAKED PLATE
306	43060001	CLICK PAWL SPRING PIN	808	48080002	YOKE BRAKED PLATE SPRING
308	43080001	CLICK BUTTON RETAINER	809	48090003	CLUTCH BAR WASHER
309	43090001	CLICK PIN	810	48100002	CLUTCH SHAFT BUSHING
400	44000738	SPOOL ASSY.	812	48120001	BRAKED PLATE HOLDER
401	44010001	SPOOL CLICK GEAR	813	48130005	CLUTCH BAR CAP
500	45000089	HANDLE ASSY.	29000002	29000002	E RETAINER
515	15150008	HANDLE NUT SCREW	49000001	49000001	E RETAINER
600	46000027	CAST CONTROL CAP	29000001	29000001	E RETAINER
601	46010003	COMPRESSION SPRING	0910325	0910325	BALL BEARING
604	46040006	DRAG CLICK	0910153	0910153	BALL BEARING
608	46080002	DRAG WASHER RETAINER	0910016	0910016	BALL BEARING
609	16090009	DRAG SPRING WASHER	0910392	0910392	BALL BEARING
610	16100055	DRAG WASHER	0910393	0910393	BALL BEARING
610-1	16100037	DRAG WASHER	0920105	0920105	WASHER
610-2	16100038	DRAG WASHER	0920117	0920117	WASHER
611	16110006	EARED WASHER	0920081	0920081	WASHER
612	16120028	KEY WASHER	0920133	0920133	WASHER
612-1	16120027	KEY WASHER	0920527	0920527	WASHER
612-2	26120056	KEY WASHER	0920076	0920076	WASHER
615	46150104	STAR DARG ASSY.	0920066	0920066	WASHER
617	46170001	DRIVE GEAR SHAFT BUSHING	0930684	0930684	SCREW
618	46180001	SPACER	0930075	0930075	SCREW
619	46190002	WASHER	0930226	0930226	SCREW
700	47000005	DRIVE GEAR	0930429	0930429	SCREW
701	47010019	DRIVE GEAR SHAFT	0930700	0930700	SCREW



Ri-400P PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
702	47020065	PINION GEAR	0940020	0940020	O RING
703	47030011	WORM SHAFT GUARD	0940027	0940027	O RING
704	47040011	LINE GUIDE SUPPORT BAR			

109OKA02718081

