



SLR-10L PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001514	MAIN BODY ASSY.	613	16130005	COMPRESSION SPRING
101	11010026	BODY LOAD	700	17000291	PINION GEAR
105	11050006	WORM SHAFT BUSHING	701	17010258	DRIVE GEAR SHAFT
105-1	11050007	WORM SHAFT BUSHING	702	17020239	DRIVE GEAR
114	11140037	CLAMP	703	17030010	WORM SHAFT GUARD
115	11150003	WUNG SCREW	704	17040017	LINE GUIDE SUPPORT BAR
116	11160003	WING NUT	705	17050013	TRANSMISSION GEAR
117	11170002	RETAINER NUT	707	17070004	TRANSMISSION GEAR
200	12000586	MAIN SIDE PLATE	710	17100032	LINE GUIDE ASSY.
201	12010033	ANTI-RE PAWL	712	17120041	WORM SHAFT
203	12030004	CONTROL PIN	713	17130002	LINE GUIDE PAWL CAP
204	12040002	COMPRESSION SPRING	715	17150009	LINE GUIDE PAWL
204-1	12040018	COMPRESSION SPRING	717	17170004	MAIN SHAFT PIN
206	12060010	LEVER DRAG STOPPER CAP	718	17180102	MAIN SHAFT
207	12070071	HOLDED PLATE	723	17230006	SILENT SPRING
208	12080080	SIDE PLATE COVER	913	19130002	SPRING WASHER
215	12150016	HOLD PLATE BUSHING	19000001	19000001	E RETAINER
215-1	12150019	HOLD PLATE BUSHING	29000001	29000001	E RETAINER
215-2	12150020	HOLD PLATE BUSHING	29010001	29010001	CLICK PAWL WASHER
216	12160011	ANTI-RE PAWL SPRING	19010006	19010006	C RETAINER
217	12170012	ANTI-RE PAWL SPRING	0910145	0910145	BALL BEARING
217-1	12170016	ANTI-RE PAWL SPRING	0910344	0910344	BALL BEARING
225	12250001	BUSHING	0910477	0910477	BALL BEARING
226	12260004	CONTROL PIN	0910248	0910248	BALL BEARING
300	13000340	VICE SIDE PLATE	0910463	0910463	BALL BEARING
303	13030051	CLICK BOTTON	0910461	0910461	BALL BEARING
304	13040011	CLICK PAWL	0920282	0920282	WASHER
304-1	13040018	CLICK PAWL	0920510	0920510	WASHER
305	13050009	CLICK PAWL SPRING	0920126	0920126	WASHER
311	13110076	SIDE PLATE COVERS	0920418	0920418	WASHER
319	13190003	MAGNET ASSY.	0920481	0920481	WASHER
320	13200001	MAGNER CONTROL BUTTON	0920066	0920066	WASHER
400	14000846	SPOOL	0920120	0920120	WASHER
401	14010042	CLICK GEAR	0920373	0920373	WASHER
402	14020009	LINE HOLDER	0920121	0920121	WASHER
404	14040007	PRESSURE LOAD BLOCK	0920106	0920106	WASHER
405	14050024	SPOOL COVER	0920207	0920207	WASHER
406	14060006	BUSHING	0920009	0920009	WASHER
500	15000303	HANDLE ASSY.	09301128	09301128	SCREW
501	15010019	HANDLE NUT	0930628	0930628	SCREW
507	15070032	PUSH BUTTON	0930666	0930666	SCREW
509	35090001	E RETAINER	0930211	0930211	SCREW
513	15130023	HANDLE COVER	0930615	0930615	SCREW
516	15160030	HANDLE NUT RETAINER	0930129	0930129	SCREW
600	16000086	CAST CONTROL CAP	0930196	0930196	SCREW
601	16010004	DRAG NUT	0930893	0930893	SCREW
602	16020050	ADJUST BLOCK	0930219	0930219	SCREW
605	16050082	LEVER DRAG	0930044	0930044	SCREW
605-1	16050126	LEVER DRAG	0930651	0930651	SCREW
607	16070047	PINION GUARD	0930885	0930885	SCREW
608	16080004	DRAG WASHER RETAINER	09301095	09301095	SCREW
609	16090013	SPRING WASHER	0940012	0940012	O RING
611	16110048	DRAG WASHER	0940032	0940032	O RING
612	16120059	KEY WASHER			