



SLR-20II PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001560	MAIN BODY ASSY	605	16050108	LEVER DRAG
101	11010028	BODY LOGO	605-1	16050094	LEVER DRAG
102	11020015	BODY FOOT	607	16070053	PINION GUARD
103	11030003	BODY FOOT SCREW	608	16080004	DRAG WASHER RETAINER
104	11040001	BODY FOOT NUT	609	16090012	SPRING WASHER
107-1	11070037	LINE GUARD	611	16110050	EARED WASHER
108	11080018	HANGER	612	16120064	KEY WASHER
108-1	11080030	THE PROTECTION COVER OF REEL S LUGS	613	16130007	COMPRESSION SPRING
114	11140005	CLAMP	700	17000094	DRIVE GEAR
115	11150006	WING SCREW	700-1	17000092	DRIVE GEAR
116	11160003	WING NUT	701	17010264	DRIVE GEAR SHAFT
117	11170002	RETAINER NUT	702	17020058	PINION GEAR
200	12001780	MAIN SIDE PLATE	702-1	17020070	PINION GEAR
201	12010027	ANTI-RE PAWL	717	17170004	MAIN SHAFT PIN
203	12030004	CONTROL PIN	718	17180210	MAIN SHAFT
204	12040002	COMPRESSION SPRING	723	17230009	SILENT SPRING
204-1	12040029	COMPRESSION SPRING	913	19130002	SPRING WASHER
204-2	12040006	COMPRESSION SPRING	19000004	19000004	E RETAINER
204-3	12040011	COMPRESSION SPRING	29000001	29000001	E RETAINER
205	12050033	DECORATION PLATE	19010006	19010006	E RETAINER
206	12060002	LEVER DRAG STOPPER CAP	0910409	0910409	BALL BEARING
207	12070075	HOLDED PLATE	0910445	0910445	BALL BEARING
208	12080082	SIDE PLATE COVER	0910459	0910459	BALL BEARING
215	12150022	HOLD PLATE BUSHING	0910099	0910099	BALL BEARING
215-1	12150026	HOLD PLATE BUSHING	0910460	0910460	BALL BEARING
217	12170014	ANTI-RE PAWL SPRING	0920503	0920503	WASHER
217-1	12170018	ANTI-RE PAWL SPRING	0920506	0920506	WASHER
225	12250002	BUSHING	0920510	0920510	WASHER
226	12260003	BALL	0920207	0920207	WASHER
300	13000962	VICE SIDE PLATE	0920218	0920218	WASHER
303	13030068	CLICK KNOB	0920411	0920411	WASHER
304	13040019	CLICK PAWL	0920426	0920426	WASHER
305	13050014	CLICK PAWL SPRING	0920004	0920004	WASHER
311	13110078	SIDE PLATE COVERS	09201000	09201000	WASHER
400	14000848	SPOOL	0920154	0920154	WASHER
401	14010036	SPOOL CLICK GEAR	0920319	0920319	WASHER
402	14020008	LINE HOLDER	0920481	0920481	WASHER
404	14040011	PRESSURE LOAD BLOCK	0920490	0920490	WASHER
405	14050031	SPOOL COVER	0920263	0920263	WASHER
406	14060006	BUSHING	09301130	09301130	SCREW
500	15000347	HANDLE ASSY	0930651	0930651	SCREW
501	15010010	HANDLE NUT	09301052	09301052	SCREW
507	15070013	DRIVE GEAR TRANSMISSION PIN	0930668	0930668	SCREW
507-1	15070034	PUSH BUTTON	09301256	09301256	SCREW
507-2	15070035	TRANSMISSION PIN	0930044	0930044	SCREW
508	15080002	PUSH BUTTON SPRING	0930614	0930614	SCREW
513	15130025	HANDLE COVER	0930646	0930646	SCREW
515	15150002	SCREW	0930196	0930196	SCREW
516	15160029	HANDLE NUT RETAINER	0930211	0930211	SCREW
517	15170015	DRIVE GEAR PIN	09301115	09301115	SCREW
517-1	15170004	TRANSMISSION PIN	0930003	0930003	SCREW
600	16000101	CAST CONTROL CAP	0930469	0930469	SCREW
601	16010004	DRAG NUT	0930048	0930048	SCREW
602	16020049	ADJUST BLOCK	0940032	0940032	O RING