



SLR-50II PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001562	MAIN BODY	605	16050108	LEVER DRAG
101	11010030	BODY LOGO	605-1	16050093	LEVER DRAG
102	11020017	BODY FOOT	607	16070048	PINION GUARD
103	11030003	BODY FOOT SCREW	608	16080008	DRAG WASHER RETAINER
104	11040001	BODY FOOT NUT	609	16090020	SPRING WASHER
107	11070030	LINE GUARD	611	16110049	FARED WASHER
108	11080016	HANGER	612	16120063	KEY WASHER
108-1	11080030	THE PROTECTION COVER OF REELS LUGS	613	16130007	COMPRESSION SPRING
114	11140005	CLAMP	700	17000305	DRIVE GEAR
115	11150006	WING SCREW	700-1	17000307	DRIVE GEAR
116	11160003	WING NUT	701	17010260	DRIVE GEAR SHAFT
117	11170002	RETAINER NUT	702	17020345	PINION GEAR
200	12001825	MAIN SIDE PLATE	702-1	17020347	PINION GEAR
201	12010027	ANTI-RE PAWL	717	17170004	MAIN SHAFT PIN
203	12030003	CONTROL PIN	718	17180188	MAIN SHAFT
204	12040002	COMPRESSION SPRING	723	17230007	SILENT SPRING
204-1	12040029	COMPRESSION SPRING	913	19130002	SPRING WASHER
204-2	12040011	COMPRESSION SPRING	19000004	19000004	E RETAINER
204-3	12040007	COMPRESSION SPRING	29000001	29000001	E RETAINER
205	12050034	DECORATION PLATE	0910099	0910099	BALL BEARING
206	12060006	LEVER DRAG STOPPER CAP	0910459	0910459	BALL BEARING
207	12070074	HOLDED PLATE	0910445	0910445	BALL BEARING
208	12080083	SIDE PLATE COVER	0910433	0910433	BALL BEARING
215	12150021	HOLD PLATE BUSHING	0910460	0910460	BALL BEARING
215-1	12150027	HOLD PLATE BUSHING	0920004	0920004	WASHER
215-2	12150025	HOLD PLATE BUSHING	0920319	0920319	WASHER
217	12170013	ANTI-RE PAWL SPRING	0920207	0920207	WASHER
217-1	12170017	ANTI-RE PAWL SPRING	0920218	0920218	WASHER
225	12250002	BUSHING	0920412	0920412	WASHER
226	12260003	BALL	0920426	0920426	WASHER
300	13000961	VICE SIDE PLATE	0920154	0920154	WASHER
303	13030068	CLICK KNOB	09201000	09201000	WASHER
304	13040019	CLICK PAWL	0920481	0920481	WASHER
305	13050014	CLICK PAWL SPRING	0920490	0920490	WASHER
311	13110080	SIDE PLATE COVERS	0920504	0920504	WASHER
400	14000850	SPOOL	0920505	0920505	WASHER
401	14010036	CLICK GEAR	0920511	0920511	WASHER
402	14020008	LINE HOLDER	0920282	0920282	WASHER
404	14040009	PRESSURE LOAD BLOCK	0920263	0920263	WASHER
405	14050028	SPOOL COVER	0930196	0930196	SCREW
500	15000348	HANDLE ASSY.	0930211	0930211	SCREW
501	15010010	HANDLE NUT	0930044	0930044	SCREW
507	15070027	DRIVE GEAR TRANSMISSION PIN	0930646	0930646	SCREW
507-1	15070034	PUSH BUTTON	0930893	0930893	SCREW
507-2	15070035	PUSH BUTTON	09301052	09301052	SCREW
508	15080002	PUSH BUTTON SPRING	09301088	09301088	SCREW
513	15130026	HANDLE COVER	09301113	09301113	SCREW
515	15150002	HANDLE SCREW	09301115	09301115	SCREW
516	15160029	HANDLE NUT RETAINER	0930469	0930469	SCREW
517	15170018	TRANSMISSION PIN	0930003	0930003	SCREW
517-1	15170004	TRANSMISSION PIN	0930048	0930048	SCREW
600	16000101	CAST CONTROL CAP	09301130	09301130	SCREW
601	16010004	COMPRESSION SPRING	09301129	09301129	SCREW
602	16020049	ADJUST BLOCK	0940032	0940032	O RING