



SLV - 45 SPARE PARTS LIST

KEY	PARTS NO	PARTS NAME	LOT
100	13100057-04006	MAIN BODY	
101	13101027-06001	MAIN SHAFT	
102	13102001-14C6A	MAIN BODY FOOT	
207	13207002-03001	SCREW MAT	
300	13300028-04002	DRAG KNOB	
300-1	13300030-01001	DRAG KNOB RETAINER	
304	1330401503001A	CLICK PAWL ASSY.	
307	1330701901	O RING	
307-1	13307006-07	O RING/ CUSHION	
307-2	13307009-07	O RING	
310	13310007-02	DRAG WASHER	
312	13312006-06	KEY WASHER	
316	13316002-07	PACKING WASHER	
400	1340006004005	SPOOL ASSY.	
404	13404016-01001	HANDEL KNOB	
405	13405006-03002	HANDLE KNOB SCREW	
408	13408007-05907	SPOOL RETAINER	
409	1340900601	SPOOL RETAINER SPRING	
410	1341001104	SPOOL COVER	
413	13413002-03907	COUNTER BALANCE	
9101	01081209-62A	ONE WAY BEARING	
9202	028.1x12x0.2-6	WASHER	
9302	03112x5-61	SPOOL COVER SCREW	
9303	032100512	HANDEL KNOB SCREW	
9303-1	032100510	COUNTER BALANCE SCREW	
9304	032100507	BODY FOOT SCREW	
9306	03412.6x4-61	DRAG KNOB SCREW	
9307	03312x5-61	CLICK PAWL SCREW	
9403	11900004-06	E RETAINER	
9501	11901007-06	C RETAINER	