



SPa-80 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003611	MAIN BODY	702	27020343	PINION GEAR
105	0910332	PINION BEARING FIXED PLATE	705	27050073	TRANSMISSION GEAR
105-1	0910396	BALL BEARING PLATE	708	27080069	OSCILLATING SLIDER
108	21081278	CAP	716	27160010	OSCILLATION SLIDER PLATE
200	22003523	SIDE PLATE	718	27180614	MAIN SHAFT
201	22010064	MAIN BODY DECORATION	719	27190005	CLICK GEAR
201-1	22010063	SIDE PLATE DECORATION	722	27220005	CLICK GEAR WASHER
201-2	22010039	MAIN BODY DECORATION	722-1	27220036	CLICK GEAR WASHER
201-3	22010037	SIDE PLATE DECORATION	725	27250019	TRANSMISSION GEAR BUSHING
300	23003922	ROTOR	800	28000256	ANTI-REVERSE/ANTI-RE LEVER
301	23011799	BAIL ARM COVER	800-1	28000327	ANTI-REVERSE/ANTI-RE LEVER
304	23042432	BAIL ARM COVER	801	28010039	ANTI-RE LEVER SPRING
305	23050136	KICK LEVER	0910352	0910352	BALL BEARING
306	23060918	BAIL HOLDER	0910184	0910184	BALL BEARING
307	23073149	BAIL HOLDER	0910141	0910141	BALL BEARING
309	23090030	BAIL ARM SUPPORT PIN	0920539	0920539	WASHER
310	23100049	COMPRESSION SPRING	0920209	0920209	WASHER
313	23131406	BAIL WIRE ASSY.	0920169	0920169	WASHER
315	23150010	LINE ROLLER	0920168	0920168	WASHER
316	23160002	LINE ROLLER BUSHING	0920075	0920075	WASHER
317	23170011	LINE ROLLERWASHER	0920355	0920355	WASHER
318	23180008	ROTOR NUT	0930452	0930452	SCREW
400	240011668	SPOOL ASSY.	0930562	0930562	SCREW
405	24050031	DRAG WASHER RETAINER	0930471	0930471	SCREW
407	24070026	EXTENSION SPRING	09301272	09301272	SCREW
500	25005185	HANDLE ASSY.	0930643	0930643	SCREW
504	25040003	HANDLE SCREW CAP WASHER	0930964	0930964	SCREW
513	25130695	HANDLE CAP	0930819	0930819	SCREW
600	26002864	DRAG KNOB ASSY.	0930663	0930663	SCREW
610	26100055	DRAG WASHER	0930575	0930575	SCREW
611	26110021	EARED WASHER	0930945	0930945	SCREW
612	26120063	KEY WASHER	0930044	0930044	SCREW
612-2	26120064	KEY WASHER	0930763	0930763	SCREW
700	27000332	DRIVE GEAR	0930541	0930541	SCREW