


okuma

BAITCAST REEL

SERRANO

SR-200W



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	5K095003	Palm side cover	39	5K093801	Pinion
2	6K974501	Lock pin	40	5K094301	Gear side cover assembly
3	6K974401	Coil spring	41	6K904901	O-ring
4	5K095101	Spool cover assembly	42	6K176701	Ball Bearing
5	63535902	Tap screw	43	5K027001	Spool tension Washer-A
6	5K027001	Spool tension washer-A	44	6K176905	Collar
7	6K474501	Ball bearing	45	6K177001	Cushion Washer
8	6K468301	Ring	46	5K095304	Tension knob
9	5K094603	Spool assembly	47	6K311311	Screw-A
10	6K311311	Screw-A	48	6K170601	Ball Bearing
11	6K956203	Screw-B	49	63201402	Retainer
12	6K314101	Tap screw	50	6K929901	Bearing plate
13	63205901	Retainer	51	6K398604	Screw
14	5K028501	Bush	52	5K093602	Gear metal
15	6K626401	Ball bearing	53	6K258101	Gear
16	6K468601	Pipe	54	6K893602	Ratchet
17	5K092901	Level Wind Assembly	55	6K174504	Washer-L1
18	5K041802	Level wind pin	56	5K093902	Drive gear
19	6K148801	Washer	57	5K094001	Washer-L2
20	6K704403	Level Wind Nut	58	6K943101	Washer-D1
21	5K093201	Worm Shaft	59	5K094101	Wahser-A
22	6K626401	Ball bearing	60	6K943103	Washer-D2
23	5K028501	Bush	61	6K882402	Collar
24	6K161806	Washer	62	6K896701	Sleeve
25	6K469301	Worm pinion	63	6K177301	Washer
26	6B339801	Retainer	64	6K259501	Leaf spring assembly
27	5K094203	Hood	65	5K027201	Spring washer
28	6K939401	Pillar	66	6K193601	Washer
29	5K092601	Frame assembly	67	5K084006	Star drag assembly
30	6K977205	Thumb bar assembly	68	6K161404	Leaf spring
31	5K119001	Kick lever spring	69	5K095705	Handle assembly
32	5K092801	Kick lever	70	5K047105	Handle nut
33	5K093401	Clutch cam spring	71	5K005004	Handle nut retainer
34	5K093301	Clutch cam	72	63520407	Screw
35	6K723502	Clutch cam screw			
36	6K723502	Clutch cam screw			
37	5K093701	Clutch			
38	6K942501	Coil spring			
			SR - 200		
			9	5K095402	Spool assembly