



X-250 SPARE PARTS LIST

KEY NO.	PARTS NAMES	PARTS NO.	KEY NO.	PARTS NAMES	PARTS NO.
100	MAIN BODY ASSY	1410000204949	706	IDLE GEAR	14706001-0114
105	WORM SHAFT BUSHING	14105001-0114	707	MEDIUM TRANSMISSION GEAR	14707001-0114
117	HANDLE NUT	14117001-03	709	TRANSMISSION GEAR BUSHING	14709001-03
200	RIGHT SIDE PLATE ASSY	1420000104950	711	LINE GUIDE ASSEMBLY	1471100101X
202	ANTI-REVERSE RATCHET	14202001-06	712	WORM SHAFT	14712002-03001
206	BRAKE COLLARS(6 PIECES)	14206001-01001	713	PAWL CAP	14713001-0170
220	RIGHT DIDE PLATE BOLTS	14220001-03907	715	LINE GUIDE PAWL	11715003-06
221	RIGHT SIDE PLATE BOLTS ORING	14221001-07	720	ONE WAY CLUTCH INNER RING	11720002-06001
222	RIGHT SIDE SET PLATE	14222001-01001	800	CLUTCH BAR SHAFT	14800001-06
300	LEFT SIDE PLATE ASSY	14300001-04950	801	CLUTCH PAWL SPRING	14801001-06
302	MAIN SHAFT LEFT DIDE SPACER	14302001-03	802	CLUTCH BAR	14802002-0170
400	SPOOL	14400002-04907	803	CLUTCH BAR SUPPORT	14803002-06
500	DOUBLE HANDE ASSY	1450000204X	804	CLUTCH PAWL	14804001-06
513	HANDLE COVER	14513001-06	805	PINNON GEAR YOKE	14805001-0114
516	HANDE NUT HOLDER	1451600101913A	806	YOKE SPRING	14806001-06
600	CAST CONTROL CAP	14600001-04907	807	CLUTCH CAM	14807001-0114
601	COMPRESSION SPRING	14601001-16	808	CLUTCH CAM SPRING	14808001-06001
603	RIGHT DIDE BUSHING O RING	14603001-07	809	CLUTCH BAR SPACER	14809001-0170
604	CONTROL CLICK	14604001-0170	810	CLUTCH BAR GUIDE	14810001-01001
608	BEARING RETAINER	14608001-06	812	CLUTCH CAM PLATE	14812001-06
609	DRAG SPRING WASHER	14609003-06001	9101	BALL BEARING	01051003-61
609-1	DRAG SPRING WASHER	14609004-05907	9103	ONE WAY CLUTCH BEARING	01101612-5
610	DRAG WASHER	11610004-006A	9104	BALL BEARING	01050825-5
610-1	DRAG WASHER	11610003-006	9106	BALL BEARING(A)	01031004-61
611	EARED WASHER	11611005-061	9201	WASHER	025.1x10.5x.2-6
612	KER WASHER	11612007-061	9203	RIGHT SIDE PLATE BOLTS SPACER	023x5x0.2-1
612-1	KER WASHER	14612001-06	9204	WASHER	025.9x12x0.2-6
614	FRICITION WASHER	11614001-06	9205	DRIVE GEAR WASHER	0210x20x1-8
615	STAR DRAG	14615003-04002C	9206	CLUTCH BAR SHAFT SPACER	023.5x6x0.5-3
618	RUBBER SPACER	14618001-07	9207	WASHER	025x6.5x0.2-3
619	MAIN SHAFT RIGHT SIDE SPACER	14619001-03	9302	RIGHT SIDE SET PLATE SCREW	03412.3x10.5-61
700	DRIVE GEAR	14700002-032	9303	LEFT SIDE PLATE SCREW	03212.6x6-61
701	DRIVE GEAR SHAFT	14701002-03002	9306	CLUTCH BAR GUIDE SCREW	03122x5-61
702	PINION GEAR ASSY.	14702001-03002	9402	DRIVE GEAR SHAFT "E"RETAINER	12900002-06
703	LEVEL WIND GUARD	14703002-06001	9403	MEDIUM TRANSMISSION GEAR"E" RETAINER	14900001-06
704	LEVEL WIND GUARD	14704002-06	9404	WORM SHAFT AND CLUTCH "E" RETAINER	12900001-06
705	WORM SHAFT GEAR	14705001-06	9504	MAIN SHAFT C RETAINER	11901001-06
706	IDLE GEAR	14706001-0114			