



MIKE'S REEL REPAIR
 #108 - 31060 Peardonville Road
 Abbotsford, B.C., Canada V2T 6K6
 Toll Free 1-888-404-1119

X-250/250S.

X-MEANS PAINT OR INJ. COLOR

SIZE	250	250S	PARTS NAMES	SIZE	250	250S	PARTS NAMES
100	141000204949	141000204949	MAIN BODY ASSY	706	14706001-0114	14706001-0114	IDLE GEAR
105	14105001-0114	14105001-0114	WORM SHAFT BUSHING	707	14707001-0114	14707001-0114	MEDIUM TRANSMISSION GEAR
117	14117001-03	14117001-03	HANDLE NUT	709	14709001-03	14709001-03	TRANSMISSION GEAR BUSHING
200	142000104950	142000104950	RIGHT SIDE PLATE ASSY	711	1471100101X	1471100101X	LINE GUIDE ASSEMBLY
202	14202001-06	14202001-06	ANTI-REVERSE RATCHET	712	14712002-03001	14712002-03001	WORM SHAFT
206	14206001-01001	14206001-01001	BRAKE COLLARS(6 PIECES)	713	14713001-0170	14713001-0170	PAWL CAP
220	14220001-03907	14220001-03907	RIGHT SIDE PLATE BOLTS	715	11715003-06	11715003-06	LINE GUIDE PAWL
221	14221001-07	14221001-07	RIGHT SIDE PLATE BOLTS ORING	720	11720002-06001	11720002-06001	ONE WAY CLUTCH INNER RING
222	14222001-01001	14222001-01001	RIGHT SIDE SET PLATE	800	14800001-06	14800001-06	CLUTCH BAR SHAFT
300	14300001-04950	14300001-04950	LEFT SIDE PLATE ASSY	801	14801001-06	14801001-06	CLUTCH PAWL SPRING
302	14302001-03	14302001-03	MAIN SHAFT LEFT SIDE SPACER	802	14802002-0170	14802002-0170	CLUTCH BAR
400	14400002-04907	14400002-04907	SPOOL	803	14803002-06	14803002-06	CLUTCH BAR SUPPORT
500	1450000204X	1450000204X	DOUBLE HANDLE ASSY	804	14804001-06	14804001-06	CLUTCH PAWL
513	14513001-06	14513001-06	HANDLE COVER	805	14805001-0114	14805001-0114	PINION GEAR YOKE
516	1451600101913A	1451600101913A	HANDLE NUT HOLDER	806	14806001-06	14806001-06	YOKE SPRING
600	14600001-04907	14600001-04907	CAST CONTROL CAP	807	14807001-0114	14807001-0114	CLUTCH CAM
601	14601001-16	14601001-16	COMPRESSION SPRING	808	14808001-06001	14808001-06001	CLUTCH CAM SPRING
603	14603001-07	14603001-07	RIGHT SIDE BUSHING O RING	809	14809001-0170	14809001-0170	CLUTCH BAR SPACER
604	14604001-0170	14604001-0170	CONTROL CLICK	810	14810001-01001	14810001-01001	CLUTCH BAR GUIDE
608	14608001-06	14608001-06	BEARING RETAINER	812	14812001-06	14812001-06	CLUTCH CAM PLATE
609	14609003-06001	14609003-06001	DRAG SPRING WASHER	9101	01051003-61	01051003-61	BALL BEARING
609-1	14609004-05907	14609004-05907	DRAG SPRING WASHER	9103	01101612-5	01101612-5	ONE WAY CLUTCH BEARING
610	11610004-006A	11610004-006A	DRAG WASHER	9104	01050825-5	01050825-5	BALL BEARING
610-1	11610003-006	11610003-006	DRAG WASHER	9106	01031004-61	01031004-61	BALL BEARING(A)
611	11611005-061	11611005-061	EARED WASHER	9201	025.1x10.5x.2-6	025.1x10.5x.2-6	WASHER
612	11612007-061	11612007-061	KEY WASHER	9203	023x5x0.2-1	023x5x0.2-1	RIGHT SIDE PLATE BOLTS SPACER
612-1	14812001-06	14812001-06	KEY WASHER	9204	025.9x12x0.2-6	025.9x12x0.2-6	WASHER
614	11614001-06	11614001-06	FRICTION WASHER	9205	0210x20x1-8	0210x20x1-8	DRIVE GEAR WASHER
615	14615003-04002C	14615003-04002C	STAR DRAG	9206	023.5x6x0.5-3	023.5x6x0.5-3	CLUTCH BAR SHAFT SPACER
618	14618001-07	14618001-07	RUBBER SPACER	9207	025x6.5x0.2-3	025x6.5x0.2-3	WASHER
619	14619001-03	14619001-03	MAIN SHAFT RIGHT SIDE SPACER	9302	03412.3x10.5-61	03412.3x10.5-61	RIGHT SIDE SET PLATE SCREW
700	14700002-032	14700002-032	DRIVE GEAR	9303	03212.6x6-61	03212.6x6-61	LEFT SIDE PLATE SCREW
701	14701002-03002	14701002-03002	DRIVE GEAR SHAFT	9306	03122x5-61	03122x5-61	CLUTCH BAR GUIDE SCREW
702	14702001-03002	14702002-032	PINION GEAR ASSY.	9402	12900002-06	12900002-06	DRIVE GEAR SHAFT "E"RETAINER
703	14703002-06001	14703002-06001	LEVEL WIND GUARD	9403	14900001-06	14900001-06	MEDIUM TRANSMISSION GEAR" E" RETAINER
704	14704002-06	14704002-06	STABILIZER BAR	9404	12900001-06	12900001-06	WORM SHAFT AND CLUTCH "E" RETAINER
705	14705001-06	14705001-06	WORM SHAFT GEAR	9504	11901001-06	11901001-06	MAIN SHAFT C RETAINER