



Please specify reel model number and number in reel foot when ordering parts.

Ambassadeur Pro Max LH 18 01

Vid beställning av reservdelar bör alltid rulltyp och nummerbeteckning under rullfoten anges

1137355, 1160469 34-12575-2

ITEM#	PART #	DESCRIPTION	ITEM#	PART #	DESCRIPTION
1	1138837	RIGHT SIDE PLATE	41	1160978	CLUTCH CAM
2	1134503	MAG DIAL	42	1138859	LEFT SIDE PLATE
3	1134431	CLICK SPRING	43	1134492	SCREW
4	1134432	O-RING	44	1134465	O-RING
5	1134433	CAM CURVE A	45	1134466	THUMB SCREW
6	1134434	CAM CURVE B	46	1104812	O-RING
7	1138838	LINE REJECTER	47	1134494	BALL BEARING
8	1134436	SCREW	48	1095593	WASHER
9	1134437	COIL SPRING	49	1104813	COLLAR
10	1134438	SCREW	50	1104814	WASHER
11	1134439	MAGNET HOLDER	51	1134510	BRAKE KNOB
12	1134440	WASHER	52	1134467	BALL BEARING
13	1134441	BALL BEARING	53	1134468	RETAINER
14	1134442	LOCK RING	54	1134469	MAIN GEAR SHAFT PLATE
15	1134505	SPOOL	55	1104820	SCREW
16	1104799	RETAINER	56	1138860	MAIN GEAR SHAFT
17	1134444	BUSHING	57	1065960	LEVEL WIND GEAR
18	1134445	LINE GUIDE	58	1134471	RATCHET
19	1134446	PAWL	59	1065962	DRAG WASHER
20	1134447	WASHER	60	1138861	MAIN GEAR
21	1134448	LINE GUIDE NUT	61	1134473	DRAG WASHER
22	1138559	WORM SHAFT TUBE	62	1134474	PRESSURE WASHER
23	1138839	WORM SHAFT	63	1134475	IAR BEARING
24	1134450	WASHER	64	1134476	IAR SLEEVE
25	1134451	GEAR	65	1134477	BALL BEARING
27	1138842	FRONT COVER	66	1134478	WASHER
28	1134453	SCREW	67	1104824	CLICK SPRING
29	1134454	LINE GUIDE SHAFT	68	1065971	SPRING WASHER
31	1138845	FRAME	69	1134497	WASHER
32	1138848	THUMB BAR	70	1138864	STAR WHEEL
33	1138849	YOKE	71	1065974	SPRING WASHER
34	1104810	YOKE SPRING	72	1141284	HANDLE
35	1138852	PINION	73	1138865	HANDLE NUT
36	1160976	FLIPPING SWITCH	74	1134515	HANDLE NUT COVER
37	1160977	CLUTCH SPRING	75	1134501	SCREW
38	1134460	SCREW			
39	1138854	SPRING			
40	1138855	KICK LEVER			