



Please specify reel model number and number in reel foot when ordering parts.

Ambassadeur Pro Max 17 01

Vid beställning av reservdelar bör alltid rulltyp och nummerbeteckning under rullfoten anges

1129928, 1157038

34-12547-2

ITEM#	PART #	DESCRIPTION	ITEM#	PART #	DESCRIPTION
1	1134502	LEFT SIDE PLATE	40	1134461	KICK LEVER
2	1134503	MAG DIAL	41	1160981	CLUTCH CAM
3	1134431	CLICK SPRING	42	1134508	RIGHT SIDE PLATE
4	1134432	O-RING	43	1134492	SCREW
5	1134433	CAM CURVE A	44	1134465	O-RING
6	1134434	CAM CURVE B	45	1134466	THUMB SCREW
7	1134435	LINE REJECTER	46	1104812	O-RING
8	1134436	SCREW	47	1134494	BALL BEARING
9	1134437	COIL SPRING	48	1095593	WASHER
10	1134438	SCREW	49	1104813	COLLAR
11	1134439	MAGNET HOLDER	50	1104814	WASHER
12	1134440	WASHER	51	1134510	BRAKE KNOB
13	1134485	BALL BEARING	52	1134467	BALL BEARING
14	1134442	LOCK RING	53	1134468	RETAINER
15	1134505	SPOOL	54	1134469	MAIN GEAR SHAFT PLATE
16	1104799	RETAINER	55	1104820	SCREW
17	1134444	BUSHING	56	1134470	MAIN GEAR SHAFT
18	1134445	LINE GUIDE	57	1065960	LEVEL WIND GEAR
19	1134446	PAWL	58	1134471	RATCHET
20	1134447	WASHER	59	1065962	DRAG WASHER
21	1134448	LINE GUIDE NUT	60	1134472	MAIN GEAR
22	1138559	WORM SHAFT TUBE	61	1134473	DRAG WASHER
23	1134449	WORM SHAFT	62	1134474	PRESSURE WASHER
24	1134450	WASHER	63	1134475	IAR BEARING
25	1134451	GEAR	64	1134476	IAR SLEEVE
27	1134506	FRONT COVER	65	1134477	BALL BEARING
28	1134453	SCREW	66	1134478	WASHER
29	1134454	LINE GUIDE SHAFT	67	1104824	CLICK SPRING
31	1134512	FRAME	68	1065971	SPRING WASHER
32	1134507	THUMB BAR	69	1134497	WASHER
33	1138560	YOKE	70	1134513	STAR WHEEL
34	1104810	YOKE SPRING	71	1065974	SPRING WASHER
35	1134457	PINION	72	1134514	HANDLE
36	1160979	FLIPPING SWITCH	73	1138561	HANDLE NUT
37	1104804	CLUTCH SPRING	74	1134515	HANDLE NUT COVER
38	1134460	SCREW	75	1134501	SCREW
39	1104807	SPRING			