




PARTS LIST FOR MODELS 113H, 113HLW, 113HSP, AND 113HLH



<u>KEY NO.</u>	<u>113H PART NO.</u>	<u>113HLW PART NO.</u>	<u>113HSP PART NO.</u>	<u>113HLH PART NO.</u>	<u>DESCRIPTION</u>
1	001 113H	001 113H	001 113H	001 113HLH	Right Side Plate
2	002 113HO	002 113HO	002 113HO	002 113HO	Outer Right Side Ring
3	003 113H	003 113H	003 113H	003 113HLH	Bridge Assembly
4	004 349	004 349	004 349	004 349	Fiber Washer
5	005 113H	005 113H	005 113H	005 113HLH	Main Gear
6	006 113H	006 113H	006 113H	006 113H	Drag Washer (5 req.)
7	007C113H	007C113H	007C113H	007C113H	Metal Drag Washer Set
8	008 349	008 349	008 349	008 349	Tension Spring
8A	018 970	018 970	018 970	018 970	Tension Spring
9	009 113H	009 113H	009 113H	009 113H	Spacing Sleeve
10	010 349	010 349	010 349	010 349	Star Drag Wheel
11	011 113	011 113	011 113	011 113	Eccentric Jack
12	012 060	012 060	012 060	012 060	Pinion Yoke
13	013 113H	013 113H	013 113H	013 113HLH	Pinion
14	014 099	014 099	014 099	014 099	Dog Spring
15	015 113H	015 113H	015 113H	015 113H	Dog
16	016 113H	016 113H	016 113H	016 113H	Lower Bridge Screw (2 req.)
17	017 113H	017 113H	017 113H	017 113H	Upper Bridge Screw (2 req.)
18	018 060	018 060	018 060	018 060	Clutch Spring (2 req.)
19	019 113	019 113	019 113	019 113	Eccentric
20	020 155	020 155	020 155	020 155	Eccentric Spring
21	021 066	021 066	021 066	021 066	Eccentric Lever
22	022 099	022 099	022 099	022 099	Eccentric Screw
23	023 114	023 114	023 114	023 114	Handle Screw
23A	110 060	110 060	110 060	110 060	Handle lock Screw
24	024S349H	024S349H	024S349H	024S349H	Handle Assembly
26	026 113H	026 113H	026 113H	026 113H	Right Side Bearing
27	027N113H	027N113H	027N113H	027N113H	Left Side Plate
28	002 113-I	002 113-I	002 113-I	002 113-I	Inner L. S. Side Ring (2 req.)
28A	002 113O	002 113O	002 113O	002 113O	Outer Left Side Ring
29L	029L113HL	029L113HLW	029M113H	029L113HL	Spool
33	033 113	033 113	033 113	033 113	Rod Clamp
*	*033R200	*033R200	*033R200	*033R200	*Ringed Rod Clamp (Optional)
34	034 045	034 045	034 045	034 045	Clamp Screw (Only)
34C	034C045	034C045	034C045	034C045	Rod Clamp Screw w/Nuts
35	035 060	035 060	035 060	035 060	Click Tongue
36	036 113	036 113	036 113	036 113	Click Button
37	037 113	037 113HLW	037 113	037 113	Frame Post
37C	050 113HL	050 113HLW	050 113HL	050 113HL	Frame Cover Post
39A	039 009	039 009	039 009	039 009	Frame Post Screw (16 req.)
**40	**040 113HL	**040 113HL	**040 113HL	**040 113HL	**Left Side Bearing
40A	120 113H	120 113H	120 113H	120 113H	Left Side Bearing O-Ring
54	054 113	054 113	054 113	054 113	Harness Lug (2 req.)
62	062 309	062 309	062 309	062 309	Click Spring
62A	063 209	063 209	063 209	063 209	Click Spring Screw
69	069B600	069B600	069B600	069B600	Retaining Ring
98	098 320	098 320	098 320	098 320LH	Gear Sleeve
102	102 113	102 113	102 113	102 113	Gear Sleeve Pin
149	149 045	149 045	149 045	149 045	Clamp Nut
149A	149 200	149 200	149 200	149 200	Hex Nut
183	183 113H	183 113HLW	183 113HSP	183 113H	Frame

*Not Shown

**Owners of older 113H, 113HLW reels must order 40-113H