




PARTS LIST FOR MODELS 4500SS & 5500SS

REEL ASSEMBLY NOs. 1151133 (4400SS) & 1151138 (5500SS)



| KEY NO. | 4500SS PART NO. | ORDER PART NO. | DESCRIPTION | ORDER PART NO. | 5500SS PART NO. |
|---------|-----------------|----------------|------------------------------|----------------|-----------------|
| **1 | **001P4500 | **1180583 | **Housing | **1180584 | **001P5500 |
| 4 | 004N4400 | 1180804 | Dog | 1180804 | 004N4400 |
| 6A | 006A450 | 1180948 | Eccentric | 1180948 | 006A450 |
| 6B | 006B750 | 1180967 | Eccentric Liner | 1180967 | 006B750 |
| 6D | 006D710 | 1180977 | Eccentric Spring | 1180977 | 006D710 |
| 6E | 006E750 | 1180987 | Eccentric Lever | 1180987 | 006E750 |
| 8N | 008N5500 | 1181134 | Main Gear | 1181134 | 008N5500 |
| 10 | 010N4400 | 1181222 | Ratchet | 1181222 | 010N4400 |
| 10A | 230N5500 | 1185068 | Friction Spring | 1185068 | 230N5500 |
| 15 | 015 550G | 1181481 | Handle Assembly | 1181481 | 015 550G |
| 16 | 016 910 | 1181585 | Eccentric Screw | 1181585 | 016 910 |
| 19N | 019N4500 | 1181750 | Pinion | 1181751 | 019N5500 |
| 20 | 020 722 | 1181792 | Ball Bearing (3 req.) | 1181792 | 020 722 |
| 21 | 021 450 | 1181869 | Bearing Cover | 1181869 | 021 450 |
| 22 | 022 750 | 1181922 | Spool Click Screw | 1181922 | 022 750 |
| 23 | 023 750 | 1181953 | Bearing Cover Screw(2 req.) | 1181953 | 023 750 |
| 24 | 024 450 | 1182037 | Bail Wire | 1182045 | 024 5500 |
| 27 | 027 4500 | 1182241 | Rotor | 1182262 | 027 5500 |
| 27A | 027A450 | 1182322 | Bail Trip Cover | 1182326 | 027A5500 |
| 27B | 027B420 | 1182338 | Rotor End Screw | 1182338 | 027B420 |
| 27E | 027E5500 | 1182345 | Balance Weight | 1182345 | 027E5500 |
| 28 | 028 450 | 1182395 | Trip Lever | 1182401 | 028 5500 |
| 28A | 028A440 | 1182426 | Cam Lever | 1182426 | 028A440 |
| 28B | 028B5500 | 1182442 | Trip Lever Bushing | 1182442 | 028B5500 |
| 28C | 028C440 | 1182451 | Trip Cam | 1182451 | 028C440 |
| 31 | 031 550 | 1182671 | Bail Arm Screw | 1182671 | 031 550 |
| 31A | 031A450 | 1182688 | Bail Cam Screw | 1182688 | 031A450 |
| 32 | 032 440 | 1182726 | Bail Spring | 1182726 | 032 440 |
| 34 | 034 450 | 1182819 | Bail Arm | 1182819 | 034 450 |
| 34A | 034A550 | 1182845 | Bail Arm Bushing | 1182845 | 034A550 |
| 35 | 035 704 | 1182937 | Line Roller | 1182937 | 035 704 |
| 35A | 035A704 | 1182962 | Line Roller Bushing | 1182962 | 035A704 |
| 36 | 036 750 | 1183016 | Bail Stud Screw | 1183016 | 036 750 |
| 36A | 036A750 | 1183032 | Lock Washer | 1183032 | 036A750 |
| 37 | 037 450 | 1183077 | Rotor Washer | 1183077 | 037 450 |
| 38 | 038 550 | 1183153 | Rotor Nut | 1183153 | 038 550 |
| 39 | 039N4500 | 1183257 | Spool Shaft | 1183258 | 039N5500 |
| 43 | 043N5500 | 1183430 | Crosswind Block | 1183430 | 043N5500 |
| 43A | 043A550 | 1183425 | Crosswind Block Plate | 1183425 | 043A550 |
| 44 | 044 704 | 1183458 | Cover Screw (4 req.) | 1183458 | 044 704 |
| 44A | 022 750 | 1181922 | Crosswind Block Screw(2 req) | 1181922 | 022 750 |
| 45 | 045 5500 | 1183511 | Housing Cover | 1183511 | 045 5500 |
| 46A | 046A704 | 1183586 | Screw (2 req.) | 1183586 | 046A704 |
| 47 | 047 4500 | 1183640 | Spool Assembly | 1183648 | 047 5500 |
| 48 | 048 450 | 1183409 | Click Tongue | 1183415 | 048 750 |
| 48A | 048A750 | 1183722 | Click Tongue Washer | 1183722 | 048A750 |
| 49 | 049 710 | 1183741 | Click Tongue Spring | 1183741 | 049 710 |
| 50 | 050 712 | 1183766 | Bail Spring Cover Screw | 1183766 | 050 712 |
| 51 | 051 710 | 1183796 | Retaining Ring | 1183796 | 051 710 |
| 52 | 052 550 | 1183824 | Drag Knob | 1183824 | 052 550 |
| 56 | 056 710 | 1183907 | Drag Washer-HT100 (3 req.) | 1183907 | 056 710 |
| 57 | 057 710 | 1183938 | Metal Keyed Washer (2 req.) | 1183938 | 057 710 |
| 58 | 058 710 | 1183961 | Metal Slot (Octagon) | 1183961 | 058 710 |
| 60 | 060 450 | 1183995 | Thrust Washer | 1183999 | 060 550 |
| 69B | 069B4400 | 1184128 | Dog Retaining Ring | 1184128 | 069B4400 |
| 106 | 106 5500 | 1184432 | Lever Spring | 1184432 | 106 5500 |
| 132 | 132 450 | 1184586 | Roller Washer | 1184586 | 132 450 |
| 225 | 225 5500 | 1185005 | Crosswind Shaft Bushing | 1185005 | 225 5500 |
| 226 | 226 5500 | 1185016 | Bushing Cap Cover | 1185016 | 226 5500 |
| 227 | 227 440 | 1185045 | Bail Spring Cover | 1185045 | 227 440 |
| **231 | **231N4500 | **1185119 | **Crosswind Gear | **1185120 | **231N5500 |
| 233 | 233 440* | 1185142 | Bearing Cover | 1185142 | 233 440 |
| *300 | *300 5500 | *1185243 | *Optional Power Handle | *1185243 | *300 5500 |

NOT ALL PARTS ARE AVAILABLE

* Not Shown
 **When ordering 001P4500 or 001P5500,
 you must order 231N4500 or 231N5500 respectively.