


# DO NOT USE THIS SHEET! SEE 407-460L-560L

## **PENN** PARTS LIST FOR MODELS 4600L AND 5600L

**NOTE: DO NOT USE THIS SHEET FOR PART IDENTITY!**  
 Models 4600L and 5600L Liveliners have been renamed to models **460L** and **560L** Slammer Liveliners.  
 Please see sheet number **407-460L-560L** for current part number identification. Thank You.



**NOT ALL PARTS ARE AVAILABLE**

KEY NO.	DESCRIPTION	PART NO.	PART NO.
32	Bail Spring	032 5600	
34	Bail Arm	034 5600	
34A	Rotor Bushing (2 req.)	034A5600	
34B	Pivot Plate	034B5600	
34C	Pivot Arm	034C5600	
35	Line Roller	035 5600	
35A	Ball Bearing	035A706	
38	Rotor Nut	038 5600	
39	Spool Shaft	039 5600	
39A	Locating Pin Clip	039A5600	
39B	Locating Pin	039B5600	
43	Crosswind Block	043N5600	
43A	Spool Shaft Clip	043A5600	
44	Screw (4 req.)	039 004CH	
45	Housing Cover	045 4600	
47	Housing Cover	045 5600	
47	Spool (Complete)	047 4600	
47	Spool (Complete)	047 5600	
47C	Drag Cover	047C5600	
47D	Line Clip	047D5600	
48	Click Tongue	048 5600	
51	Retaining Ring	051 650	
52	Drag Knob Assembly	052 5600	
56T	Drag Washer (Teflon)	056T650	
57	Drag Washer (Keyed)	057 5600	
70	Live Liner Eccentric Lever (Left)	070 5600	
70A	Live Liner Eccentric Lever (Right)	070A5600	
70C	Screw	070C5600	
71	Live Liner Eccentric Spring	071 5600	
72	Live Liner Eccentric	072 5600	
73	Live Liner Plate	073 5600	
74	Live Liner Dog	074 5600	
75	Live Liner Dog Spring	075 5600	
82	Rear Housing	082 5600	
83	Rear Drag Ratchet	083 5600	
83A	Rear Drag Ratchet Washer	083A5600	
84	Rear Drag Click Spring	084 5600	
84A	Rear Drag Click Retainer	084A5600	
85	Rear Drag Washer	085 5600	
85A	Rear Keyed Washer	085A5600	
85B	Rear Eared Washer	085B5600	
86	Rear Drag Spring	086 5600	
86A	Rear Drag Nut	086A5600	
87	Rear Click Pin	087 5600	
87A	Rear Click Pin Ring	087A5600	
88	Rear Drag Knob	088 5600	
95B	Rotor Locking Plate	095B070	
98	Clutch Retainer	098 5600	
98B	Bearing	098B5600	
98S	Clutch Bearing Sleeve	098S5600	
117	Drive Plate	117 5600	
132	Line Roller Washer	132 5600	
227	Bail Trip Cover	227 5600	
231	Crosswind Gear	231N5600	
233	Bearing Cover	233 5600	

KEY NO.	DESCRIPTION	PART NO.
1	Housing	001 4600
1	Housing	001 5600
2	Screw (3 req.)	044 5600
3	Screw (3 req.)	044 710
6	Main Drag Washer HT-100	006 5600
7	Main Keyed Drag Washer	007 5600
8	Gear	008 5600
9	Screw (2 req.)	022 750
11	Screw	036 5600
13	Screw	063A2.5FR
14	Screw (2 req.)	044 4400
15	Handle (4600L) Assembly	015 460
15	Handle (5600L) Assembly	015 560
19	Pinion	019 5600
20	Ball Bearing (2 req.)	020 722
20A	Ball Bearing (2 req.)	020 6500
24	Bail Wire	024 4600
24	Bail Wire	024 5600
27	Rotor Cup	027 4600
27	Rotor Cup	027 5600
27A	Bail Pivot Cover	027A5600
28	Trip Lever	028 5600
31	Screw (2 req.)	036 750