


**PENN** PARTS LIST FOR MODELS 650SS



**NOT ALL PARTS ARE AVAILABLE.**

KEY NO.	DESCRIPTION	PART NO.	ORDER PART NO.
1	Housing	001 650	1180537
3	Dog Screw (2 req)	003 750	1180736
4	Dog	004 650	1180782
4A	Silent Dog	004A650	1180800
5	Click Dog Spring	005 704	1180877
6	Drag Washer (2 req)	006 155	1180915
6A	Upper Eccentric	006A550	1180951
6B	Upper Eccentric Liner	006B750	1180967
6C	Silent Eccentric Screw	006B700Z	1180965
6D	Eccentric Spring (2 req)	006D710	1180977
6E	Anti-Reverse Lever	006E750	1180987
6J	Silent Dog Lever	006J750	1180996
6L	Silent Eccentric	006L650	1180997

KEY NO.	DESCRIPTION	PART NO.	ORDER PART NO.
*7	*Pinion Bushing	*007 750	*1181023
8	Main Gear	008 650	1181096
9A	Standard Drive Screw	009A650	1181170
10	Ratchet	010 650	1181207
15	Handle Assembly	015 650N	1191148
16A	Eccentric Screw (2 req.)	016 910	1181585
17	Seal Washer	017 650	1181600
19	Pinion	019 650	1181706
19A	Pinion Spacer	019A650	1181736
20	Bearing	020 704	1181790
20A	Bearing (2 req)	020 722	1181792
21	Bearing Cover	021 750	1181880
22	Spool Click Screw	022 750	1181922
23	Bearing Cover Screw (3 req.)	023 750	1181953
24	Bail Wire	024 650	1182055
27	Rotor	027 650	1182269
31	Bail Arm Screw	031 750M	1182679
32	Bail Arm Spring	032 750	1182739
34	Bail Arm	034 750	1182832
34A	Bail Arm Bushing	034A750	1182847
35	Line Roller	035 750	1182942
35A	Roller Sleeve	035A704	1182962
36	Bail Stud Screw	036 750	1183016
36A	Lock Washer	036A750	1183032
37	Rotor Washer	037 650	1183082
38	Rotor Nut	038 710	1183157
39	Crosswind Shaft	039 650	1183227
43	Crosswind Block	043 750	1183405
43A	Crosswind Block Plate	043A750	1183427
44	Crosswind Block Screw (2 req)	044 750	1183462
44A	Trip Bumper Screw	044 750	1183462
45	Housing Cover	045 650	1183518
46	Housing Cover Screw (3 req)	046 750	1183576
47	Spool Complete	047 6500	1183656
48	Click Tongue	048 750	1183715
48A	Click Tongue Washer	048A750	1183722
49	Click Tongue Spring	049 710	1183741
50	Bail Spring Cover Screw	050 712	1183766
51	Retaining Ring	051 650	1183794
52	Drag Knob	052 650	1183831
56T	Drag Washer (Teflon®) (2 req)	056T650	1183917
57	Drag Washer (Keyed) (2 req)	057 650	1183936
58	Metal Washer (Octagon) (2 req)	058 650	1183959
60	Thrust Washer	060 750	1184007
132	Roller Washer	132 750	1184595
224	Transfer Lever	224 650	1184993
225	Crosswind Shaft Bushing	225 750	1185007
226	Bushing Cap Cover	226 750	1185019
227	Bail Spring Cover	227 750	1185053
231	Crosswind Gear	231 650	1185091
232	Bearing Cover (Open)	232 650	1185123
233	Bearing Cover (Closed)	233 650	1185149
234	Transfer Lever Screw	234 750	1185153
236	Trip Bumper	236 750	1185156
	* Not Shown		