




RIGHT SIDE FRAME ASSEMBLY





PARTS AND PRICE LIST FOR FATHOM-MASTER® 800-825




RIGHT SIDE FRAME ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION	PRICE
1	132A800	Frame w Bearing & Seals	
2	264 800	Frame Gasket	15.40
3	227 800	Frame Cover	39.50
4	063 800	Cover Mounting Screw (9)	.80
5	220 800	Rubber Washers (15)	.80
6	205 800	Flat Washers(15)	.50
7	530 800	Power Cable (Upper)	37.50
8	203 800	Power Cable Clip	1.25
9	532 800	Power Cable (Lower)	33.00
10	216 800	Model Number Decal	.80
	216 825	Model Number Decal	.80
10A	226 825	Wiring Diagram (Not Shown)	.70
11	247 800	Counter Cup Shaft Seal (1)	3.30
12	247 620	Counter Cup Thrust Washer (2)	.75
13	190P600	Counter Cup Washer	1.65
14	200 600	Counter Cup Lock Nut	1.65
15	302 800	Magnet w/Housing	13.50
16	124 800	Counter Cup Plate	1.70
17	181 800	Counter Cup	15.40
18	305 800	Counter Cup Indicator	1.90

KEY NO.	PART NO.	DESCRIPTION	PRICE
19	057 109	Compression Spring	\$.65
20	303 800	Magnet Housing Knob	3.00
59	184 600	Hold Down Knob	7.90
60	206 600	Hold Down Knob Washer	.80
61	192 600	Hold Down Knob Spring	1.25
62	195 600	Hold Down Retaining Ring	1.35
88	155A800	Gear Box Cover w Bearing	
89	063 800	Gear Box Cover Mounting Screw (6)	.80
91	024A800	Worm Gear	
93	014A800	Worm Shaft Pin	
94	253 800	Worm Retainer w Balls	
94A	252 800	Worm Thrust BRG. Washer	
94B	009 820	Worm Shaft Spacer	
95	253 820	Worm Retainer w Balls	
95A	252 820	Worm Thrust BRG. Washer	
96	018 970	Tension Washer	
97	012A800	Worm Shaft w Worm & Pin	
98	246 800	Worm Shaft Seal (2)	
98A	245 800	Main Shaft Seal (2)	
113	531 800	Lower Power Cord Cap	2.30

LEFT SIDE FRAME ASSEMBLY



KEY NO.	PART NO.	DESCRIPTION	PRICE
5	220 800	Rubber Washer (1)	\$.80
6	205 800	Flat Washer (1)	.50
10B	225A800	Frame Warning Label	.70
10C	217 825	Switch Label	.70
11	247 800	Counter Cup Shaft Seal (1)	3.30
21	098 800	Main Sleeve	16.25
22	102 800	Main Sleeve Pin	.80
23	178 600	Idle Gear (2)	6.70
24	069B600	Idle Gear Retaining Ring (2)	.90
25	188 800	Counter Cup Shaft	.80
26	179 600	Counter Cup Gear	4.70
27	032 800	Motor Mounting Screw	.75
28	194 825	Boom Screw	2.50

Penn Reel Parts list for:

Model: 800 & 825 Fathom-Master Series

RIGHT SIDE FRAME ASSEMBLY:

KEY	PART	
NO	NO.	DESCRIPTION
1	132A-800	FRAME W/BEARING & SEALS
2	264-800	FRAME GASKET
3	227-800	FRAME COVER
4	63-800	COVER MOUNTING SCREW (9 REQ.)
5	220-800	RUBBER WASHERS (15 REQ.)
6	205-800	FLAT WASHERS (15 REQ.)
7	530-800	POWER CABLE (UPPER)
8	203-800	POWER CABLE CLIP
9	532-800	POWER CABLE (LOWER)
10	216-800	MODEL NUMBER DECAL (800)
	216-825	MODEL NUMBER DECAL (825)
10A	226-825	WIRING DIAGRAM (NOT SHOWN)
11	247-800	COUNTER CUP SHAFT SEAL (1)
12	247-620	COUNTER CUP THRUST WASHER (2 REQ)
13	190P-600	COUNTER CUP WASHER
14	200-600	COUNTER CUP LOCK NUT
15	302-800	MAGNET W/ HOUSING
16	124-800	COUNTER CUP PLATE
17	181-800	COUNTER CUP
18	305-800	COUNTER CUP INDICATOR
19	57-109	COMPRESSION SPRING
20	303-800	MAGNET HOUSING KNOB
59	184-600	HOLD DOWN KNOB
60	206-600	HOLD DOWN KNOB WASHER
61	192-600	HOLD DOWN KNOB SPRING
62	195-600	HOLD DOWN RETAINING RING
88	156A-800	GEAR BOX COVER W/BEARING
89	63-800	GEAR BOX COVER MOUNTING SCREW (6 REQ.)
91	5A-800	MAIN GEAR W/SHAFT
93	44A-800	WORM SHAFT BEARING (2 REQ.)
94	253-800	BEARING RETAINER W/BALLS
94A	252-800	WORM THRUST BEARING WASHER (4 REQ.)
94B	9-820	MAIN SHAFT SPACER
95	253-820	BEARING RETAINER W/BALLS
95A	252-820	WORM THRUST BEARING WASHER (4 REQ.)
96	18-970	TENSION WASHER
97	42A-800	WORM SHAFT W/WORM & PIN
98	246-800	WORM SHAFT SEAL (2 REQ.)
98A	245-800	MAIN SHAFT SEAL (2 REQ.)
113	531-800	LOWER POWER CORD CAP

LEFT SIDE FRAME ASSEMBLY:

KEY	PART	
NO	NO.	DESCRIPTION
5	220-800	RUBBER WASHER
6	205-800	FLAT WASHES
10B	225A-800	FRAME WARNING LABEL
10C	217-825	SWITCH LABEL
11	247-800	COUNTER CUP SHAFT SEAL
21	98-800	MAIN SLEEVE
22	102-800	MAIN SLEEVE PIN
23	178-600	IDLER GEAR (2 REQ.)
24	69B-600	IDLER GEAR RETAINING RING (2 REQ.)
25	188-800	COUNTER CUP SHAFT
26	179-600	COUNTER CUP GEAR
27	32-800	MOTOR MOUNTING SCREW
28	194-825	BOOM SCREW

DRAG BRAKE ASSEMBLY:

KEY	PART	
NO	NO.	DESCRIPTION
44	29-800	SPOOL
45	191-836	THERMAL INSULATOR
46	199P-600	INSULATING WASHER (2 REQ.)
47	86-600	KEY WASHER (2 REQ.)
48	6P-600	DRAG WASHER (2 REQ.)
49	7-836	EAR WASHER (2 REQ.)
50	8-600	TENSION WASHER
51	10-600	DRAG CONTROL KNOB
62	9-800	STAR DRAG SPACER
63	195-800	MAIN SHAFT RETAINING RING

ELECTRIC MOTOR ASSEMBLY:

KEY	PART	
NO	NO.	DESCRIPTION
6	205-800	FLAT WASHER
80	501-800	MOTOR
81	273-800	MOTOR SHROUD
82	31-800	MOTOR SHROUD SCREW
83	304-800	FAN W/ SET SCREW
84	119-800	MOTOR SHAFT COUPLING
85	270-800	MOTOR MOUNTING STRAP
86	123-800	MOUNTING SCREW (2 REQ.)

ELECTRICAL DRIVE COMPONENTS:

KEY	PART	
NO	NO.	DESCRIPTION
1	507-825	PC BOARD
2	515-825	HARNESS
3	63-349	MOUNTING SCREW
4	181A-800	INDICATOR BRACKET
5	503-825	SWITCH
6	504-800	SWITCH BOOT