




# PARTS LIST FOR MODEL PURII5000/PURII6000



KEY NO.	PART NO.	DESCRIPTION
27	1308161	27-PURII6000 Rotor (w/weight & screw)
27A	1204023	27A-5000PUR Bail Pivot Cover
27A	1204025	27A-6000PUR Bail Pivot Cover
28	1204026	28-5000PUR Trip Lever
28	1204027	28-6000PUR Trip Lever
31	1203987	31-3000PUR Bail Arm Screw (2 req)
31	1204039	31-6000PUR Bail Arm Screw (2 req)
32	1203988	32-3000PUR Bail Spring
32	1200520	32-6000SG Bail Spring
34	1211513	34-3000FRC Bail Arm
34	1214201	34-6000FRC Bail Arm
34C	1203990	34C-3000PUR Pivot Arm
34C	1191656	34C-7000SG Pivot Arm
35	1191674	35-3000SG Line Roller
35A	1203992	35A-3000PUR Line Roller Bushing
36	1191699	36-3000SG Bail Stud Screw (PURII5000)
36	1203993	36-3000PUR Bail Stud Screw (PURII5000)
38	1204049	38-5000PUR Rotor Nut
38A	1203995	38A-3000PUR Rotor Locking Plate Screw
39	1204051	39-5000PUR Main Shaft Assembly
39	1214203	39-6000FRC Main Shaft Assembly
43	1191805	43-5000SG Crosswind Block
43A	1191820	43A-5000SG Crosswind Block Plate
43B	1203997	43B-3000PUR Crosswind Block Plate Screw (2 req)
44	1191845	44-5000SG Crosswind Block Screw (2 req)
45	1308162	45-PURII5000 Housing Cover
46	1204054	46-5000PUR Housing Cover Screw (4 req)
47	1308163	47-PURII5000 Spool Assembly
47	1308164	47-PURII6000 Spool Assembly
48	1211625	48-5000SG Click Tongue
48A	1211626	48A-5000SG Click Tongue Washer
48B	1211612	48B-5000SG Spool Click Screw
49	1211627	49-5000SG Click Tongue Spring
51	1287230	51-6000PUR Drag Retaining Ring
52	1308165	52-PURII5000 Drag Knob Assembly
56	1192036	56-5000SG Drag Washer (5 req)
57	1192044	57-5000SG Keyed Washer (3 req)
58	1192053	58-5000SG Eared Washer (2 req)
60	1192062	60-5000SG Thrust Washer
95B	1192186	95B-5000SG Rotor Locking Plate
98C	1192215	98C-5000SG Clutch/Sleeve Assembly
132	1192297	132-5000SG Roller Washer
132A	1192302	132A-3000SG Line Roller Washer (2 req)
231	1192503	231-5000SG Crosswind Gear
231	1200523	231-6000SG Crosswind Gear
233	1308166	233-PURII5000 Bearing Cover Assembly

KEY NO.	PART NO.	DESCRIPTION
1	1308153	1-PURII5000 Housing
1	1308154	1-PURII6000 Housing
8	1204009	8-5000PUR Main Gear
8A	1191030	8A-5000SG Shim
11	1191085	11-5000SG Bushing
15	1308155	15-PURII5000 Handle Assembly
19	1204011	19-5000PUR Pinion Gear
19A	1191253	19A-5000SG Pinion Bushing
20	1204012	20-5000PUR Ball Bearing (4 req)
21	1192636	21-5000SG Bearing Retainer
21A	1204016	21A-5000PUR Bearing Retainer Screw (3 req)
21B	1192650	21B-5000SG Collar
22	1203978	22-3000PUR Bail Pivot Cover Screw
22	1204018	22-6000PUR Bail Pivot Cover Screw
24	1308156	24-PURII5000 Bail Wire
24	1308157	24-PURII6000 Bail Wire
25	1308145	25-PURII3000 Bail Holder
25	1308159	25-PURII6000 Bail Holder
27	1308160	27-PURII5000 Rotor (w/weight & screw)

407-PURII5000/PURII6000 Rev. 1 6-3-13

1292960/1292962