




PARTS LIST FOR MODEL SSV6500BLS



407-SSV6500BLS Rev1 04-01-13
1292946

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	1313703	1-SSV6500BLS Body Assembly	35	1313708	35-SSV6500BLS Line Roller
2L	1277035	2L-SSV6500 Body Seal	35A	1277060	35A-SSV6500 Line Roller Ball Bearing
8	1277036	8-SSV6500 Drive Gear	36	1277061	36-SSV6500 Line Roller Screw
8A	1277037	8A-SSV6500 Drive Gear Spin Washer	38	1277062	38-SSV6500 Rotor Nut
15	1277038	15-SSV6500 Handle Assembly	39A	1277063	39A-SSV6500 Rotor Nut Lock Plate Screw
15L	1292783	15L-SSV6500 Handle Seal	39D	1277064	39D-SSV6500 Rotor Washer
19	1277041	19-SSV6500 Pinion Gear	39	1277065	39-SSV6500 Main Shaft
19A	1314711	19A-SSV6500BLS Pinion Gear Washer	39A	1277066	39A-SSV6500 Spool Adjust Washer
19B	1313704	19B-SSV6500BLS Pinion Seal	39B	1277067	39B-SSV6500 Main Shaft Washer
20A	1277042	20A-SSV6500 Ball Bearing (4req)	43	1277068	43-SSV6500 Oscillation Slider
21	1313705	21-SSV6500BLS Pinion Bearing Retainer	43A	1277069	43A-SSV6500 Oscillation Slider Guide
21A	1277044	21A-SSV6500 Pinion Bearing Retainer Screw (3req)	43B	1277070	43B-SSV6500 Oscillation Slider Guide Screw (2req)
21B	1277045	21B-SSV6500 Pinion Ball Bearing Collar	43C	1277071	43C-SSV6500 Oscillation Slider Busting Screw
22A	1277047	22A-SSV			