




PARTS LIST FOR MODEL SSV5500/SSV6500



KEY NO.	PART NO.	DESCRIPTION
28D	1277109	28D-SSV6500 Rotor Brake
28S	1277054	28S-SSV5500 Rotor Brake Screw (2 req.)
31	1277055	31-SSV5500 Bail Arm Screw (2 req.)
32	1277056	32-SSV5500 Bail Spring
34	1277057	34-SSV5500 Bail Arm
34C	1277058	34C-SSV5500 Pivot Arm
35	1277059	35-SSV5500 Line Roller
35A	1277060	35A-SSV5500 Line Roller Ball Bearing
36	1277061	36-SSV5500 Line Roller Screw
38	1277062	38-SSV5500 Rotor Nut
38A	1277063	38A-SSV5500 Rotor Nut Lock Plate Screw
38D	1277064	38D-SSV5500 Rotor Washer
39	1277065	39-SSV5500 Main Shaft
39A	1277066	39A-SSV5500 Spool Adjust Washer
39B	1277067	39B-SSV5500 Main Shaft Washer
43	1277068	43-SSV5500 Oscillation Slider
43A	1277069	43A-SSV5500 Oscillation Slider Guide
43B	1277070	43B-SSV5500 Oscillation Slider Guide Screw (2 req.)
43C	1277071	43C-SSV5500 Oscillation Slider Bushing Screw
43D	1279457	43D-SSV3500 Oscillation Slider Bushing
44	1277072	44-SSV5500 Main Shaft Screw (2 req.)
45	1277073	45-SSV5500 Body Cover
45	1277110	45-SSV6500 Body Cover
46	1277074	46-SSV5500 Body Cover Screw (4 req.)
47	1277075	47-SSV5500 Spool Assembly
47	1277111	47-SSV6500 Spool Assembly
47B	1277076	47B-SSV5500 Spool Band
47C	1277077	47C-SSV5500 Drag Cover
47D	1277078	47D-SSV5500 Line Clip
47E	1277079	47E-SSV5500 Line Clip Bushing
47F	1277080	47F-SSV5500 Line Clip Retainer
47F	1277112	47F-SSV6500 Line Clip Retainer
47P	1277081	47P-SSV5500 Spool
47P	1277113	47P-SSV6500 Spool
47S	1277082	47S-SSV5500 Drag Drive Plate Seal
48	1277083	48-SSV5500 Spool Clicker
48S	1277084	48S-SSV5500 Drag Cover Seal
51	1277085	51-SSV5500 Drag Washer Retainer
51A	1277086	51A-SSV5500 Bearing Retainer Screw (6 req.)
52	1277087	52-SSV5500 Drag Knob Assembly
52	1277114	52-SSV6500 Drag Knob Assembly
53S	1293252	53S-SSV5500 Drag Knob Seal
56	1277088	56-SSV5500 Drag Friction Washer (2 req.)
56T	1277089	56T-SSV5500 Drag Friction Washer
57	1277090	57-SSV5500 Keyed Drag Washer (2 req.)
57T	1277091	57T-SSV5500 Keyed Drag Washer
63	1277092	63-SSV5500 Spool Bushing
95B	1277093	95B-SSV5500 Rotor Nut Locking Plate
98	1277094	98-SSV5500 Clutch / Sleeve Assembly
117	1277095	117-SSV5500 Drag Drive Plate
132	1277096	132-SSV5500 Line Roller Collar
132A	1277097	132A-SSV5500 Line Roller Washer
231	1277098	231-SSV5500 Oscillation Gear
231B	1277100	231B-SSV5500 Oscillation Gear Screw
232	1277101	232-SSV5500 Bearing Retainer(2 req.)
232	1277115	232-SSV6500 Bearing Retainer(2 req.)
232B	1302502	232B-SSV3500 Bearing Retainer O - Ring(2 req.)
233A	1277103	233A-SSV5500 Handle Cap
233C	1277104	233C-SSV5500 Handle Cap Washer

KEY NO.	PART NO.	DESCRIPTION
1	1277034	1-SSV5500 Body Assembly
1	1277105	1-SSV6500 Body Assembly
2L	1277035	2L-SSV5500 Body Seal
8	1277036	8-SSV5500 Drive Gear
8A	1277037	8A-SSV5500 Drive Gear Shim Washer
15	1277038	15-SSV5500 Handle Assembly
15L	1292783	15L-SSV5500 Handle Seal
19	1277041	19-SSV5500 Pinion Gear
20A	1277042	20A-SSV5500 Ball Bearing(4 req.)
21	1277043	21-SSV5500 Pinion Bearing Retainer
21A	1277044	21A-SSV5500 Pinion Retainer Screw (3 req.)
21B	1277045	21B-SSV5500 Pinion Ball Bearing Collar
22	1277046	22-SSV5500 Rotor Cover Screw
22A	1277047	22A-SSV5500 Drag Cover Screw (3 req.)
24	1277048	24-SSV5500 Bail Assembly
24	1277106	24-SSV6500 Bail Assembly
25	1277049	25-SSV5500 Bail Holder
27	1277050	27-SSV5500 Rotor
27	1277107	27-SSV6500 Rotor
27A	1277051	27A-SSV5500 Rotor Cover
27A	1277108	27A-SSV6500 Rotor Cover
28	1277052	28-SSV5500 Bail Trip Lever
28D	1277053	28D-SSV5500 Rotor Brake