




PARTS LIST FOR MODELS TRQ30B & TRQ30G & TRQ30BEU

REEL ASM NOS. 1206074 & 1236679 & 1207744



| KEY NO. | PART NO. | ORIGINAL PENN NO. | DESCRIPTION |
|---------|----------|-------------------|-----------------------------|
| 1 | 1228844 | 001 TRQ30 | R.S. Plate Asm (Black/Gold) |
| 1 | 1243347 | 001 TRQ30G | R.S. Plate Asm (Gold/Black) |
| 1A | 1228856 | 001ATRQ40 | R.S. Inner Plate |
| 1D | 1228867 | 001DTRQ40 | Gear Cover (Black) |
| 1D | 1243354 | 001DTRQ40S | Gear Cover (Silver) |
| 4 | 1180755 | 004 060 | Graphite Washer |
| 4A | 1180770 | 004 300T | Graphite Washer |
| 5 | 1229005 | 005 TRQ15 | Main Gear Asm |
| 6 | 1237037 | 006 TRQ40 | Drag Washer, Tab (3 req) |
| 8 | 1229041 | 008 TRQ40 | Detent Spring Retainer |
| 8A | 1229050 | 008ATS7-8 | Shim |
| 8B | 1181056 | 008 060 | Tension Washer |
| 10 | 1229306 | 010 TRQ40 | Drag Star Asm (Black) |
| 10 | 1243355 | 010 TRQ40G | Drag Star Asm (Gold/Silver) |
| 10B | 1181218 | 010B2.5FR | Detent Spring |
| 11 | 1229316 | 011 TRQ40 | Jack |
| 12 | 1181271 | 012 555 | Yoke |
| 12A | 1229319 | 012ATRQ40 | Yoke Pin (2 req) |
| 13 | 1229339 | 013 TRQ15 | Pinion |
| 13R | 1229364 | 013RTRQ40 | Retaining Ring |
| 15 | 1229374 | 015 TRQ40 | Dog Asm (2 req) |
| 18 | 1181623 | 018 505 | Tension Washer (2 req) |
| 18A | 1181624 | 018 525 | Yoke Spring (2 req) |
| 19 | 1229430 | 019 TRQ40 | Eccentric |

| KEY NO. | PART NO. | ORIGINAL PENN NO. | DESCRIPTION |
|---------|----------|-------------------|-------------------------------|
| 20 | 1181785 | 020 525 | Eccentric Spring |
| 21 | 1229450 | 021 TRQ40 | Lever Asm (Black/Gold) |
| 21 | 1243362 | 021 TRQ40G | Lever Asm (Gold/Silver) |
| 22 | 1229457 | 022 TRQ40 | 8-32 Sems Screw (Black) |
| 22 | 1181908 | 022 060CH | 8-32 Sems Screw (Silver) |
| 23 | 1229462 | 023 TRQ40 | Handle Nut (Black) |
| 23 | 1243364 | 023 TRQ40S | Handle Nut (Silver) |
| 24 | 1229501 | 024 TRQ40 | Handle Asm (Black/Gold) |
| 24 | 1241383 | 024 TRQ40G | Handle Asm (Gold/Silver) |
| 26 | 1229579 | 026 TRQ25 | Eccentric Bushing |
| 26A | 1229583 | 026ATRQ40 | Lever Washer |
| 26B | 1214706 | 026B525MAG2 | Spool Tension Cap |
| 26D | 1125769 | 026D525MAG2 | Click Spring |
| 26F | 1125768 | 026F525MAG2 | Click Plate A |
| 26G | 1125772 | 026G525MAG2 | Click Plate B |
| 26R | 1214654 | 026R525MAG2 | Retaining Ring |
| 27 | 1229716 | 027 TRQ30 | Plate, L.S. (Black/Gold) |
| 27 | 1243380 | 027 TRQ30G | Plate, L.S. (Gold/Black) |
| 29 | 1229807 | 029 TRQ30 | Spool (Black/Gold) |
| 29 | 1243388 | 029 TRQ30G | Spool (Gold/Silver) |
| 32 | 1214707 | 032 525MAG2 | 5-40 Screw (Black) |
| 32 | 1184436 | 110 050 | 5-40 Screw (Silver) |
| 33 | 1182754 | 033 113 | Rod Clamp |
| 33C | 1229936 | 033CTRQ40 | Rod Clamp Kit |
| 34 | 1182788 | 034 045 | 10-24 Screw (2 req) |
| 35 | 1229949 | 035 TRQ40 | Click Tongue |
| 36 | 1229953 | 036 TRQ40 | Click Button (Black) |
| 36 | 1243392 | 036 TRQ40S | Click Button (Silver) |
| 38 | 1229971 | 038 TRQ40 | Screw (Black) (2 req) |
| 38 | 1243393 | 038 TRQ40S | Screw (Silver) (2 req) |
| 38A | 1229973 | 038ATRQ40 | Screw (Black) |
| 38A | 1243394 | 038ATRQ40S | Screw (Silver) |
| 39 | 1229994 | 039 TRQ40 | Screw (Black) (3 req) |
| 39 | 1243395 | 039 TRQ40S | Screw (Silver) (3 req) |
| 40 | 1230004 | 040 TRQ40 | Bushing, L.S. Spool |
| 40C | 1208115 | 040C525MAG2 | Washer, Metal Thrust |
| 40D | 1125771 | 040D525MAG2 | Washer, Rubber Thrust |
| 55 | 1183873 | 055 012H | Ball Bearing |
| 55A | 1183880 | 055 113H | Ball Bearing |
| 55B | 1214665 | 055 525MAG2 | Ball Bearing (12X8X3.5) |
| 55D | 1214666 | 055A525MAG2 | Ball Bearing (2 req) |
| 55L | 1192031 | 055L965 | Ball Bearing (2 req) |
| 62 | 1236596 | 062 TRQ40 | Click Locator Spring |
| 62A | 1230189 | 062ATRQ40 | Click Button Locator |
| 62B | 1184036 | 062B310 | Click Pin (2 req) |
| 62C | 1184041 | 062C321LH | Spring Cover (2 req) |
| 62D | 1184033 | 062A310 | Click Spring (2 req) |
| 63 | 1230192 | 063 TRQ40 | Screw, Pan Hd (2 req) |
| 69B | 1184125 | 069B050 | Retaining Ring |
| 71 | 1230216 | 071 TRQ30 | Spool Spindle |
| 71B | 1230226 | 071BTRQ40 | Spool Driver |
| 71C | 1230227 | 071CTRQ40 | Retaining Ring |
| 81 | 1230303 | 081 TRQ40 | Click Ratchet |
| 86 | 1184251 | 086 049L | Drag Washer, Keyed (3 req) |
| 95 | 1230373 | 095 TRQ40 | Click Housing |
| 98 | 1230412 | 098 TRQ40 | Anti-Reverse Ratchet |
| 98B | 1200401 | 098B750M | Anti-Reverse Bearing |
| 98S | 1230425 | 098STRQ40 | Bearing Sleeve |
| 101 | 1184404 | 101 050S | 5-40 Screw (2 req) |
| 110A | 1230439 | 110ATRQ40 | Handle Nut Lock (Black/Gold) |
| 110A | 1242335 | 110ATRQ40G | Handle Nut Lock (Gold/Silver) |
| 120 | 1184522 | 120 113H | O-Ring |
| 134 | 1230592 | 134 TRQ40 | Gear Stud |
| 149 | 1184702 | 149 045 | Rod Clamp Nut (2 req) |
| 149A | 1184706 | 149 200 | Hex Nut (2 req) |
| 158 | 1230647 | 158 TRQ40 | Dog Pin (2 req) |
| 183 | 1230754 | 183 TRQ30 | Frame Asm (Black/Gold) |
| 183 | 1243411 | 183 TRQ30G | Frame Asm (Gold/Black) |
| 183 | 1243409 | 183 TRQ30BEU | Frame Asm (Blk/Gld Euro) |