


Supreme[®] 110 Baitcast Reel

Use this parts list for ordering replacement parts for your Supreme 110 Baitcast Reel.



Part #	Part Name	Part #	Part Name
1	Left Side Cover	35	Friction Washer
2	Control Dial	36	Drive Gear
3	Dial Friction Ring	37	Fiber Washer
4	Dial Base	38	Drag Washer
5	Dial Base Spring	39	Spring D Washer
6	Spool Cover	40	Spacer
7	Magnet Plate Assembly	41	Ball Bearing
8	Spool Bushing	42	Hood
9	Spool Shim	43	Retainer Screw
10	Spool	44	Anti-Reverse Pawl Assembly
12	Click Spring	45	Pinion Assembly
13	Click Washer	46	Pinion Yoke
14	Carrier Guide	47	Yoke Spring
15	Line Guide Assembly	48	Right Side Cover
16	Line Guide Pawl	49	Thumb Screw
17	Pawl Cover	50	O-Ring
18	Shuttle Screw	51	Tension Knob Washer
19	Shuttle Gear	52	Rubber Washer
20	Frame	53	Tension Knob
21	Thumb Lever	54	Star Drag
23	Release Crank	55	Handle Spring Washer
24	Release Slider	56	Handle Assembly
25	Slider Screw	57	Handle Nut
26	Release Spring	58	Lock Cap
27	Bushing	59	Lock Cap Screw
28	Retaining Ring	60	Plate Screw
29	Crank Shaft Retainer	61	Spool Cover Screw
30	Crank Shaft	62	Cover Screw
31	Star Trip Latch	63	Bushing
32	Ring Trip Latch	64	Thumb Screw O-Ring
33	Ratchet Washer	65	Flipping Switch
34	Ratchet		