


# QUANTUM<sup>®</sup>

## AC40PTi



Quantum AC40PTi Spinning Reel Part List

Key #	Description	Qty.	Part No.	Key #	Description	Qty.	Part No.
1	Drag Knob Assembly	1	BAA332-01	28	Pinion Ball Bearing	1	BAA028-01
2	Spool Assembly	1	DAA320-01	29	Pinion Bushing	1	BAA213-01
3	Rotor Nut Lock Screw	1	BAA094-01	30	Pinion	1	DAA011-01
4	Spool Adjust Washer	1	BAA030-01	31	Stopper Cam	1	BAA090-01
5	Click Gear	1	BAA094-01	32	Clutch Spring	1	BAA216-01
6	Rotor Nut	1	BAA006-01	33	Stopper Cam Spring	1	BAA089-01
7	Main Shaft	1	BAA015-01	34	Stopper Lever	1	BAA059-01
8	Arm Lever Screw	2	BAA042-01	35	Stopper Lever Screw	1	BAA135-01
9	Rotor	1	DAA009-01	37	Handle Screw Assembly	1	BAA354-01
10	Kick Lever	1	DAA019-01	40	Rear Cap Screw (Front)	1	CAA168-01
11	Acuator	1	DAA031-01	41	Body Assembly	1	DAA301-01
12	Actuator Spring	1	DAA022-01	42	Body Rear Cap	1	DAA140-01
13	Arm Lever Cover	1	DAA087-01	43	Tapping Screw	1	CAA094-01
14	Arm Lever Cover Screw	3	BAA077-01	44	Main Shaft Screw	1	BAA100-01
15	Line Roller Screw	1	BAA108-01	45	O/S Slider	1	DAA025-01
16	Arm Lever	1	DAA007-01	46	O/S Gear	1	DAA053-01
17	Line Roller Collar	1	DAA102-01	47	O/S Gear Ball Bearing	1	BAA158-01
18	Line Roller Washer	1	BAA102-01	48	O/S Slider Retainer	1	DAA078-01
19	Line Roller	1	DAA004-01	49	Body Ball Bearing	1	BAA157-01
20	Line Roller Ball Bearing	1	GH202-01	51	Drive Gear	1	BAA012-01
21	Bail Assembly	1	DAA347-01	52	Drive Gear Adjust Wahser	1	BAA105-01
22	Rotor Adjust Washer	1	BAA105-01	53	Side Cover Ball Bearing	1	CAA157-01
23	Tapping Screw (Flat head)	3	CAA057-01	54	Side Cover Assembly	1	DAA323-01
24	Clutch Stack Retainer	1	CAA040-01	55	Side Cover Screw	3	BAA085-01
25	Clutch Retainer Ball Bearing	1	CAA028-01	56	Side Cover Screw (Flat head)	1	DAA057-01
26	Clutch Bearing Adapter	1	BAA190-01	58	Handle Assembly	1	DAA418-01
27	Clutch Unit	1	BAA363-01				